
## Hazard warning flasher



Day or night, if your vehicle becomes a traffic hazard, use the hazard warning flasher. Avoid stopping on the road. It is best to safely pull off the road if a problem occurs. Turn on the hazard warning by pushing the hazard warning flasher switch. Turn it off by pushing the switch again.

## **Engine overheating**

## 

Never attempt to remove the radiator cap until the engine has been shut off and has fully cooled down. When the engine is hot, the coolant is under pressure. Removing the cap while the engine is still hot could release a spray of boiling hot coolant, which could burn you very seriously.

If the engine overheats, safely pull off the road and stop the vehicle in a safe place.

## If steam is coming from the engine compartment

Turn the engine off and get everyone away from the vehicle until it cools down.