

the schedule described in the Warranty and Maintenance Booklet.


Steering.

■ Tilt steering wheel

⚠ WARNING

Do not adjust the steering tilt position while driving. This may cause loss of vehicle control and result in personal injury.

▼ Tilt adjustment



1. Pull the tilt lock lever down.
2. Move the steering wheel to the desired level.
3. Push the lever up to lock the steering wheel in place.
4. Make sure that the steering wheel is securely locked by moving it up and down.

■ Power steering



CAUTION

Do not hold the steering wheel at the fully locked position left or right for more than five seconds. This may damage the power steering pump.

The power steering system operates only when the engine is running. If you lose power steering assist because the engine stops or the system fails to function, you can steer but it will take much more effort.

Cruise control (if equipped)



WARNING

Do not use the cruise control under any of the following conditions. This may cause loss of vehicle control:

- **driving up or down a steep grade**
- **driving on slippery or winding roads**
- **driving in heavy traffic**

Cruise control enables you to maintain a constant vehicle speed without holding your foot on the accelerator pedal and it is operative when the vehicle speed is 25 mph (40 km/h) or more. Make sure the main switch is turned "OFF" when the cruise control is not in use.