


10. Diagnostics Chart with Select Monitor

A: BASIC DIAGNOSTIC CHART



NOTE:

To check harness for broken wires or short circuits, shake it while holding it or the connector.

B: LIST OF TROUBLE CODE

Code	Display screen (FB1)	Contents of diagnosis	Ref. to
—	ERROR 3 (1)	Select monitor communication failure	4-4c [T10C0]
11	NO TROUBLE	Although no trouble appears on the select monitor display, the ABS warning light remains on.	4-4c [T10D0]
21	FR. SS HARD	Open circuit or input voltage too high of FR sensor	4-4c [T10E0]
22	FR. SS SOFT	Abnormal ABS sensor signal of FR sensor	4-4c [T10I0]
23	FL. SS HARD	Open circuit or input voltage too high of FL sensor	4-4c [T10F0]
24	FL. SS SOFT	Abnormal ABS sensor signal of FL sensor	4-4c [T10J0]
25	RR. SS HARD	Open circuit or input voltage too high of RR sensor	4-4c [T10G0]
26	RR. SS SOFT	Abnormal ABS sensor signal of RR sensor	4-4c [T10K0]
27	RL. SS HARD	Open circuit or input voltage too high of RL sensor	4-4c [T10H0]
28	RL. SS SOFT	Abnormal ABS sensor signal of RL sensor	4-4c [T10L0]
29	EITHER. SS SOFT	Abnormal ABS sensor signal (any one of four)	4-4c [T10M0]
31	FR. EV VALVE	Abnormal FR inlet valve	4-4c [T10N0]
32	FR. AV VALVE	Abnormal FR outlet valve	4-4c [T10R0]
33	FL. EV VALVE	Abnormal FL inlet valve	4-4c [T10O0]
34	FL. AV VALVE	Abnormal FL outlet valve	4-4c [T10S0]
35	RR. EV VALVE	Abnormal RR inlet valve	4-4c [T10P0]
36	RR. AV VALVE	Abnormal RR outlet valve	4-4c [T10T0]
37	RL. EV VALVE	Abnormal RL inlet valve	4-4c [T10Q0]
38	RL. AV VALVE	Abnormal RL outlet valve	4-4c [T10U0]
41	ECU	Abnormal ABSCM	4-4c [T10V0]
42	LOW VOLTAGE	Source voltage is low.	4-4c [T10W0]
44	CCM LINE	A combination of AT control abnormalities (ABS not in control)	4-4c [T10X0]
	CCM OPEN	A combination of AT control abnormalities (ABS in control)	4-4c [T10Y0]
46	GS POWER OVER	G sensor line voltage too high	4-4c [T10Z0]
	GS POWER LOW	G sensor line voltage too low	4-4c [T10AA0]
51	V. RELAY	Abnormal valve relay	4-4c [T10AB0]
	V. RELAY ON	Valve relay ON failure	4-4c [T10AC0]
52	M. RELAY OPEN	Open circuit of motor relay	4-4c [T10AD0]
	M. RELAY ON	Motor relay ON failure	4-4c [T10AE0]
	MOTOR	Abnormal motor	4-4c [T10AF0]
54	BLS	Abnormal stop light switch	4-4c [T10AG0]
56	G SENSOR LINE	Open or short circuit of G sensor	4-4c [T10AH0]
	G SENSOR +B	Battery short of G sensor	4-4c [T10AI0]
	G SENSOR H μ	Abnormal G sensor high μ output	4-4c [T10AJ0]
	G SENSOR STICK	G sensor output is stuck.	4-4c [T10AK0]

NOTE:

High μ means high friction coefficient against road surface.

ERROR 3
 B4M0943


**C: ERROR 3 (1)
 — SELECT MONITOR COMMUNICATION
 FAILURE —**

DIAGNOSIS:


- Faulty harness connector

TROUBLE SYMPTOM:


- ABS warning light remains on.
- ERROR 3 or 1 appears on the select monitor display.



WIRING DIAGRAM:



B4M1043



10C1	CHECK GENERATOR.
-------------	-------------------------

- 1) Start the engine.
- 2) Idle the engine.
- 3) Measure voltage between generator and chassis ground.

CHECK : **Terminal Generator B terminal (+) — Chassis ground (-):**
Is voltage 10 — 15 V?

YES : Go to step **10C2**.

NO : Repair generator.

10C2	CHECK BATTERY TERMINAL.
-------------	--------------------------------

Turn ignition switch to OFF.

CHECK : **Is there poor contact at battery terminal?**

YES : Repair battery terminal.

NO : Go to step **10C3**.

10C3	CHECK COMMUNICATION OF SELECT MONITOR.
-------------	---

Using the select monitor, check whether communication to other system (such as engine, AT, etc.) can be executed normally.

CHECK : **Are the name and year of the system displayed on the select monitor?**

YES : Go to step **10C4**.

NO : Repair select monitor communication cable and connector.


10C4	CHECK INSTALLATION OF ABSCM CONNECTOR.
-------------	---

Turn ignition switch to OFF.

CHECK : **Is ABSCM connector inserted into ABSCM until the clamp locks onto it?**

YES : Go to step **10C5**.

NO : Insert ABSCM connector into ABSCM until the clamp locks onto it.


**10C5 CHECK POWER SUPPLY OF ABSCM.**

- 1) Disconnect connector from ABSCM.
- 2) Start engine.
- 3) Idle the engine.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 28 (+) — Chassis ground (-): Is voltage 10 — 15 V?**

YES : Go to step 10C6.

NO : Repair ABSCM power supply circuit.


**10C6 CHECK GROUND CIRCUIT OF ABSCM.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 1 — Chassis ground: (F49) No. 55 — Chassis ground: Is resistance less than 0.5 Ω?**

YES : Repair harness/connector between ABSCM and select monitor.

NO : Go to step 10C7.

**10C7**

CHECK HARNESS CONNECTOR BETWEEN ABSCM AND DATA LINK CONNECTOR.

- 1) Turn ignition switch OFF.
- 2) Measure resistance between ABSCM connector and data link connector.

CHECK : **Connector & terminal**
(F49) No. 11 — (B78) No. 3
(F49) No. 38 — (B78) No. 2
Is resistance less than 0.5 Ω?

YES : Repair harness and connector between ABSCM and data link connector.

NO : Go to step **10C8**.


10C8

CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND DATA LINK CONNECTOR.

CHECK : **Is there poor contact in connectors between ABSCM and data link connector?**

YES : Repair connector.

NO : Replace ABSCM.



D: NO TROUBLE
— ALTHOUGH NO TROUBLE APPEARS ON THE SELECT MONITOR DISPLAY, THE ABS WARNING LIGHT REMAINS ON. —

DIAGNOSIS:


- ABS warning light circuit is shorted.

TROUBLE SYMPTOM:


- ABS warning light remains on.
- NO TROUBLE displayed on the select monitor.

NOTE:

When the ABS warning light is OFF and “NO TROUBLE” is displayed on the select monitor, the system is in normal condition.



WIRING DIAGRAM:



10D1	CHECK GROUND SHORT OF HARNESS.
-------------	---------------------------------------

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Disconnect connector (F50) from relay box.
- 4) Turn ignition switch to ON.

CHECK : ***Does the ABS warning light remain OFF?***

YES : Go to step **10D2**.

NO : Repair harness between ABSCM, relay box ABS warning light.

10D2	CHECK GROUND SHORT OF RELAY BOX.
-------------	---

- 1) Turn ignition switch to OFF.
- 2) Connect connector (F50) to relay box.
- 3) Disconnect connector (ABS1) from hydraulic unit.
- 4) Remove valve relay from relay box.
- 5) Turn ignition switch to ON.

CHECK : ***Does the ABS warning light remain OFF?***

YES : Replace ABSCM.

NO : Replace relay box.

D•NEW 21 (FB1)
FR. SS HARD

B4M0945

E: 21 FR. SS HARD
— ABNORMAL FRONT RH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

D•NEW 23 (FB1)
FL. SS HARD

B4M0946

F: 23 FL. SS HARD
— ABNORMAL FRONT LH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

D•NEW 25 (FB1)
RR. SS HARD

B4M0947

G: 25 RR. SS HARD
— ABNORMAL REAR RH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

D•NEW 27 (FB1)
RL. SS HARD

B4M0948


H: 27 RL. SS HARD
— ABNORMAL REAR LH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

DIAGNOSIS:


- Faulty ABS sensor (Broken wire, input voltage too high)
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:



FR (F05)
30 km/h

B4M0922

10H1 CHECK OUTPUT OF ABS SENSOR USING SELECT MONITOR.

Read the ABS sensor output corresponding to the faulty system in the select monitor function mode.

NOTE:

The select monitor display shows that the front right wheel is rotating at 30 km/h.

CHECK : *Does the speed indicated on the display change in response to the speedometer reading during acceleration/deceleration when the steering wheel is in the straight-ahead position?*

YES : Go to step 10H2.

NO : Go to step 10H5.

10H2 CHECK ABS SENSOR MECHANICAL TROUBLE.

CHECK : *Tightening torque:
32±10 N·m (3.3±1.0 kg-m, 24±7 ft-lb)
Are the ABS sensor installation bolts tightened securely?*


YES : Go to next **CHECK** .

NO : Tighten ABS sensor installation bolts securely.

CHECK : *Tightening torque:
13±3 N·m (1.3±0.3 kg-m, 9±2.2 ft-lb)
Are the tone wheel installation bolts tightened securely?*

YES : Go to next step.


NO : Tighten tone wheel installation bolts securely.



1) Measure tone wheel-to-pole piece gap over entire perimeter of the wheel.

CHECK : *Is the gap within the specifications shown in the following table?*

	Front wheel	Rear wheel
Specifications	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



YES : Go to next step.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

2) Measure hub runout.

CHECK : *Is the runout less than 0.05 mm (0.0020 in)?*

YES : Go to step **10H3**.

NO : Repair hub.

10H3	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND ABS SENSOR.
-------------	--

CHECK : *Is there poor contact in connectors between ABSCM and ABS sensor?*

YES : Repair connector.

NO : Go to step **10H4**.

10H4	CHECK ABSCM.
-------------	---------------------

1) Connect all connectors.

2) Erase the memory.

3) Perform inspection mode.

4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*


YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

NOTE:

Check harness and connectors between ABSCM and ABS sensor.

Except OUTBACK with step roof model



B4M0806B

10H5 CHECK RESISTANCE OF ABS SENSOR.


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance of ABS sensor connector terminals.

CHECK : *Trouble code/Connector & terminal*
 21/to (B6) No. 1 — No. 2
 23/to (B15) No. 1 — No. 2
 25/to (P8) No. 1 — No. 2
 27/to (P9) No. 1 — No. 2
 Is resistance 0.8 — 1.2 kΩ?

YES : Go to step 10H6.


NO : Replace ABS sensor.

OUTBACK with step roof model



B4M1036A

Except OUTBACK with step roof model



B4M0807B

10H6 CHECK BATTERY SHORT OF ABS SENSOR.


- 1) Disconnect connector from ABSCM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ABS sensor and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 21/to (B6) No. 1 (+) — Chassis ground (-)
 23/to (B15) No. 1 (+) — Chassis ground (-)
 25/to (P8) No. 1 (+) — Chassis ground (-)
 27/to (P9) No. 1 (+) — Chassis ground (-)
 Is voltage 0 V?

YES : Go to next step.

NO : Replace ABS sensor.

OUTBACK with step roof model




B4M1037A

- 4) Turn ignition switch to OFF.
- 5) Measure voltage between ABS sensor and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 21/to (B6) No. 1 (+) — Chassis ground (-)
 23/to (B15) No. 1 (+) — Chassis ground (-)
 25/to (P8) No. 1 (+) — Chassis ground (-)
 27/to (P9) No. 1 (+) — Chassis ground (-)
 Is voltage 0 V?

YES : Go to step 10H7.

NO : Replace ABS sensor.



10H7


CHECK HARNESS CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

- 1) Connect connector to ABS sensor.
- 2) Measure resistance between ABSCM connector terminals.

CHECK : *Trouble code/Connector & terminal*
 21/(F49) No. 14 — No. 15
 23/(F49) No. 49 — No. 19
 25/(F49) No. 18 — No. 46
 27/(F49) No. 16 — No. 17
Is resistance 0.8 — 1.2 kΩ?

YES : Go to step 10H8.

NO : Repair harness connector between ABSCM and ABS sensor.



10H8

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 21/(F49) No. 14 — Chassis ground
 23/(F49) No. 49 — Chassis ground
 25/(F49) No. 18 — Chassis ground
 27/(F49) No. 16 — Chassis ground
Is voltage 0 V?

YES : Go to next step.

NO : Repair harness between ABSCM and ABS sensor.

- 3) Turn ignition switch to OFF.

- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 21/(F49) No. 14 — Chassis ground
 23/(F49) No. 49 — Chassis ground
 25/(F49) No. 18 — Chassis ground
 27/(F49) No. 16 — Chassis ground
Is voltage 0 V?

YES : Go to step 10H9.

NO : Repair harness between ABSCM and ABS sensor.

10H9	CHECK ABS SENSOR MECHANICAL TROUBLE.
-------------	---

CHECK : **Tightening torque:**
 $32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft}\cdot\text{lb}$)
Are the ABS sensor installation bolts tightened securely?


YES : Go to next **CHECK** .

NO : Tighten ABS sensor installation bolts securely.

CHECK : **Tightening torque:**
 $13 \pm 3 \text{ N}\cdot\text{m}$ ($1.3 \pm 0.3 \text{ kg}\cdot\text{m}$, $9 \pm 2.2 \text{ ft}\cdot\text{lb}$)
Are the tone wheel installation bolts tightened securely?

YES : Go to next step.


NO : Tighten tone wheel installation bolts securely.



1) Measure tone wheel-to-pole piece gap over entire perimeter of the wheel.

CHECK : **Is the gap within the specifications shown in the following table?**

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



YES : Go to next step.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

2) Measure hub runout.

CHECK : **Is the runout less than 0.05 mm (0.0020 in)?**

YES : Go to step 10H10.

NO : Repair hub.

10H10	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND ABS SENSOR.
--------------	--

CHECK : *Is there poor contact in connectors between ABSCM and ABS sensor?*

YES : Repair connector.

NO : Go to step **10H11**.

10H11	CHECK ABSCM.
--------------	---------------------

1) Connect all connectors.

2) Erase the memory.

3) Perform inspection mode.

4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

NOTE:

Check harness and connectors between ABSCM and ABS sensor.

D•NEW 22 (FB1)
FR. SS SOFT

B4M0812

I: 22 FR. SS SOFT
— ABNORMAL FRONT RH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

D•NEW 24 (FB1)
FL. SS SOFT

B4M0949

J: 24 FL. SS SOFT
— ABNORMAL FRONT LH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

D•NEW 26 (FB1)
RR. SS SOFT

B4M0950

K: 26 RR. SS SOFT
— ABNORMAL REAR RH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

D•NEW 28 (FB1)
RL. SS SOFT

B4M0951


L: 28 RL. SS SOFT
— ABNORMAL REAR LH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

DIAGNOSIS:


- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty harness/connector

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1035



10L1

CHECK OUTPUT OF ABS SENSOR USING SELECT MONITOR.

Read the ABS sensor output corresponding to the faulty system in the select monitor function mode.

NOTE:

The select monitor display shows that the front right wheel is rotating at 30 km/h.

CHECK : *Does the speed indicated on the display change in response to the speedometer reading during acceleration/deceleration when the steering wheel is in the straight-ahead position?*

YES : Go to step 10L2.

NO : Go to step 10L3.

10L2

CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

CHECK : *Is there poor contact in connectors between ABSCM and ABS sensor?*

YES : Repair connector.

NO : Go to step 10L3.

10L3

CHECK SOURCES OF SIGNAL NOISE.

CHECK : *Is the car telephone or the wireless transmitter properly installed?*


YES : Go to next **CHECK** .

NO : Properly install the car telephone or the wireless transmitter.

CHECK : *Are noise sources (such as an antenna) installed near the sensor harness?*

YES : Install the noise sources apart from the sensor harness.

NO : Go to step 10L4.

**10L4 CHECK SHIELD CIRCUIT.**

- 1) Connect all connectors.
- 2) Measure resistance between shield connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
22/(B100) No. 11 — Chassis ground
24/(B100) No. 2 — Chassis ground
26/(P1) No. 8 — Chassis ground
28/(P1) No. 3 — Chassis ground
Is resistance less than 0.5 Ω?

YES : Go to step 10L5.

NO : Repair shield harness.

10L5 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary noise interference.

10L6	CHECK ABS SENSOR MECHANICAL TROUBLE.
-------------	---

CHECK : **Tightening torque:**
 $32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft}\cdot\text{lb}$)
Are the ABS sensor installation bolts tightened securely?


YES : Go to next **CHECK** .

NO : Tighten ABS sensor installation bolts securely.

CHECK : **Tightening torque:**
 $13 \pm 3 \text{ N}\cdot\text{m}$ ($1.3 \pm 0.3 \text{ kg}\cdot\text{m}$, $9 \pm 2.2 \text{ ft}\cdot\text{lb}$)
Are the tone wheel installation bolts tightened securely?

YES : Go to next step.


NO : Tighten tone wheel installation bolts securely.



1) Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : **Is the gap within the specifications shown in the following table?**

	Front wheel	Rear wheel
Specifications	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



YES : Go to next **CHECK** .

NO : Adjust the gap.

NOTE:

Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

CHECK : **Is an oscilloscope available?**

YES : Go to next step.

NO : Go to step 10).

2) Raise all four wheels of ground.

3) Turn ignition switch OFF.

4) Disconnect connector from ABS control module.


5) Disconnect connector cover from connector.

<Ref. to 4-4c [T8C1] steps 5) to 8).>

6) Connect connector to ABS control module.

7) Connect the oscilloscope to the ABS control module connector in accordance with trouble code.

8) Turn ignition switch ON.



9) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

TROUBLE CODE / Connector & terminal:

22 / (F49) No. 14 (+) — No. 15 (-)

24 / (F49) No. 49 (+) — No. 19 (-)

26 / (F49) No. 18 (+) — No. 46 (-)

28 / (F49) No. 16 (+) — No. 17 (-)

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : *Is oscilloscope pattern smooth, as shown in figure?*

YES : Go to step 10L7.

NO : Go to next step.

10) Remove disc rotor from hub in accordance with trouble code.

CHECK : *Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?*

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to next **CHECK** .

CHECK : *Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?*

YES : Replace ABS sensor or tone wheel.


NO : Go to next step.

11) Measure hub runout.

CHECK : *Is the runout less than 0.05 mm (0.0020 in)?*

YES : Go to step 10L7.

NO : Repair hub.



10L7 CHECK RESISTANCE OF ABS SENSOR.

1) Turn ignition switch OFF.

2) Disconnect connector from ABS sensor.

3) Measure resistance between ABS sensor connector terminals.

CHECK : *Trouble code/Connector & terminal*

22/to (B6) No. 1 — No. 2

24/to (B15) No. 1 — No. 2


26/to (P8) No. 1 — No. 2


28/to (P9) No. 1 — No. 2

Is resistance 0.8 — 1.2 kΩ?

YES : Go to step 10L8.

NO : Replace ABS sensor.







10L8 CHECK GROUND SHORT OF ABS SENSOR.

Measure resistance between ABS sensor and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 22/to (B6) No. 1 — Chassis ground
 24/to (B15) No. 1 — Chassis ground
 26/to (P8) No. 1 — Chassis ground
 28/to (P9) No. 1 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10L9.

NO : Replace ABS sensor.




10L9 CHECK HARNESS CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

- 1) Connect connector to ABS sensor.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance at ABSCM connector terminals.

CHECK : *Trouble code/Connector & terminal*
 22/(F49) No. 14 — No. 15
 24/(F49) No. 49 — No. 69
 26/(F49) No. 18 — No. 46
 28/(F49) No. 16 — No. 17
Is resistance 0.8 — 1.2 kΩ?

YES : Go to step 10L10.

NO : Repair harness connector between ABSCM and ABS sensor.


**10L10 CHECK GROUND SHORT OF HARNESS.**

Measure resistance between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal 22/(F49) No. 14 — Chassis ground
24/(F49) No. 49 — Chassis ground
26/(F49) No. 18 — Chassis ground
28/(F49) No. 16 — Chassis ground
Is resistance more than 1 MΩ?*

YES : Go to step 10L11.

NO : Repair harness connector between ABSCM and ABS sensor.

**10L11 CHECK GROUND CIRCUIT OF ABSCM.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM and chassis ground.

CHECK : *Connector & terminal (F49) No. 1 — GND
(F49) No. 55 — GND
Is resistance less than 0.5 Ω?*

YES : Go to step 10L12.

NO : Repair ABSCM ground harness.

10L12 CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND ABS SENSOR.


CHECK : *Is there poor contact in connectors between ABSCM and ABS sensor?*

YES : Repair connector.

NO : Go to step 10L13.

10L13 CHECK SOURCES OF SIGNAL NOISE.

- CHECK** : *Is the car telephone or the wireless transmitter properly installed?*
- YES** : Go to next **CHECK** .
- NO** : Properly install the car telephone or the wireless transmitter.
- CHECK** : *Are noise sources (such as an antenna) installed near the sensor harness?*
- YES** : Install the noise sources apart from the sensor harness.
- NO** : Go to step **10L14**.

**10L14 CHECK SHIELD CIRCUIT.**

- 1) Connect all connectors.
 - 2) Measure resistance between shield connector and chassis ground.
- CHECK** : *Trouble code/Connector & terminal
22/(B100) No. 11 — Chassis ground
24/(B100) No. 2 — Chassis ground
26/(P1) No. 8 — Chassis ground
28/(P1) No. 3 — Chassis ground
Is resistance less than 0.5 Ω?*
- YES** : Go to step **10L15**.
- NO** : Repair shield harness.

10L15	CHECK ABSCM.
-------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary noise interference.

D•NEW 29 (FB1)
EITHER. SS SOFT

B4M0952


M: 29 EITHER. SS SOFT
— ABNORMAL ABS SENSOR SIGNAL (ANY ONE OF FOUR) —

DIAGNOSIS:


- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty tone wheel
- Wheels turning freely for a long time

TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:



B4M1035


10M1	CHECK IF THE WHEELS HAVE TURNED FREELY FOR A LONG TIME.
CHECK	: Check if the wheels have been turned freely for more than one minute, such as when the vehicle is jacked-up, under full-lock cornering or when tire is not in contact with road surface.
YES	: The ABS is normal. Erase the trouble code.
NOTE:	
When the wheels turn freely for a long time, such as when the vehicle is towed or jacked-up, or when steering wheel is continuously turned all the way, this trouble code may sometimes occur.	
NO	: Go to step 10M2 .

10M2	CHECK TIRE.
-------------	--------------------

- CHECK** : *Are the tire specifications correct?*
- YES** : Go to next **CHECK** .
- NO** : Replace tire.
- CHECK** : *Is the tire worn excessively?*
- YES** : Replace tire.
- NO** : Go to next **CHECK** .
- CHECK** : *Is the tire pressure correct?*
- YES** : Go to step **10M3**.
- NO** : Adjust tire pressure.

10M3	CHECK ABS SENSOR MECHANICAL TROUBLE.
-------------	---


- CHECK** : *Tightening torque:*
 $32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft}\cdot\text{lb}$)
Are the ABS sensor installation bolts tightened securely?
- YES** : Go to next **CHECK** .
- NO** : Tighten ABS sensor installation bolts securely.
- CHECK** : *Tightening torque:*
 $13 \pm 3 \text{ N}\cdot\text{m}$ ($1.3 \pm 0.3 \text{ kg}\cdot\text{m}$, $9 \pm 2.2 \text{ ft}\cdot\text{lb}$)
Are the ABS sensor installation bolts tightened securely?
- YES** : Go to next step.
- NO** : Tighten ABS sensor installation bolts securely.



1) Measure tone wheel to pole piece gap over entire perimeter of the wheel.

- CHECK** : *Is the gap within the specifications shown in the following table?*

	Front wheel	Rear wheel
Specifications	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



YES : Go to next **CHECK** .

NO : Adjust the gap.

NOTE:

Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

CHECK : *Is an oscilloscope available?*

YES : Go to next step.

NO : Go to step 10).

2) Raise all four wheels of ground.

3) Turn ignition switch OFF.

4) Disconnect connector from ABS control module.


5) Disconnect connector cover from connector.

<Ref. to 4-4c [T8C1] steps 5) to 8).>

6) Connect connector to ABS control module.

7) Connect the oscilloscope to the ABS control module connector.

8) Turn ignition switch ON.



9) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

TROUBLE CODE / Connector & terminal:

(F49) No. 14 (+) — No. 15 (-) (Front RH)

(F49) No. 49 (+) — No. 19 (-) (Front LH)

(F49) No. 18 (+) — No. 46 (-) (Rear RH)

(F49) No. 16 (+) — No. 17 (-) (Rear LH)

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : *Is oscilloscope pattern smooth, as shown in figure?*

YES : Go to step 10M4.

NO : Go to next step.

10) Remove disc rotor from hub.

CHECK : *Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?*

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to next **CHECK** .

CHECK : *Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?*

YES : Replace ABS sensor or tone wheel.

NO : Go to next step.

11) Measure hub runout.

CHECK : *Is the runout less than 0.05 mm (0.0020 in)?*

YES : Go to step 10M4.

NO : Repair hub.

10M4	CHECK ABSCM.
-------------	---------------------

1) Turn ignition switch to OFF.

2) Connect all connectors.

3) Erase the memory.

4) Perform inspection mode.

5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 31 (FB1)
FR. EV VALVE

B4M0953

N: 31 FR. EV VALVE
— ABNORMAL FRONT RH INLET SOLENOID VALVE —

D•NEW 33 (FB1)
FL. EV VALVE

B4M0954

O: 33 FL. EV VALVE
— ABNORMAL FRONT LH INLET SOLENOID VALVE —

D•NEW 35 (FB1)
RR. EV VALVE

B4M0955

P: 35 RR. EV VALVE
— ABNORMAL REAR RH INLET SOLENOID VALVE —

D•NEW 37 (FB1)
RL. EV VALVE

B4M0956


Q: 37 RL. EV VALVE
— ABNORMAL REAR LH INLET SOLENOID VALVE —

DIAGNOSIS:


- Faulty harness/connector
- Faulty inlet solenoid valve in hydraulic unit

TROUBLE SYMPTOM:


- ABS does not operate.




From the former page.



WIRING DIAGRAM:



B4M1046



B4M0957A

10Q1 CHECK FREEZE FRAME DATA.

Press **F**, **E**, **1** and **5** on the select monitor.

CHECK : Is the select monitor LED 5 off? Was the ABS inactive when the problem occurred?

YES : Go to step 10Q2.

NO : Go to step 10Q11.

10Q2

CHECK THE CONDITION WHEN THE TROUBLE OCCURRED.

Ask the vehicle owner about driving conditions when the trouble occurred. Attempt to duplicate the conditions.

CHECK : *Is the trouble immediately apparent?*


YES : Go to next **CHECK** .

NO : Go to step 11.

CHECK : *Did the trouble occur immediately after engine starting or during standing starts?*

YES : Go to step 10Q9.

NO : Go to step 10Q3.



10Q3


CHECK RESISTANCE OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

CHECK : *Trouble code/Connector & terminal*
31/to (F9) No. 4 — to (ABS1) No. 2
33/to (F9) No. 1 — to (ABS1) No. 2
35/to (F9) No. 2 — to (ABS1) No. 2
37/to (F9) No. 3 — to (ABS1) No. 2
Is resistance $8.5 \pm 0.7 \Omega$?

YES : Go to step 10Q4.

NO : Replace hydraulic unit.



10Q4


CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/to (F9) No. 4 — Chassis ground
33/to (F9) No. 1 — Chassis ground
35/to (F9) No. 2 — Chassis ground
37/to (F9) No. 3 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10Q5.

NO : Replace hydraulic unit.



10Q5


CHECK GROUND SHORT OF HARNESS.

- 1) Disconnect connector from ABSCM.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/(F49) No. 30 — Chassis ground
33/(F49) No. 24 — Chassis ground
35/(F49) No. 23 — Chassis ground
37/(F49) No. 31 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10Q6.

NO : Repair harness between ABSCM and hydraulic unit.

**10Q6****CHECK HARNESS CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

CHECK : *Trouble code/Connector & terminal*
31/(F49) No. 30 — No. 1
33/(F49) No. 24 — No. 1
35/(F49) No. 23 — No. 1
37/(F49) No. 31 — No. 1
Is resistance $9.0 \pm 0.7 \Omega$?

YES : Go to step **10Q7**.

NO : Repair harness connector between ABSCM and hydraulic unit.

10Q7**CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit?*

YES : Repair connector.

NO : Go to step **10Q8**.

10Q8**CHECK ABSCM.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.



10Q9

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Disconnect connector from ABSCM.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/to (F9) No. 4 (+) — Chassis ground (-)
33/to (F9) No. 1 (+) — Chassis ground (-)
35/to (F9) No. 2 (+) — Chassis ground (-)
37/to (F9) No. 3 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Replace hydraulic unit.

- 6) Turn ignition switch to OFF.
- 7) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/to (F9) No. 4 (+) — Chassis ground (-)
33/to (F9) No. 1 (+) — Chassis ground (-)
35/to (F9) No. 2 (+) — Chassis ground (-)
37/to (F9) No. 3 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10Q10.

NO : Replace hydraulic unit.



10Q10

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/(F49) No. 30 (+) — Chassis ground (-)
33/(F49) No. 24 (+) — Chassis ground (-)
35/(F49) No. 23 (+) — Chassis ground (-)
37/(F49) No. 31 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between ABSCM and hydraulic unit.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 31/(F49) No. 30 (+) — Chassis ground (-)
 33/(F49) No. 24 (+) — Chassis ground (-)
 35/(F49) No. 23 (+) — Chassis ground (-)
 37/(F49) No. 31 (+) — Chassis ground (-)
 Is voltage 0 V?

YES : Replace ABSCM.

NO : Repair harness between ABSCM and hydraulic unit.




10Q11 CHECK RESISTANCE OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

CHECK : *Trouble code/Connector & terminal*
 31/to (F9) No. 4 — to (ABS1) No. 2
 33/to (F9) No. 1 — to (ABS1) No. 2
 35/to (F9) No. 2 — to (ABS1) No. 2
 37/to (F9) No. 3 — to (ABS1) No. 2
 Is resistance $8.5 \pm 0.7 \Omega$?

YES : Go to step 10Q12.

NO : Replace hydraulic unit.




10Q12 CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
 31/to (F9) No. 4 — Chassis ground
 33/to (F9) No. 1 — Chassis ground
 35/to (F9) No. 2 — Chassis ground
 37/to (F9) No. 3 — Chassis ground
 Is resistance more than 1 MΩ?

YES : Go to step 10Q13.

NO : Replace hydraulic unit.



10Q13 CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector from ABSCM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/to (F9) No. 4 (+) — Chassis ground (-)
33/to (F9) No. 1 (+) — Chassis ground (-)
35/to (F9) No. 2 (+) — Chassis ground (-)
37/to (F9) No. 3 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Replace hydraulic unit.

- 4) Turn ignition switch to OFF.
- 5) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/to (F9) No. 4 (+) — Chassis ground (-)
33/to (F9) No. 1 (+) — Chassis ground (-)
35/to (F9) No. 2 (+) — Chassis ground (-)
37/to (F9) No. 3 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10Q14.

NO : Replace hydraulic unit.



10Q14 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
31/(F49) No. 30 (+) — Chassis ground (-)
33/(F49) No. 24 (+) — Chassis ground (-)
35/(F49) No. 23 (+) — Chassis ground (-)
37/(F49) No. 31 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between ABSCM and hydraulic unit.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Trouble code/Connector & terminal**
 31/(F49) No. 30 (+) — Chassis ground (-)
 33/(F49) No. 24 (+) — Chassis ground (-)
 35/(F49) No. 23 (+) — Chassis ground (-)
 37/(F49) No. 31 (+) — Chassis ground (-)
 Is voltage 0 V?

YES : Go to step 10Q15.

NO : Repair harness between ABSCM and hydraulic unit.




10Q15 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

CHECK : **Trouble code/Connector & terminal**
 31/(F49) No. 30 — Chassis ground
 33/(F49) No. 24 — Chassis ground
 35/(F49) No. 23 — Chassis ground
 37/(F49) No. 31 — Chassis ground
 Is resistance more than 1 MΩ?

YES : Go to step 10Q16.

NO : Repair harness between ABSCM and hydraulic unit.



10Q16 CHECK HARNESS CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

1) Connect connector to hydraulic unit.
 2) Measure resistance between ABSCM connector terminals.

CHECK : **Trouble code/Connector & terminal**
 31/(F49) No. 30 — No. 1
 33/(F49) No. 24 — No. 1
 35/(F49) No. 23 — No. 1
 37/(F49) No. 31 — No. 1
 Is resistance $9.0 \pm 0.7 \Omega$?

YES : Go to step 10Q17.

NO : Repair harness connector between ABSCM and hydraulic unit.

10Q17	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.
--------------	--

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit?*

YES : Repair connector.

NO : Go to step **10Q18**.

10Q18	CHECK ABSCM.
--------------	---------------------

1) Connect all connectors.

2) Erase the memory.

3) Perform inspection mode.

4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 32 (FB1)
FR. AV VALVE

B4M0958

R: 32 FR. AV VALVE
— ABNORMAL FRONT RH OUTLET
SOLENOID VALVE —

D•NEW 34 (FB1)
FL. AV VALVE

B4M0959

S: 34 FL. AV VALVE
— ABNORMAL FRONT LH OUTLET
SOLENOID VALVE —

D•NEW 36 (FB1)
RR. AV VALVE

B4M0960

T: 36 RR. AV VALVE
— ABNORMAL REAR RH OUTLET SOLENOID
VALVE —

D•NEW 38 (FB1)
RL. AV VALVE

B4M0961


U: 38 RL. AV VALVE
— ABNORMAL REAR LH OUTLET SOLENOID
VALVE —

DIAGNOSIS:


- Faulty harness/connector
- Faulty outlet solenoid valve in hydraulic unit

TROUBLE SYMPTOM:


- ABS does not operate.




From the former page.



WIRING DIAGRAM:



B4M1046



10U1	CHECK FREEZE FRAME DATA.
Press F , E , 1 and 5 on the select monitor.	
CHECK	: Is the select monitor LED 5 off? Was the ABS inactive when the problem occurred?
YES	: Go to step 10U2.
NO	: Go to step 10U11.

10U2

CHECK THE CONDITION WHEN THE TROUBLE OCCURRED.

Ask the vehicle owner about driving conditions when the trouble occurred. Attempt to duplicate the conditions.

CHECK : *Is the trouble immediately apparent?*


YES : Go to next **CHECK** .

NO : Go to step 10U11.

CHECK : *Did the trouble occur immediately after engine starting or during standing starts?*

YES : Go to step 10U9.

NO : Go to step 10U3.



10U3


CHECK RESISTANCE OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

CHECK : *Trouble code/Connector & terminal*
32/to (F9) No. 8 — to (ABS1) No. 2
34/to (F9) No. 5 — to (ABS1) No. 2
36/to (F9) No. 6 — to (ABS1) No. 2
38/to (F9) No. 7 — to (ABS1) No. 2
Is resistance $4.3 \pm 0.5 \Omega$?

YES : Go to step 10U4.

NO : Replace hydraulic unit.



10U4


CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/to (F9) No. 8 — Chassis ground
34/to (F9) No. 5 — Chassis ground
36/to (F9) No. 6 — Chassis ground
38/to (F9) No. 7 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10U5.

NO : Replace hydraulic unit.



10U5


CHECK GROUND SHORT OF HARNESS.

- 1) Disconnect connector from ABSCM.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/(F49) No. 3 — Chassis ground
34/(F49) No. 51 — Chassis ground
36/(F49) No. 50 — Chassis ground
38/(F49) No. 4 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10U6.

NO : Repair harness between ABSCM and hydraulic unit.

**10U6****CHECK HARNESS CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

CHECK : **Trouble code/Connector & terminal**
32/(F49) No. 3 — No. 1
34/(F49) No. 51 — No. 1
36/(F49) No. 50 — No. 1
38/(F49) No. 4 — No. 1
Is resistance $4.8 \pm 0.5 \Omega$?

YES : Go to step **10U7**.

NO : Repair harness connector between ABSCM and hydraulic unit.

10U7**CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

CHECK : **Is there poor contact in connectors between ABSCM and hydraulic unit?**

YES : Repair connector.

NO : Go to step **10U8**.

10U8**CHECK ABSCM.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.



10U9 CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Disconnect connector from ABSCM.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/to (F9) No. 8 (+) — Chassis ground (-)
34/to (F9) No. 5 (+) — Chassis ground (-)
36/to (F9) No. 6 (+) — Chassis ground (-)
38/to (F9) No. 7 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Replace hydraulic unit.

- 6) Turn ignition switch to OFF.
- 7) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/to (F9) No. 8 (+) — Chassis ground (-)
34/to (F9) No. 5 (+) — Chassis ground (-)
36/to (F9) No. 6 (+) — Chassis ground (-)
38/to (F9) No. 7 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10U10.

NO : Replace hydraulic unit.



10U10 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/(F49) No. 3 (+) — Chassis ground (-)
34/(F49) No. 51 (+) — Chassis ground (-)
36/(F49) No. 50 (+) — Chassis ground (-)
38/(F49) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between ABSCM and hydraulic unit.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Trouble code/Connector & terminal**
 32/(F49) No. 3 (+) — Chassis ground (-)
 34/(F49) No. 51 (+) — Chassis ground (-)
 36/(F49) No. 50 (+) — Chassis ground (-)
 38/(F49) No. 4 (+) — Chassis ground (-)
 Is voltage 0 V?

YES : Replace ABSCM.

NO : Repair harness between ABSCM and hydraulic unit.




10U11 CHECK RESISTANCE OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

CHECK : **Trouble code/Connector & terminal**
 32/to (F9) No. 8 — to (ABS1) No. 2
 34/to (F9) No. 5 — to (ABS1) No. 2
 36/to (F9) No. 6 — to (ABS1) No. 2
 38/to (F9) No. 7 — to (ABS1) No. 2
 Is resistance $4.3 \pm 0.5 \Omega$?

YES : Go to step 10U12.

NO : Replace hydraulic unit.




10U12 CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.

CHECK : **Trouble code/Connector & terminal**
 32/to (F9) No. 8 — Chassis ground
 34/to (F9) No. 5 — Chassis ground
 36/to (F9) No. 6 — Chassis ground
 38/to (F9) No. 7 — Chassis ground
 Is resistance more than 1 MΩ?

YES : Go to step 10U13.

NO : Replace hydraulic unit.



10U13

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector from ABSCM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/to (F9) No. 8 (+) — Chassis ground (-)
34/to (F9) No. 5 (+) — Chassis ground (-)
36/to (F9) No. 6 (+) — Chassis ground (-)
38/to (F9) No. 7 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Replace hydraulic unit.

- 4) Turn ignition switch to OFF.
- 5) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/to (F9) No. 8 (+) — Chassis ground (-)
34/to (F9) No. 5 (+) — Chassis ground (-)
36/to (F9) No. 6 (+) — Chassis ground (-)
38/to (F9) No. 7 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step **10U14**.

NO : Replace hydraulic unit.



10U14

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Trouble code/Connector & terminal*
32/(F49) No. 3 (+) — Chassis ground (-)
34/(F49) No. 51 (+) — Chassis ground (-)
36/(F49) No. 50 (+) — Chassis ground (-)
38/(F49) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between ABSCM and hydraulic unit.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Trouble code/Connector & terminal**
32/(F49) No. 3 (+) — Chassis ground (-)
34/(F49) No. 51 (+) — Chassis ground (-)
36/(F49) No. 50 (+) — Chassis ground (-)
38/(F49) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10U15.

NO : Repair harness between ABSCM and hydraulic unit.




10U15 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

CHECK : **Trouble code/Connector & terminal**
32/(F49) No. 3 — Chassis ground
34/(F49) No. 51 — Chassis ground
36/(F49) No. 50 — Chassis ground
38/(F49) No. 4 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10U16.

NO : Repair harness between ABSCM and hydraulic unit.



10U16 CHECK HARNESS CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

1) Connect connector to hydraulic unit.
 2) Measure resistance between ABSCM connector terminals.

CHECK : **Trouble code/Connector & terminal**
32/(F49) No. 3 — No. 1
34/(F49) No. 51 — No. 1
36/(F49) No. 50 — No. 1
38/(F49) No. 4 — No. 1
Is resistance 4.8±0.5 Ω?

YES : Go to step 10U17.

NO : Repair harness connector between ABSCM and hydraulic unit.

10U17	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.
-------	---

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit?*

YES : Repair connector.

NO : Go to step 10U18.

10U18	CHECK ABSCM.
-------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 41 (FB1)
ECU


B4M0962

V: 41 ECU
— ABNORMAL ABS CONTROL MODULE —
DIAGNOSIS:


- Faulty ABSCM


TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:



**10V1 CHECK GROUND CIRCUIT OF ABSCm.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCm.
- 3) Measure resistance between ABSCm and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 1 — Chassis ground
(F49) No. 55 — Chassis ground
Is resistance less than 0.5 Ω?

YES : Go to step **10V2**.

NO : Repair ABSCm ground harness.

10V2 CHECK POOR CONTACT IN CONNECTORS BETWEEN BATTERY, IGNITION SWITCH AND ABSCm.

CHECK : **Is there poor contact in connectors between battery, ignition switch and ABSCm?**

YES : Repair connector.

NO : Go to step **10V3**.

10V3 CHECK SOURCES OF SIGNAL NOISE.

CHECK : **Is the car telephone or the wireless transmitter properly installed?**

YES : Go to next **CHECK** .

NO : Properly install the car telephone or the wireless transmitter.

CHECK : **Are noise sources (such as an antenna) installed near the sensor harness?**

YES : Install the noise sources apart from the sensor harness.

NO : Go to step **10V4**.

10V4	CHECK ABSCM.
------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.




W: 42 LOW VOLTAGE
— SOURCE VOLTAGE IS LOW. —

DIAGNOSIS:


- Power source voltage of the ABSCM is low.

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1039



B4M0430

10W1 CHECK GENERATOR.

- 1) Start engine.
- 2) Idling after warm-up.
- 3) Measure voltage between generator B terminal and chassis ground.

CHECK : *Terminal Generator B terminal — Chassis ground*
Is voltage 10 — 15 V?

YES : Go to step 10W2.

NO : Repair generator.


10W2 CHECK BATTERY TERMINAL.

Turn ignition switch to OFF.

CHECK : *Are the positive and negative battery terminals tightly clamped?*

YES : Go to step 10W3.

NO : Tighten the clamp of terminal.



B4M0842A


10W3 CHECK INPUT VOLTAGE OF ABSCM.

- 1) Disconnect connector from ABSCM.
- 2) Run the engine at idle.
- 3) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 28 (+) — Chassis ground (-)*
Is voltage 10 — 15 V?

YES : Go to step 10W4.

NO : Repair harness connector between battery, ignition switch and ABSCM.

**10W4 CHECK GROUND CIRCUIT OF ABSCM.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 1 — Chassis ground**
Is resistance less than 0.5 Ω?

YES : Go to step **10W5**.

NO : Repair ABSCM ground harness.

10W5 CHECK POOR CONTACT IN CONNECTOR BETWEEN GENERATOR, BATTERY AND ABSCM.

CHECK : **Is there poor contact in connectors between generator, battery and ABSCM?**

YES : Repair connector.

NO : Go to step **10W6**.

10W6 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 44 (FB1) CCM LINE

B4M0964


X: 44 CCM LINE — A COMBINATION OF AT CONTROL ABNORMALS —

DIAGNOSIS:


- Combination of AT control faults

TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:




B4M1040

1996 (F00)
 ABS 4WD•AT

B4M0921

10X1 CHECK SPECIFICATIONS OF ABSCM USING SELECT MONITOR.

- 1) Press **F**, **0** and **0** on the select monitor.
 - 2) Read the select monitor display.
- CHECK** : Is an ABSCM for AT model installed on a MT model?
- YES** : Replace ABSCM.
- NO** : Go to step 10X2.




10X2 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors from AT control module.
- 3) Disconnect connector from ABSCM.
- 4) Measure resistance between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 12 — Chassis ground*
Is resistance more than 1 MΩ?

YES : Go to step 10X3.

NO : Repair harness between AT control module and ABSCM.




10X3 CHECK AT CONTROL MODULE.

- 1) Connect all connectors to AT control module.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between AT control module connector terminals.

CHECK : *Connector & terminal (B55) No. 1 (+) — (B56) No. 5 (-)*
Is voltage 10 — 13 V?

YES : Go to step 10X4.

NO : Go to next step.




- 4) Measure voltage between AT control module connector and chassis ground.

CHECK : *Connector & terminal (B54) No. 6 (+) — Chassis ground (-)*
(B55) No. 1 (+) — Chassis ground (-)
Is voltage 10 — 13 V?

YES : Replace AT control module.

NO : Repair harness connector between battery, ignition switch and AT control module.



10X4 CHECK OPEN CIRCUIT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 12 (+) — Chassis ground (-)**
(F49) No. 39 (+) — Chassis ground (-)
Is voltage 10 — 13 V?

YES : Go to step **10X5**.

NO : Repair harness connector between AT control module and ABSCM.

10X5 CHECK POOR CONTACT IN CONNECTOR BETWEEN AT CONTROL MODULE AND ABSCM.

CHECK : **Is there poor contact in connectors between AT control module and ABSCM?**

YES : Repair connector.

NO : Go to step **10X6**.

10X6 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 44 (FB1)
CCM OPEN

B4M0965


Y: 44 CCM OPEN
— A COMBINATION OF AT CONTROL
ABNORMALS —

DIAGNOSIS:


- Combination of AT control faults

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1040

**10Y1 CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors from AT control module.
- 3) Disconnect connector from ABSCM.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 12 (+) — Chassis ground (-)**
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between AT control module and ABSCM.

- 6) Turn ignition switch to OFF.
- 7) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 12 (+) — Chassis ground (-)**
Is voltage 0 V?

YES : Go to step 10Y2.

NO : Repair harness between AT control module and ABSCM.

**10Y2 CHECK OPEN CIRCUIT OF HARNESS.**

- 1) Connect all connectors to AT control module.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 12 (+) — Chassis ground (-)**
(F49) No. 39 (+) — Chassis ground (-)
Is voltage 10 — 13 V?

YES : Go to step 10Y3.

NO : Repair harness connector between AT control module and ABSCM.

10Y3	CHECK POOR CONTACT IN CONNECTOR BETWEEN AT CONTROL MODULE AND ABSCM.
-------------	---

CHECK : *Is there poor contact in connectors between AT control module and ABSCM?*

YES : Repair connector.

NO : Go to step **10Y4**.

10Y4	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 46 (FB1)
GS POWER OVER

B4M0966

Z: 46 GS POWER OVER
— G SENSOR LINE VOLTAGE TOO HIGH —

DIAGNOSIS:


- Faulty G sensor power supply voltage


TROUBLE SYMPTOM:

- ABS does not operate.

10Z1. Check battery short of harness.

WIRING DIAGRAM:



**10Z1 CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Remove console cover from console box.
- 3) Disconnect connector from G sensor.
- 4) Disconnect connector from ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 8 (+) — Chassis ground (-)
(F49) No. 45 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between ABSCM and G sensor.

- 7) Turn ignition switch to OFF.
- 8) Measure voltage between ABSCM and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 8 (+) — Chassis ground (-)
(F49) No. 45 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Replace ABSCM.

NO : Repair harness between ABSCM and chassis ground.




AA: 46 GS POWER LOW
— G SENSOR LINE VOLTAGE TOO LOW —
DIAGNOSIS:


- Faulty G sensor power supply voltage

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1047



B4M0851B


10AA1 CHECK G SENSOR.

- 1) Turn ignition switch to OFF.
- 2) Remove console cover from console box.
- 3) Disconnect connector from G sensor.
- 4) Measure resistance of G sensor.

CHECK : **Connector & terminal**
To (P11) No. 1 — No. 3
Is resistance 50±8 kΩ?

YES : Go to step 10AA2.


NO : Replace G sensor.



10AA2 CHECK GROUND SHORT OF G SENSOR.

Measure resistance between G sensor and bracket.


- CHECK** : *Connector & terminal To (P11) No. 3 — Bracket Is resistance more than 1 MΩ?*
- YES** : Go to step 10AA3.
- NO** : Replace G sensor.



10AA3 CHECK SHORT OF HARNESS BETWEEN ABSCM AND G SENSOR.

- 1) Disconnect connector from ABSCM.
- 2) Measure resistance between ABSCM connector terminals.

- CHECK** : *Connector & terminal (F49) No. 45 — No. 8 Is resistance more than 1 MΩ?*
- YES** : Go to step 10AA4.
- NO** : Repair harness between ABSCM and G sensor.



10AA4 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

- CHECK** : *Connector & terminal (F49) No. 8 — Chassis ground (F49) No. 45 — Chassis ground Is resistance more than 1 MΩ?*
- YES** : Go to step 10AA5.
- NO** : Repair harness between ABSCM and G sensor.

10AA5 CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND G SENSOR.

- CHECK** : *Is there poor contact in connectors between ABSCM and G sensor?*
- YES** : Repair connector.
- NO** : Go to step 10AA6.

10AA6	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 51 (FB1)
V. RELAY

B4M0968


AB: 51 V. RELAY
— ABNORMAL VALVE RELAY —


DIAGNOSIS:

- Faulty valve relay



TROUBLE SYMPTOM:

- ABS does not operate.





WIRING DIAGRAM:




10AB1 CHECK FREEZE FRAME DATA.

Press **F**, **E**, **1** and **5** on the select monitor.

CHECK : *Is the select monitor LED 5 off? Was the ABS inactive when the problem occurred?*

YES : Go to step 10AB2.

NO : Go to step 10AB24.




10AB2 CHECK RESISTANCE OF VALVE RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove valve relay from relay box.
- 3) Measure resistance between valve relay terminals.

CHECK : **Terminals**
No. 85 — No. 86
Is resistance $103 \pm 10 \Omega$?

- YES** : Go to step **10AB3**.
NO : Replace valve relay.



10AB3 CHECK CONTACT POINT OF VALVE RELAY.


- 1) Connect battery to valve relay terminals No. 85 and No. 86.
- 2) Measure resistance between valve relay terminals.

CHECK : **Terminals**
No. 30 — No. 87
Is resistance less than 0.5Ω ?

- YES** : Go to next **CHECK** .
NO : Replace valve relay.

CHECK : **Terminals**
No. 30 — No. 87a
Is resistance more than $1 M\Omega$?

- YES** : Go to next step.
NO : Replace valve relay.




- 3) Disconnect battery from valve relay terminals.
- 4) Measure resistance between valve relay terminals.

CHECK : **Terminals**
No. 30 — No. 87
Is resistance more than $1 M\Omega$?

- YES** : Go to next **CHECK** .
NO : Replace valve relay.

CHECK : **Terminals**
No. 30 — No. 87a
Is resistance less than 0.5Ω ?

- YES** : Go to step **10AB4**.
NO : Replace valve relay.


**10AB4 CHECK SHORT OF VALVE RELAY.**

Measure resistance between valve relay terminals.

CHECK : **Terminals**
No. 86 — No. 87
No. 86 — No. 87a
Is resistance more than 1 MΩ?

YES : Go to step 10AB5.

NO : Replace valve relay.


**10AB5 CHECK POWER SUPPLY VOLTAGE AT VALVE RELAY CONTACT POINT.**

- 1) Disconnect connector (F8) from relay box.
- 2) Measure voltage between relay box connector and chassis ground.

CHECK : **Connector & terminal**
(F8) No. 1 (+) — Chassis ground (-)
Is voltage 10 — 13 V?

YES : Go to step 10AB6.

NO : Repair harness connector between battery and relay box. Check fuse No. 19.


**10AB6 CHECK BROKEN WIRE AND GROUND SHORT IN POWER SUPPLY CIRCUIT OF RELAY BOX.**

- 1) Disconnect connector (ABS1) from hydraulic unit.
- 2) Connect connector (F8) to relay box.
- 3) Disconnect connector (F50) from relay box.
- 4) Measure voltage of relay box.

CHECK : **Connector & terminal**
Valve relay installing point No. 87 — Chassis ground
Is voltage 10 — 13 V?

YES : Go to step 10AB7.

NO : Replace relay box. Check fuse No. 19.



10AB7 CHECK BROKEN WIRE IN CONTACT POINT CIRCUIT OF RELAY BOX.

Measure resistance between hydraulic unit connector and valve relay installing point.

CHECK : **Connector & terminal (ABS1) No. 2 — Valve relay installing point No. 30**
Is resistance less than 0.5 Ω?

YES : Go to step 10AB8.

NO : Replace relay box.



10AB8 CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

Measure resistance between relay box connector and chassis ground.

CHECK : **Connector & terminal (ABS1) No. 2 — Chassis ground**
Is resistance more than 1 MΩ?

YES : Go to step 10AB9.

NO : Replace relay box. Check fuse SBF6.



10AB9 CHECK DIODE OF RELAY BOX.

Measure resistance between relay box connector and valve relay installing point.

CHECK : **Connector & terminal Valve relay installing point No. 30 (+) — To (F50) No. 2 (-)**
Is resistance more than 1 MΩ?

YES : Go to step 10AB10.

NO : Replace relay box.


10AB10 CHECK BATTERY SHORT IN GROUND CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between relay box connector and chassis ground.

CHECK : **Connector & terminal**
To (F50) No. 3 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.

NO : Replace relay box and check all fuses.


- 4) Turn ignition switch to OFF.

- 5) Measure voltage between relay box connector and chassis ground.

CHECK : **Connector & terminal**
To (F50) No. 3 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10AB11.

NO : Replace relay box and check all fuses.



10AB11 CHECK BROKEN WIRE IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Install valve relay to relay box.
- 2) Measure resistance between relay box connector terminals.

CHECK : **Connector & terminal**
To (F50) No. 1 — No. 5
Is resistance $103 \pm 10 \Omega$?

YES : Go to step 10AB12.

NO : Replace relay box.




10AB12 CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.

Measure resistance between relay box connector and chassis ground.

CHECK : *Connector & terminal To (F50) No. 1 — Chassis ground Is resistance more than 1 MΩ?*

YES : Go to step 10AB13.

NO : Replace relay box and check all fuses.



10AB13 CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between relay box connector and chassis ground.

CHECK : *Connector & terminal To (F50) No. 1 (+) — Chassis ground (-) Is voltage 0 V?*

YES : Go to next step.


NO : Replace relay box. Check fuse No. 19 and SBF6.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between relay box connector and chassis ground.

CHECK : *Connector & terminal To (F50) No. 1 (+) — Chassis ground (-) Is voltage 0 V?*

YES : Go to step 10AB14.

NO : Replace relay box. Check fuse No. 19 and SBF6.




10AB14 CHECK BROKEN WIRE IN CONTROL SYSTEM HARNESS OF VALVE RELAY.

- 1) Connect connector (F50) to relay box.
- 2) Measure resistance between ABSCM connector terminals.

CHECK : *Connector & terminal (F49) No. 27 — No. 47 Is resistance 103±10 Ω?*

YES : Go to step 10AB15.

NO : Repair harness between ABSCM and relay box. Check fuse No. 18.




10AB15 CHECK GROUND SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 27 — Chassis ground*
Is resistance more than 1 MΩ?

YES : Go to step **10AB16**.

NO : Repair harness between ABSCM and relay box. Check fuse No. 18.



10AB16 CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.

- 1) Connect connector (F50) to relay box.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 27 (+) — Chassis ground (-)*
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between ABSCM and relay box and check all fuses.

- 4) Turn ignition switch to OFF.
- 5) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 27 (+) — Chassis ground (-)*
Is voltage 0 V?

YES : Go to step **10AB17**.

NO : Repair harness between ABSCM and relay box and check all fuses.




10AB17 CHECK RESISTANCE OF INLET SOLENOID VALVE.

- 1) Disconnect connector from hydraulic unit.
- 2) Measure resistance between hydraulic unit connector terminals.

CHECK : *Connector & terminal*
 To (F9) No. 4 — to (ABS1) No. 2
 To (F9) No. 1 — to (ABS1) No. 2
 To (F9) No. 2 — to (ABS1) No. 2
 To (F9) No. 3 — to (ABS1) No. 2
 Is resistance $8.5 \pm 0.7 \Omega$?

- YES** : Go to step 10AB18.
NO : Replace hydraulic unit.




10AB18 CHECK RESISTANCE OF OUTLET SOLENOID VALVE.

Measure resistance between hydraulic unit connector terminals.

CHECK : *Connector & terminal*
 To (F9) No. 8 — to (ABS1) No. 2
 To (F9) No. 5 — to (ABS1) No. 2
 To (F9) No. 6 — to (ABS1) No. 2
 To (F9) No. 7 — to (ABS1) No. 2
 Is resistance $4.3 \pm 0.5 \Omega$?

- YES** : Go to step 10AB19.
NO : Replace hydraulic unit.




10AB19 CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.

CHECK : *Connector & terminal*
 To (F9) No. 4 — Chassis ground
 Is resistance more than $1 M\Omega$?

- YES** : Go to step 10AB20.
NO : Replace hydraulic unit and check all fuses.




10AB20 CHECK GROUND SHORT OF HARNESS.

- 1) Disconnect connector from hydraulic unit.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
 (F49) No. 30 — Chassis ground
 (F49) No. 24 — Chassis ground
 (F49) No. 23 — Chassis ground
 (F49) No. 31 — Chassis ground
 (F49) No. 3 — Chassis ground
 (F49) No. 51 — Chassis ground
 (F49) No. 50 — Chassis ground
 (F49) No. 4 — Chassis ground
 Is resistance more than 1 MΩ?

- YES** : Go to step 10AB21.
NO : Repair harness between hydraulic unit and ABSCM.




10AB21 CHECK HARNESS CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

CHECK : **Connector & terminal**
 (F49) No. 30 — No. 1
 (F49) No. 24 — No. 1
 (F49) No. 23 — No. 1
 (F49) No. 31 — No. 1
 Is resistance 9.0±0.7 Ω?

- YES** : Go to next **CHECK** .
NO : Repair harness connector between hydraulic unit and ABSCM.



CHECK : **Connector & terminal**
 (F49) No. 3 — No. 1
 (F49) No. 51 — No. 1
 (F49) No. 50 — No. 1
 (F49) No. 4 — No. 1
 Is resistance 4.8±0.5 Ω?

- YES** : Go to step 10AB22.
NO : Repair harness connector between hydraulic unit and ABSCM.

10AB22	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.
---------------	--

CHECK : *Is there poor contact in connector between ABSCM and hydraulic unit?*

YES : Repair connector.

NO : Go to step **10AB23**.

10AB23	CHECK ABSCM.
---------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.



10AB24	CHECK BATTERY SHORT OF SOLENOID VALVE.
---------------	---

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors (ABS1, F9) from hydraulic unit.
- 3) Disconnect connector from ABSCM.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : *Connector & terminal To (F9) No. 4 (+) — Chassis ground (-) Is voltage 0 V?*

YES : Go to next step.


NO : Replace hydraulic unit and check all fuses.

- 6) Turn ignition switch to OFF.
- 7) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : **Connector & terminal**
To (F63) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step **10AB25**.

NO : Replace hydraulic unit and check all fuses.



10AB25 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 30 (+) — Chassis ground (-)
(F49) No. 24 (+) — Chassis ground (-)
(F49) No. 23 (+) — Chassis ground (-)
(F49) No. 31 (+) — Chassis ground (-)
(F49) No. 3 (+) — Chassis ground (-)
(F49) No. 51 (+) — Chassis ground (-)
(F49) No. 50 (+) — Chassis ground (-)
(F49) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.

NO : Repair harness between hydraulic unit and ABSCM and check all fuses.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 30 (+) — Chassis ground (-)
(F49) No. 24 (+) — Chassis ground (-)
(F49) No. 23 (+) — Chassis ground (-)
(F49) No. 31 (+) — Chassis ground (-)
(F49) No. 3 (+) — Chassis ground (-)
(F49) No. 51 (+) — Chassis ground (-)
(F49) No. 50 (+) — Chassis ground (-)
(F49) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step **10AB26**.

NO : Repair harness between hydraulic unit and ABSCM and check all fuses.

10AB26	CHECK ABSCM.
---------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.




**AC: 51 V. RELAY ON
— VALVE RELAY ON FAILURE —**

DIAGNOSIS:


- Faulty valve relay

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1048



B4M0858A


10AC1 CHECK RESISTANCE OF VALVE RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove valve relay from relay box.
- 3) Measure resistance between valve relay terminals.

CHECK : **Terminals**
No. 85 — No. 86
Is resistance 103±10 Ω?

YES : Go to step **10AC2**.

NO : Replace valve relay.



10AC2 CHECK CONTACT POINT OF VALVE RELAY.

- 1) Connect battery to valve relay terminals No. 85 and No. 86.
- 2) Measure resistance between valve relay terminals.

CHECK : *Terminals No. 30 — No. 87*
Is resistance less than 0.5 Ω?


YES : Go to next **CHECK** .

NO : Replace valve relay.

CHECK : *Terminals No. 30 — No. 87a*
Is resistance more than 1 MΩ?

YES : Go to next step.

NO : Replace valve relay.



- 3) Disconnect battery from valve relay terminals.
- 4) Measure resistance between valve relay terminals.

CHECK : *Terminals No. 30 — No. 87*
Is resistance more than 1 MΩ?


YES : Go to next **CHECK** .

NO : Replace valve relay.

CHECK : *Terminals No. 30 — No. 87a*
Is resistance less than 0.5 Ω?

YES : Go to step 10AC3.

NO : Replace valve relay.



10AC3 CHECK GROUND CIRCUIT OF RELAY BOX.

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between relay box connector and chassis ground.

CHECK : **Connector & terminal (F50) No. 3 — Chassis ground**
Is resistance less than 0.5 Ω?

YES : Go to step 10AC4.

NO : Repair relay box ground harness.


10AC4 CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Disconnect connector (ABS1) from hydraulic unit.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : **Connector & terminal (ABS1) No. 2 (+) — Chassis ground (-)**
Is voltage 0 V?

YES : Go to next step.

NO : Replace relay box. Check fuse No. 19 and SBF6.


5) Turn ignition switch to OFF.

- 6) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : **Connector & terminal (ABS1) No. 2 (+) — Chassis ground (-)**
Is voltage 0 V?

YES : Go to step 10AC5.

NO : Replace relay box. Check fuse No. 9 and SBF6.




10AC5 CHECK BROKEN WIRE IN GROUND CIRCUIT OF RELAY BOX.

Measure resistance between relay box connector and valve relay installing point.

CHECK : **Connector & terminal To (F50) No. 3 — Valve relay installing point No. 87a**
Is resistance less than 0.5 Ω?

YES : Go to step 10AC6.

NO : Replace relay box.




10AC6 CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.

1) Install valve relay to relay box.
 2) Measure resistance between relay box connector and chassis ground.

CHECK : **Connector & terminal To (F50) No. 1 — Chassis ground**
Is resistance more than 1 MΩ?

YES : Go to step 10AC7.

NO : Replace relay box and check all fuses.




10AC7 CHECK GROUND SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.

Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 27 — Chassis ground**
Is resistance more than 1 MΩ?

YES : Go to step 10AC8.

NO : Repair harness between ABSCM and relay box. Check fuse No. 18.



10AC8 CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector (ABS1, F9) from hydraulic unit.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : **Connector & terminal**
To (F63) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.

NO : Replace hydraulic unit and check all fuses.


- 4) Turn ignition switch to OFF.

- 5) Measure voltage between hydraulic unit connector and chassis ground.

CHECK : **Connector & terminal**
To (F63) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10AC9.

NO : Replace hydraulic unit and check all fuses.



10AC9 CHECK BATTERY SHORT OF HARNESS.

- 1) Disconnect connector from hydraulic unit.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 30 (+) — Chassis ground (-)
(F49) No. 24 (+) — Chassis ground (-)
(F49) No. 23 (+) — Chassis ground (-)
(F49) No. 31 (+) — Chassis ground (-)
(F49) No. 3 (+) — Chassis ground (-)
(F49) No. 51 (+) — Chassis ground (-)
(F49) No. 50 (+) — Chassis ground (-)
(F49) No. 4 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.

NO : Repair harness between hydraulic unit and ABSCM and check all fuses.

- 4) Turn ignition switch to OFF.
- 5) Measure voltage between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
 (F49) No. 30 (+) — Chassis ground (-)
 (F49) No. 24 (+) — Chassis ground (-)
 (F49) No. 23 (+) — Chassis ground (-)
 (F49) No. 31 (+) — Chassis ground (-)
 (F49) No. 3 (+) — Chassis ground (-)
 (F49) No. 51 (+) — Chassis ground (-)
 (F49) No. 50 (+) — Chassis ground (-)
 (F49) No. 4 (+) — Chassis ground (-)
 Is voltage 0 V?

YES : Go to step 10AC10.

NO : Repair harness between hydraulic unit and ABSCM and check all fuses.

10AC10	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.
---------------	--

CHECK : **Is there poor contact in connector between ABSCM and hydraulic unit?**

YES : Repair connector.

NO : Go to step 10AC11.

10AC11	CHECK ABSCM.
---------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 52 (FB1) M. RELAY OPEN

B4M0969


AD: 52 M. RELAY OPEN — OPEN CIRCUIT OF MOTOR RELAY —

DIAGNOSIS:

- Faulty motor
- Faulty motor relay
- Faulty harness connector


TROUBLE SYMPTOM:

- ABS does not operate.





Continues to next page.

From the former page.



WIRING DIAGRAM:






10AD1 CHECK RESISTANCE OF MOTOR RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Measure resistance between motor relay terminals.

CHECK : *Terminals*
No. 85 — No. 86
Is resistance $80 \pm 10 \Omega$?

- YES** : Go to step 10AD2.
NO : Replace motor relay.




10AD2 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Connect battery to motor relay terminals No. 85 and No. 86.
- 2) Measure resistance between motor relay terminals.

CHECK : *Terminals*
No. 30 — No. 87
Is resistance less than 0.5Ω ?


- YES** : Go to next step.
NO : Replace motor relay.



- 3) Disconnect battery from motor relay terminals.
- 4) Measure resistance between motor relay terminals.

CHECK : *Terminals*
No. 30 — No. 87
Is resistance more than $1 M\Omega$?

- YES** : Go to step 10AD3.
NO : Replace motor relay.




10AD3 CHECK SHORT OF MOTOR RELAY.

Measure resistance between motor relay terminals.

CHECK : *Terminals*
No. 85 — No. 30
No. 85 — No. 87
Is resistance more than $1 M\Omega$?

- YES** : Go to step 10AD4.
NO : Replace motor relay.



10AD4 CHECK INPUT VOLTAGE OF RELAY BOX.

- 1) Disconnect connector (F8) from relay box.
- 2) Measure voltage between relay box connector and chassis ground.

CHECK : **Connector & terminal (F8) No. 2 (+) — Chassis ground (-)**
Is voltage 10 — 13 V?

YES : Go to step **10AD5**.

NO : Repair harness connector between battery and relay box. Check fuse SBF6.



10AD5 CHECK INPUT VOLTAGE OF MOTOR RELAY.

- 1) Connect connector (F8) to relay box.
- 2) Measure voltage between relay box and chassis ground.

CHECK : **Connector & terminal Relay installing point No. 87 (+) — Chassis ground (-)**
Is voltage 10 — 13 V?

YES : Go to step **10AD6**.

NO : Replace relay box and fuse SBF6.




10AD6 CHECK BROKEN WIRE IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Disconnect connector (ABS1) from hydraulic unit.
- 2) Measure resistance between hydraulic unit and motor relay installing portion.

CHECK : **Connector & terminal (ABS1) No. 1 — Motor relay installing portion No. 30**
Is resistance less than 0.5 Ω?

YES : Go to step 10AD7.

NO : Replace relay box.




10AD7 CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

Measure resistance between hydraulic unit and chassis ground.

CHECK : **Connector & terminal (ABS1) No. 1 — Chassis ground**
Is resistance more than 1 MΩ?

YES : Go to step 10AD8.

NO : Replace relay box. Check fuse No. 19.




10AD8 CHECK BROKEN WIRE IN MONITOR SYSTEM CIRCUIT OF RELAY BOX.

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between relay box connector and motor relay installing point.

CHECK : **Connector & terminal To (F50) No. 6 — Motor relay installing point No. 30**
Is resistance less than 0.5 Ω?

YES : Go to step 10AD9.

NO : Replace relay box.



10AD9 CHECK BROKEN WIRE IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Remove valve relay from relay box.
- 2) Measure resistance between motor relay installing point and valve relay installing point.

CHECK : **Connector & terminal**
Motor relay installing point No. 86 — Valve relay installing point No. 30
Is resistance less than 0.5 Ω?

YES : Go to next step.

NO : Replace relay box.




- 3) Measure resistance between motor relay installing point and relay box connector.

CHECK : **Connector & terminal**
Motor relay installing point No. 86 — To (F50) No. 4
Is resistance less than 0.5 Ω?

YES : Go to step 10AD10.

NO : Replace relay box.



10AD10 CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.

Measure resistance between relay box and chassis ground.

CHECK : **Connector & terminal**
Motor relay installing point No. 86 — Chassis ground
Motor relay installing point No. 85 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10AD11.

NO : Replace relay box. Check fuse No. 19.


10AD11 CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between motor relay installing point and chassis ground.

CHECK : **Connector & terminal**
Motor relay installing point No. 85 (+) —
Chassis ground (-)
Motor relay installing point No. 86 (+) —
Chassis ground (-).
Is voltage 0 V?

YES : Go to next step.

NO : Replace relay box and check all fuses.


- 4) Turn ignition switch to OFF.

- 5) Measure voltage between motor relay installing point and chassis ground.

CHECK : **Connector & terminal**
Motor relay installing point No. 85 (+) —
Chassis ground
Motor relay installing point No. 86 (+) —
Chassis ground (-)
Is voltage 0 V?

YES : Go to step **10AD12**.

NO : Replace relay box and check all fuses.



10AD12 CHECK BROKEN WIRE IN MONITOR SYSTEM HARNESS.

- 1) Connect between terminals No. 10 and No. 1 of ABSCM connector (F49) with a lead wire.
- 2) Measure resistance between relay box connector and chassis ground.

CHECK : **Connector & terminal**
(F50) No. 6 — Chassis ground
Is resistance less than 0.5 Ω?

YES : Go to step **10AD13**.

NO : Repair harness connector between ABSCM and relay box.




10AD13 CHECK BROKEN WIRE IN RELAY CONTROL SYSTEM HARNESS.

- 1) Connect valve relay and motor relay to relay box.
- 2) Connect connector (F50) to relay box.
- 3) Connect connector to hydraulic unit.
- 4) Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 22 — Chassis ground**
Is resistance $80 \pm 10 \Omega$?

- YES** : Go to step **10AD14**.
- NO** : Repair harness connector between ABSCM and relay box.




10AD14 CHECK GROUND SHORT BETWEEN RELAY BOX AND ABSCM.

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal (F49) No. 22 — Chassis ground**
(F49) No. 10 — Chassis ground
Is resistance more than $1 M\Omega$?

- YES** : Go to step **10AD15**.
- NO** : Repair harness between ABSCM and relay box. Check fuse No. 19 and SBF6.



10AD15 CHECK BATTERY SHORT BETWEEN RELAY BOX AND ABSCM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM and chassis ground.


CHECK : *Connector & terminal*
 (F49) No. 22 (+) — Chassis ground (-)
 (F49) No. 10 (+) — Chassis ground (-)
 Is voltage 0 V?

- YES** : Go to next step.
NO : Repair harness between relay box and ABSCM. Check fuse SBF6.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM and chassis ground.

CHECK : *Connector & terminal*
 (F49) No. 22 (+) — Chassis ground (-)
 (F49) No. 10 (+) — Chassis ground (-)
 Is voltage 0 V?

- YES** : Go to step 10AD16.
NO : Repair harness between relay box and ABSCM. Check fuse SBF6.




10AD16 CHECK GROUND SHORT AT ABSCM MONITOR TERMINAL.

Measure resistance between ABSCM terminals.

CHECK : *Connector & terminal*
 To (F49) No. 10 — No. 1
 Is resistance more than 1 MΩ?

- YES** : Go to step 10AD17.
NO : Replace ABSCM.




10AD17 CHECK ABSCM MOTOR DRIVE TERMINAL.

- 1) Disconnect connector cover from ABSCM connector. <Ref. to 4-4c [T8C3] steps 5) to 8).>
- 2) Connect all connectors.
- 3) Measure voltage between ABSCM connector terminals.
- 4) Operate the check sequence. <Ref. to 4-4 [W22D1].>

CHECK : *Connector & terminals*
 (F49) No. 22 (+) — No. 1 (-)
 Does the voltage drop from 10 — 13 V to less than 1.5 V, and rise to 10 — 13 V again when carrying out the check sequence?

- YES** : Go to step 10AD18.
NO : Replace ABSCM.

**10AD18 CHECK MOTOR OPERATION.**

- 1) Measure voltage between ABSCM connector terminal.
- 2) Operate the check sequence. <Ref. to 4-4 [W22D1].>

CHECK : **Connector & terminals (F49) No. 10 (+) — No. 1 (-)**
Does the voltage raise from less than 1.5 V to 10 — 13 V, and return to less than 1.5 V again when carrying out the check sequence?
Can motor revolution noise (buzz) be heard when carrying out the check sequence?

- YES** : Go to step **10AD19**.
NO : Replace hydraulic unit.

10AD19 CHECK POOR CONTACT IN CONNECTOR BETWEEN HYDRAULIC UNIT, RELAY BOX AND ABSCM.

CHECK : **Is there poor contact in connector between hydraulic unit, relay box and ABSCM?**

- YES** : Repair connector.
NO : Go to step **10AD20**.

10AD20 CHECK ABSCM.


- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**

- YES** : Replace ABSCM.
NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

- YES** : Proceed with the diagnosis corresponding to the trouble code.
NO : A temporary poor contact.




**AE: 52 M. RELAY ON
— MOTOR RELAY ON FAILURE —**

DIAGNOSIS:


- Faulty motor
- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1049



B4M0886A


10AE1 CHECK RESISTANCE OF MOTOR RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Measure resistance between motor relay terminals.

CHECK : **Terminals**
No. 85 — No. 86
Is resistance 80±10 Ω?

YES : Go to step **10AE2**.

NO : Replace motor relay.




10AE2 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Connect battery to motor relay terminals No. 85 and No. 86.
- 2) Measure resistance between motor relay terminals.

CHECK : *Terminals No. 30 — No. 87*
Is resistance less than 0.5 Ω?

YES : Go to next step.

NO : Replace motor relay.




- 3) Disconnect battery from motor relay terminals.
- 4) Measure resistance between motor relay terminals.

CHECK : *Terminals No. 30 — No. 87*
Is resistance more than 1 MΩ?

YES : Go to step 10AE3.

NO : Replace motor relay.




10AE3 CHECK SHORT OF MOTOR RELAY.

Measure resistance between motor relay terminals.

CHECK : *Terminals No. 85 — No. 30*
No. 85 — No. 87
Is resistance more than 1 MΩ?

YES : Go to step 10AE4.

NO : Replace motor relay.



10AE4 CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Disconnect connector (ABS1) from hydraulic unit.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between relay box connector and chassis ground.

CHECK : **Connector & terminal (ABS1) No. 1 (+) — Chassis ground (-)**
Is voltage 0 V?

YES : Go to next step.

NO : Replace relay box.


- 5) Turn ignition switch to OFF.

- 6) Measure voltage between relay box connector and chassis ground.

CHECK : **Connector & terminal (ABS1) No. 1 (+) — Chassis ground (-)**
Is voltage 0 V?

YES : Go to step 10AE5.

NO : Replace relay box.




10AE5 CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between relay box and chassis ground.

CHECK : **Connector & terminal Motor relay installing point No. 85 — Chassis ground**
Motor relay installing point No. 86 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10AE6.

NO : Replace relay box. Check fuse No. 19.




10AE6 CHECK GROUND SHORT BETWEEN RELAY BOX AND ABSCM.

- 1) Disconnect connector (F49) from ABSCM.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 22 — Chassis ground
(F49) No. 10 — Chassis ground
Is resistance more than 1 MΩ?

YES : Go to step 10AE7.

NO : Repair harness between ABSCM and relay box.
 Check fuse No. 19 and SBF6.



10AE7 CHECK BATTERY SHORT BETWEEN RELAY BOX AND ABSCM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 22 (+) — Chassis ground (-)
(F49) No. 10 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to next step.


NO : Repair harness between relay box and ABSCM.
 Check fuse SBF6.

- 3) Turn ignition switch to OFF.
- 4) Measure voltage between ABSCM and chassis ground.

CHECK : **Connector & terminal**
(F49) No. 22 (+) — Chassis ground (-)
(F49) No. 10 (+) — Chassis ground (-)
Is voltage 0 V?

YES : Go to step 10AE8.

NO : Repair harness between relay box and ABSCM.
 Check fuse SBF6.

**10AE8 CHECK BATTERY SHORT AT ABSCM MONITOR TERMINAL.**

- 1) Disconnect connector cover from ABSCM connector.
<Ref. to 4-4c [T8C1] steps 5) to 8).>
- 2) Connect all connectors.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ABSCM connector terminals.

CHECK : **Connector & terminal (F49) No. 10 (+) — No. 1 (-)**
Is voltage less than 2 V?

YES : Go to next step.


NO : Replace ABSCM.

- 5) Turn ignition switch to OFF.
- 6) Measure voltage between ABSCM connector terminals.

CHECK : **Connector & terminals (F49) No. 10 (+) — No. 1 (-)**
Is voltage less than 2 V?

YES : Go to step 10AE9.


NO : Replace ABSCM.

**10AE9 CHECK MOTOR GROUND.**

CHECK : **Tightening torque:**
 $32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft}\cdot\text{lb}$)
Is the motor ground terminal tightly clamped?

YES : Go to step 10AE10.

NO : Tighten the clamp of motor ground terminal.


**10AE10 CHECK ABSCM MOTOR DRIVE TERMINAL.**

- 1) Measure voltage between ABSCM connector terminals.
- 2) Operate the check sequence. <Ref. to 4-4 [W22D1].>

CHECK : **Connector & terminals (F49) No. 22 (+) — No. 1 (-)**
Does the voltage drop from 10 — 13 V to less than 1.5 V, and rise to 10 — 13 V again when carrying out the check sequence?

YES : Go to step 10AE11.

NO : Replace ABSCM.

**10AE11 CHECK MOTOR OPERATION.**

- 1) Measure voltage between ABSCM connector terminal.
- 2) Operate the check sequence. <Ref. to 4-4 [W22D1].>

CHECK : **Connector & terminals (F49) No. 10 (+) — No. 1 (–)**
Does the voltage raise from less than 1.5 V to 10 — 13 V, and return to less than 1.5 V again when carrying out the check sequence?
Can motor revolution noise (buzz) be heard when carrying out the check sequence?

- YES** : Go to step **10AE12**.
NO : Replace hydraulic unit.

10AE12 CHECK POOR CONTACT IN CONNECTOR BETWEEN HYDRAULIC UNIT, RELAY BOX AND ABSCM.

CHECK : **Is there poor contact in connector between hydraulic unit, relay box and ABSCM?**

- YES** : Repair connector.
NO : Go to step **10AE13**.

10AE13 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**

- YES** : Replace ABSCM.
NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

- YES** : Proceed with the diagnosis corresponding to the trouble code.
NO : A temporary poor contact.

D•NEW 52 (FB1) MOTOR

B4M0971


AF: 52 MOTOR — ABNORMAL MOTOR —

DIAGNOSIS:


- Faulty motor
- Faulty motor relay
- Faulty harness connector


TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:






10AF1 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Connect battery to motor relay terminals No. 85 and No. 86.
- 4) Measure resistance between motor relay terminals.

CHECK : *Terminals No. 30 — No. 87*
Is resistance less than 0.5 Ω?


- YES** : Go to next step.
- NO** : Replace motor relay.



- 5) Disconnect battery from motor relay terminals.
- 6) Measure resistance between motor relay terminals.

CHECK : *Terminals No. 30 — No. 87*
Is resistance more than 1 MΩ?

- YES** : Go to step 10AF2.
- NO** : Replace motor relay.




10AF2 CHECK INPUT VOLTAGE OF RELAY BOX.

- 1) Disconnect connector (F8) from relay box.
- 2) Measure voltage between relay box connector and chassis ground.

CHECK : *Connector & terminal (F8) No. 2 (+) — Chassis ground (-)*
Is voltage 10 — 13 V?


- YES** : Go to step 10AF3.
- NO** : Repair harness connector between battery and relay box. Check fuse SBF6.

**10AF3 CHECK MOTOR GROUND.**

CHECK : **Tightening torque:**
 $32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft}\cdot\text{lb}$)
Is the motor ground terminal tightly clamped?

YES : Go to step 10AF4.

NO : Tighten the clamp of motor ground terminal.

**10AF4 CHECK MOTOR OPERATION.**

- 1) Disconnect connector (F49) from ABSCM.
- 2) Disconnect connector cover from ABSCM connector (F49). <Ref. to 4-4c [T8C1] steps 5) to 8).>
- 3) Connect connector (F49) to ABSCM.
- 4) Connect motor relay to relay box.
- 5) Connect all connectors.
- 6) Measure voltage between ABSCM connector terminal.
- 7) Operate the check sequence. <Ref. to 4-4 [W22D1].>

CHECK : **Connector & terminals**
(F49) No. 10 (+) — No. 1 (-)
Does the voltage raise from less than 1.5 V to 10 — 13 V, and return to less than 1.5 V again when carrying out the check sequence?
Can motor revolution noise (buzz) be heard when carrying out the check sequence?

YES : Go to step 10AF5.

NO : Replace hydraulic unit.

10AF5 CHECK POOR CONTACT IN CONNECTOR BETWEEN HYDRAULIC UNIT, RELAY BOX AND ABSCM.

CHECK : **Is there poor contact in connector between hydraulic unit, relay box and ABSCM?**

YES : Repair connector.

NO : Go to step 10AF6.

10AF6	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 54 (FB1)
BLS

B4M0972


AG: 54 BLS
— ABNORMAL STOP LIGHT SWITCH —

DIAGNOSIS:


- Faulty stop light switch

TROUBLE SYMPTOM:


- ABS does not operate.



WIRING DIAGRAM:



B4M1041



10AG1 CHECK OUTPUT OF STOP LIGHT SWITCH USING SELECT MONITOR.

- 1) Press **F**, **0** and **9** on the select monitor.
- 2) Depress the brake pedal.
- 3) Read the stop light switch output on the select monitor display.

CHECK : *Is the reading indicated on monitor display less than 1.5 V?*

YES : Go to next step.

NO : Go to step **10AG1**.

- 4) Release the brake pedal.

- 5) Read the stop light switch output on the select monitor display.

CHECK : *Is the reading indicated on monitor display greater than 4.5 V?*

YES : Go to step **10AG4**.

NO : Go to step **10AG2**.


10AG2 CHECK IF STOP LIGHTS COME ON.

Depress the brake pedal.

CHECK : *Do stop lights turn on?*

YES : Go to step **10AG3**.

NO : Repair stop lights circuit.



10AG3 CHECK OPEN CIRCUIT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Depress brake pedal.
- 4) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 36 — Chassis ground Is voltage 10 — 13 V?*

YES : Go to step **10AG4**.

NO : Repair harness between stop light switch and ABSCM.

10AG4	CHECK POOR CONTACT IN CONNECTOR BETWEEN STOP LIGHT SWITCH AND ABSCM.
--------------	---

CHECK : *Is there poor contact in connector between stop light switch and ABSCM?*

YES : Repair connector.

NO : Go to step **10AG5**.

10AG5	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR LINE

B4M0974


AH: 56 G SENSOR LINE
— OPEN OR SHORT CIRCUIT OF G SENSOR
—

DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.



Continues to next page.

From the former page.


10AH11. Check ground short in G sensor output harness.

10AH12. Check G sensor.

10AH13. Check poor contact in connector between ABSCM and G sensor.

10AH14. Check ABSCM.

WIRING DIAGRAM:



B4M1050

1996 (F00)
ABS 4WD•AT

B4M0921

10AH1 CHECK SPECIFICATIONS OF ABSCM USING SELECT MONITOR.

- 1) Press **F**, **0** and **0** on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is an ABSCM for 4WD model installed on a FWD model?*

YES : Replace ABSCM.

NO : Go to step 10AH2.

G-SENS (F10)
2.30 V

B4M0927

10AH2 CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.

- 1) Press **F**, **1** and **0** on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading 2.3 ± 0.2 V when the G sensor is in horizontal position?*

YES : Go to step 10AH3.

NO : Go to step 10AH5.

10AH3 CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND G SENSOR.

CHECK : *Is there poor contact in connector between ABSCM and G sensor?*

YES : Repair connector.

NO : Go to step 10AH4.

10AH4 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.


**10AH5 CHECK FREEZE FRAME DATA.**

1) Press **[F]**, **[E]** and **[5]** on the select monitor.

CHECK : *Is the reading indicated on monitor display 0 km?*

YES : Go to next step.

NO : Go to step **10AH9**.




2) Press the scroll key so that FE6 appears on the monitor display.

CHECK : *Is the reading indicated on monitor display 0 km?*

YES : Go to next step.

NO : Go to step **10AH9**.




3) Press the scroll key so that FE7 appears on the monitor display.

CHECK : *Is the reading indicated on monitor display 0 km?*

YES : Go to next step.

NO : Go to step **10AH9**.




4) Press the scroll key so that FE8 appears on the monitor display.

CHECK : *Is the reading indicated on monitor display 0 km?*

YES : Go to next step.

NO : Go to step **10AH9**.




5) Press the scroll key so that FE14 appears on the monitor display.

CHECK : *Is the reading indicated on monitor display greater than 3.65 V?*

YES : Go to step **10AH6**.

NO : Go to step **10AH9**.

**10AH6**

CHECK BROKEN WIRE IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.

CHECK : **Connector & terminal (P49) No. 7 — No. 45**
Is resistance $4.6 \pm 0.3 \text{ k}\Omega$?

YES : Go to step 10AH7.

NO : Repair harness between G sensor and ABSCM.

10AH7

CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND G SENSOR.

CHECK : **Is there poor contact in connector between ABSCM and G sensor?**

YES : Repair connector.

NO : Go to step 10AH8.

10AH8

CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.




10AH9 CHECK INPUT VOLTAGE OF G SENSOR.

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect G sensor from body. (Do not disconnect connector.)
- 4) Turn ignition switch to ON.
- 5) Measure voltage between G sensor connector terminals.

CHECK : **Connector & terminal (P11) No. 1 (+) — No. 3 (-)**
Is voltage 5 ± 0.25 V?

YES : Go to step **10AH10**.

NO : Repair harness connector between G sensor and ABSCM.




10AH10 CHECK BROKEN WIRE IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.

CHECK : **Connector & terminal (P49) No. 7 — No. 45**
Is resistance 4.6 ± 0.3 k Ω ?

YES : Go to step **10AH11**.

NO : Repair harness between G sensor and ABSCM.




10AH11 CHECK GROUND SHORT IN G SENSOR OUTPUT HARNESS.

- 1) Disconnect connector from G sensor.
- 2) Measure resistance between ABSCM connector and chassis ground.

CHECK : Connector & terminal (F49) No. 7 — Chassis ground
Is resistance more than 1 MΩ?

- YES** : Go to step 10AH12.
NO : Repair harness between G sensor and ABSCM.




10AH12 CHECK G SENSOR.

- 1) Connect connector to G sensor.
- 2) Connect connector to ABSCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between G sensor connector terminals.


CHECK : Connector & terminal (P11) No. 2 (+) — No. 1 (-)
Is voltage 2.3±0.2 V when G sensor is horizontal?

- YES** : Go to next **CHECK** .
NO : Replace G sensor.



CHECK : Connector & terminal (P11) No. 2 (+) — No. 1 (-)
Is voltage 3.9±0.2 V when G sensor is inclined forwards to 90°?

- YES** : Go to next **CHECK** .
NO : Replace G sensor.



CHECK : **Connector & terminal**
(P11) No. 2 (+) — No. 1 (-)
Is voltage 0.7 ± 0.2 V when G sensor is
inclined backwards to 90° ?

YES : Go to step **10AH13**.

NO : Replace G sensor.

10AH13	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND G SENSOR.
---------------	--

CHECK : **Is there poor contact in connector between**
ABSCM and G sensor?

YES : Repair connector.

NO : Go to step **10AH14**.

10AH14	CHECK ABSCM.
---------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current**
diagnosis still being output?

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR +B

B4M0982


AI: 56 G SENSOR +B
— BATTERY SHORT OF G SENSOR —

DIAGNOSIS:


- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.




WIRING DIAGRAM:



G - SENS (F10)
2.30 V

B4M0927



B4M0914A

10AI1 CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.

- 1) Press **F**, **1** and **0** on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading 2.3 ± 0.2 V when the G sensor is in horizontal position?*

YES : Replace ABSCM.

NO : Go to step **10AI2**.

10AI2 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect connector from G sensor.
- 4) Disconnect connector from ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 7 (+) — Chassis ground (-)
Is voltage 0 V?*

YES : Go to next step.

NO : Repair harness between G sensor and ABSCM.

- 7) Turn ignition switch to OFF.

- 8) Measure voltage between ABSCM connector and chassis ground.

CHECK : *Connector & terminal (F49) No. 7 (+) — Chassis ground (-)
Is voltage 0 V?*

YES : Go to step **10AI3**.

NO : Repair harness between G sensor and ABSCM.

10AI3 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR H μ

B4M0984


AJ: 56 G SENSOR H μ
— ABNORMAL G SENSOR HIGH μ OUTPUT
—

DIAGNOSIS:


- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:



B4M1050

G - SENS (F 10)
2.30 V

B4M0927

10AJ1 CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.

- 1) Press **F**, **1** and **0** on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading 2.3±0.2 V when the G sensor is in horizontal position?*

YES : Go to step 10AJ2.

NO : Go to step 10AJ5.

10AJ2 CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND G SENSOR.

CHECK : *Is there poor contact in connector between ABSCM and G sensor?*

YES : Repair connector.

NO : Go to step 10AJ3.

10AJ3 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.




10AJ4 CHECK BROKEN WIRE IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.

CHECK : *Connector & terminal (F49) No. 7 — No. 45
Is resistance $4.6 \pm 0.3 \text{ k}\Omega$?*

YES : Go to step 10AJ5.

NO : Repair harness between G sensor and ABSCM.




10AJ5 CHECK G SENSOR.

- 1) Remove console box.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Connect connector to ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between G sensor connector terminals.

CHECK : **Connector & terminal (P11) No. 2 (+) — No. 1 (-)**
Is voltage 2.3 ± 0.2 V when G sensor is horizontal?

YES : Go to next **CHECK** .


NO : Replace G sensor.



CHECK : **Connector & terminal (P11) No. 2 (+) — No. 1 (-)**
Is voltage 3.9 ± 0.2 V when G sensor is inclined forwards to 90°?

YES : Go to next **CHECK** .

NO : Replace G sensor.



CHECK : **Connector & terminal (P11) No. 2 (+) — No. 1 (-)**
Is voltage 0.7 ± 0.2 V when G sensor is inclined backwards to 90°?

YES : Go to step **10AJ6**.

NO : Replace G sensor.

10AJ6	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : **Is the same trouble code as in the current diagnosis still being output?**

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : **Are other trouble codes being output?**

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR STICK

B4M0813


**AK: 56 G SENSOR STICK
— G SENSOR OUTPUT IS STUCK. —**

DIAGNOSIS:


- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.



WIRING DIAGRAM:



B4M1050

10AK1 CHECK ALL FOUR WHEELS FOR FREE TURNING.

- CHECK** : Have the wheels been turned freely such as when the vehicle is lifted up, or operated on a rolling road?
- YES** : The ABS is normal. Erase the trouble code.
- NO** : Go to step **10AK2**.

G - SENS (F 10)


2.30 V

B4M0927

10AK2 CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.

- 1) Press **F**, **1** and **0** on the select monitor.
 - 2) Read the select monitor display.
- CHECK** : Is the indicated reading **2.3±0.2 V** when the vehicle is in horizontal position?
 - YES** : Go to next step.
 - NO** : Go to step **10AK5**.

- 3) Remove console box.
- 4) Remove G sensor from vehicle. (Do not disconnect connector.)




5) Read the select monitor display.

CHECK : *Is the indicated reading 3.9 ± 0.2 V when G sensor is inclined forwards to 90° ?*

YES : Go to next **CHECK** .

NO : Replace G sensor.



CHECK : *Is the indicated reading 0.7 ± 0.2 V when G sensor is inclined backwards to 90° ?*

YES : Go to step **10AK3**.

NO : Replace G sensor.

10AK3	CHECK POOR CONTACT IN CONNECTOR BETWEEN ABSCM AND G SENSOR.
--------------	--

CHECK : *Is there poor contact in connector between ABSCM and G sensor?*

YES : Repair connector.

NO : Go to step **10AK4**.

10AK4 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*


YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.




10AK5 CHECK BROKEN WIRE IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.

CHECK : *Connector & terminal (F49) No. 7 — No. 45
Is resistance $4.6 \pm 0.3 \text{ k}\Omega$?*

YES : Go to step 10AK6.

NO : Repair harness between G sensor and ABSCM.




10AK6 CHECK G SENSOR.

- 1) Remove console box.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Connect connector to ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between G sensor connector terminals.

CHECK : **Connector & terminal (P11) No. 2 (+) — No. 1 (-)**
Is voltage 2.3 ± 0.2 V when G sensor is horizontal?

YES : Go to next **CHECK** .


NO : Replace G sensor.



CHECK : **Connector & terminal (P11) No. 2 (+) — No. 1 (-)**
Is voltage 3.9 ± 0.2 V when G sensor is inclined forwards to 90°?

YES : Go to next **CHECK** .

NO : Replace G sensor.



CHECK : **Connector & terminal (P11) No. 2 (+) — No. 1 (-)**
Is voltage 0.7 ± 0.2 V when G sensor is inclined backwards to 90°?

YES : Go to step **10AK7**.

NO : Replace G sensor.

10AK7	CHECK ABSCM.
-------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to next **CHECK** .

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.