

8. Diagnostics Chart with Trouble Code by ABS Warning Light

A: LIST OF TROUBLE CODE

Trouble code	Contents of diagnosis	Ref. to	
11	Start code <ul style="list-style-type: none"> ● Trouble code is shown after start code. ● Only start code is shown in normal condition. 	—	
21	Abnormal ABS sensor (Open circuit or input voltage too high)	Front right ABS sensor	4-4d [T8B0]
23		Front left ABS sensor	4-4d [T8C0]
25		Rear right ABS sensor	4-4d [T8D0]
27		Rear left ABS sensor	4-4d [T8E0]
22	Abnormal ABS sensor (Abnormal ABS sensor signal)	Front right ABS sensor	4-4d [T8F0]
24		Front left ABS sensor	4-4d [T8G0]
26		Rear right ABS sensor	4-4d [T8H0]
28		Rear left ABS sensor	4-4d [T8I0]
29		Any one of four	4-4d [T8J0]
31		Abnormal solenoid valve circuit(s) in ABS control module and hydraulic unit	Front right inlet valve
32	Front right outlet valve		4-4d [T8O0]
33	Front left inlet valve		4-4d [T8L0]
34	Front left outlet valve		4-4d [T8P0]
35	Rear right inlet valve		4-4d [T8M0]
36	Rear right outlet valve		4-4d [T8Q0]
37	Rear left inlet valve		4-4d [T8N0]
38	Rear left outlet valve		4-4d [T8R0]
41	Abnormal ABS control module	4-4d [T8S0]	
42	Source voltage is abnormal.	4-4d [T8T0]	
44	A combination of AT control abnormal	4-4d [T8U0]	
51	Abnormal valve relay	4-4d [T8V0]	
52	Abnormal motor and/or motor relay	4-4d [T8W0]	
54	Abnormal stop light switch	4-4d [T8X0]	
56	Abnormal G sensor output voltage	4-4d [T8Y0]	

B: TROUBLE CODE 21 (FRONT RH)
C: TROUBLE CODE 23 (FRONT LH)
D: TROUBLE CODE 25 (REAR RH)
E: TROUBLE CODE 27 (REAR LH)
— ABNORMAL ABS SENSOR (OPEN CIRCUIT OR INPUT VOLTAGE TOO HIGH) —


DIAGNOSIS:





- Faulty ABS sensor (Broken wire, input voltage too high)
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:





8E1	CHECK ABS SENSOR.
------------	--------------------------

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance of ABS sensor connector terminals.

Terminal

Front RH No. 1 — No. 2:

Front LH No. 1 — No. 2:

Rear RH No. 1 — No. 2:

Rear LH No. 1 — No. 2:

CHECK : Is the resistance between 0.8 and 1.2 kΩ?

YES : Go to step 8E2.

NO : Replace ABS sensor.

8E2	CHECK BATTERY SHORT OF ABS SENSOR.
------------	---

- 1) Disconnect connector from ABSCM&H/U.
- 2) Measure voltage between ABS sensor and chassis ground.

Terminal

Front RH No. 1 (+) — Chassis ground (-):

Front LH No. 1 (+) — Chassis ground (-):




Rear RH No. 1 (+) — Chassis ground (-):

Rear LH No. 1 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8E3.

NO : Replace ABS sensor.



8E3 **CHECK BATTERY SHORT OF ABS SENSOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABS sensor and chassis ground.

Terminal

Front RH No. 1 (+) — Chassis ground (-):

Front LH No. 1 (+) — Chassis ground (-):

Rear RH No. 1 (+) — Chassis ground (-):

Rear LH No. 1 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8E4.

NO : Replace ABS sensor.

8E4 **CHECK HARNESS/CONNECTOR BETWEEN ABSCM&H/U AND ABS SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Connect connector to ABS sensor.
- 3) Measure resistance between ABSCM&H/U connector terminals.

Connector & terminal

Trouble code 21 / (F49) No. 11 — No. 12:

Trouble code 23 / (F49) No. 9 — No. 10:


Trouble code 25 / (F49) No. 14 — No. 15:

Trouble code 27 / (F49) No. 7 — No. 8:

CHECK : Is the resistance between 0.8 and 1.2 kΩ?

YES : Go to step 8E5.

NO : Repair harness/connector between ABSCM&H/U and ABS sensor.




8E5 CHECK BATTERY SHORT OF HARNESS.

Measure voltage between ABSCM&H/U connector and chassis ground.

- Connector & terminal**
Trouble code 21 / (F49) No. 11 (+) — Chassis ground (-):
Trouble code 23 / (F49) No. 9 (+) — Chassis ground (-):
Trouble code 25 / (F49) No. 14 (+) — Chassis ground (-):
Trouble code 27 / (F49) No. 7 (+) — Chassis ground (-):

- CHECK** : Is the voltage less than 1 V?
YES : Go to step 8E6.
NO : Repair harness between ABSCM&H/U and ABS sensor.



8E6 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM&H/U connector and chassis ground.

- Connector & terminal**
Trouble code 21 / (F49) No. 11 (+) — Chassis ground (-):
Trouble code 23 / (F49) No. 9 (+) — Chassis ground (-):
Trouble code 25 / (F49) No. 14 (+) — Chassis ground (-):
Trouble code 27 / (F49) No. 7 (+) — Chassis ground (-):

- CHECK** : Is the voltage less than 1 V?
YES : Go to step 8E7.
NO : Repair harness between ABSCM&H/U and ABS sensor.

8E7 CHECK INSTALLATION OF ABS SENSOR.

Tightening torque:
32±10 N·m (3.3±1.0 kg·m, 24±7 ft·lb)

- CHECK** : Are the ABS sensor installation bolts tightened securely?
YES : Go to step 8E8.
NO : Tighten ABS sensor installation bolts securely.

8E8	CHECK INSTALLATION OF TONE WHEEL.
------------	--


Tightening torque:

13±3 N·m (1.3±0.3 kg-m, 9±2.2 ft-lb)

CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step 8E9.

NO : Tighten tone wheel installation bolts securely.



8E9	CHECK ABS SENSOR GAP.
------------	------------------------------

Measure tone wheel-to-pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?


	Front wheel	Rear wheel
Specifications	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)

YES : Go to step 8E10.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.






8E10	CHECK HUB RUNOUT.
-------------	--------------------------

Measure hub runout.

CHECK : Is the runout less than 0.05 mm (0.0020 in)?

YES : Go to step 8E11.

NO : Repair hub.



8E11 CHECK GROUND SHORT OF ABS SENSOR.

- 1) Turn ignition switch to ON.
- 2) Measure resistance between ABS sensor and chassis ground.

Terminal

Front RH No. 1 — Chassis ground:

Front LH No. 1 — Chassis ground:

Rear RH No. 1 — Chassis ground:

Rear LH No. 1 — Chassis ground:

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step 8E12.

NO : Replace ABS sensor and ABSCM&H/U.

8E12 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Connect connector to ABS sensor.
- 3) Measure resistance between ABSCM&H/U connector terminal and chassis ground.

Connector & terminal

Trouble code 21 / (F49) No. 11 — Chassis ground:

Trouble code 23 / (F49) No. 9 — Chassis ground:

Trouble code 25 / (F49) No. 14 — Chassis ground:

Trouble code 27 / (F49) No. 7 — Chassis ground:

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step 8E13.

NO : Repair harness between ABSCM&H/U and ABS sensor.
Replace ABSCM&H/U.

8E13 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between ABSCM&H/U and ABS sensor? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8E14.

8E14	CHECK ABSCM&H/U.
-------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8E15**.

8E15	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

NOTE:

Check harness and connectors between ABSCM&H/U and ABS sensor.

F: TROUBLE CODE 22 (FRONT RH)
G: TROUBLE CODE 24 (FRONT LH)
H: TROUBLE CODE 26 (REAR RH)
I: TROUBLE CODE 28 (REAR LH)
— ABNORMAL ABS SENSOR (ABNORMAL ABS SENSOR SIGNAL) —


DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty harness/connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



811	CHECK INSTALLATION OF ABS SENSOR.
------------	--

Tightening torque:

32±10 N·m (3.3±1.0 kg·m, 24±7 ft·lb)

CHECK : Are the ABS sensor installation bolts tightened securely?

YES : Go to step 812.

NO : Tighten ABS sensor installation bolts securely.

812	CHECK INSTALLATION OF TONE WHEEL.
------------	--


Tightening torque:

13±3 N·m (1.3±0.3 kg·m, 9±2.2 ft·lb)

CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step 813.

NO : Tighten tone wheel installation bolts securely.



813	CHECK ABS SENSOR GAP.
------------	------------------------------

Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?


	Front wheel	Rear wheel
Specifications	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)

YES : Go to step 814.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.



814	CHECK OSCILLOSCOPE.
------------	----------------------------


CHECK : Is an oscilloscope available?

YES : Go to step 815.

NO : Go to step 816.

815	CHECK ABS SENSOR SIGNAL.
------------	---------------------------------

- 1) Raise all four wheels of ground.
- 2) Turn ignition switch OFF.
- 3) Connect the oscilloscope to the connector (F1) or connector (B100).
- 4) Turn ignition switch ON.



- 5) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

Connector & terminal

Trouble code 22 / (B100) No. 12 (+) — No. 13 (-):

Trouble code 24 / (B100) No. 3 (+) — No. 4 (-):

Trouble code 26 / (F1) No. 4 (+) — No. 5 (-):

Trouble code 28 / (F1) No. 1 (+) — No. 2 (-):

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : *Is oscilloscope pattern smooth, as shown in figure?*

YES : Go to step 819.

NO : Go to step 816.

816	CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL.
------------	---

Remove disc rotor or drum from hub in accordance with trouble code.

CHECK : *Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?*

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to step 817.

817	CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL.
------------	--

CHECK : *Are there broken or damaged in the ABS sensor pole piece or the tone wheel?*


YES : Replace ABS sensor or tone wheel.

NO : Go to step 818.

818	CHECK HUB RUNOUT.
------------	--------------------------

Measure hub runout.

- CHECK** : *Is the runout less than 0.05 mm (0.0020 in)?*
- YES** : Go to step **819**.
- NO** : Repair hub.



819	CHECK RESISTANCE OF ABS SENSOR.
------------	--

- 1) Turn ignition switch OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance between ABS sensor connector terminals.

Terminal



Front RH No. 1 — No. 2:

Front LH No. 1 — No. 2:

Rear RH No. 1 — No. 2:

Rear LH No. 1 — No. 2:

- CHECK** : *Is the resistance between 0.8 and 1.2 kΩ?*
- YES** : Go to step **8110**.
- NO** : Replace ABS sensor.



8110	CHECK GROUND SHORT OF ABS SENSOR.
-------------	--

Measure resistance between ABS sensor and chassis ground.

Terminal


Front RH No. 1 — Chassis ground:


Front LH No. 1 — Chassis ground:

Rear RH No. 1 — Chassis ground:

Rear LH No. 1 — Chassis ground:

- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **8111**.
- NO** : Replace ABS sensor.





8I11 CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

- 1) Connect connector to ABS sensor.
- 2) Disconnect connector from ABSCM&H/U.
- 3) Measure resistance at ABSCM&H/U connector terminals.

Connector & terminal

Trouble code 22 / (F49) No. 11 — No. 12:

Trouble code 24 / (F49) No. 9 — No. 10:


Trouble code 26 / (F49) No. 14 — No. 15:

Trouble code 28 / (F49) No. 7 — No. 8:

CHECK : Is the resistance between 0.8 and 1.2 kΩ?

YES : Go to step 8I12.

NO : Repair harness/connector between ABSCM&H/U and ABS sensor.



8I12 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal

Trouble code 22 / (F49) No. 11 — Chassis ground:

Trouble code 24 / (F49) No. 9 — Chassis ground:


Trouble code 26 / (F49) No. 14 — Chassis ground:

Trouble code 28 / (F49) No. 7 — Chassis ground:

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step 8I13.

NO : Repair harness/connector between ABSCM&H/U and ABS sensor.



8I13 CHECK GROUND CIRCUIT OF ABSCM&H/U.

Measure resistance between ABSCM&H/U and chassis ground.

Connector & terminal

(F49) No. 23 — GND:

CHECK : Is the resistance less than 0.5 Ω?

YES : Go to step 8I14.

NO : Repair ABSCM&H/U ground harness.

8I14	CHECK POOR CONTACT IN CONNECTORS.
-------------	--

CHECK : *Is there poor contact in connectors between ABSCM&H/U and ABS sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 8I15.

8I15	CHECK SOURCES OF SIGNAL NOISE.
-------------	---------------------------------------

CHECK : *Is the car telephone or the wireless transmitter properly installed?*

YES : Go to step 8I16.


NO : Properly install the car telephone or the wireless transmitter.

8I16	CHECK SOURCES OF SIGNAL NOISE.
-------------	---------------------------------------

CHECK : *Are noise sources (such as an antenna) installed near the sensor harness?*

YES : Install the noise sources apart from the sensor harness.

NO : Go to step 8I17.



8I17	CHECK SHIELD CIRCUIT.
-------------	------------------------------

- 1) Connect all connectors.
- 2) Measure resistance between shield connector and chassis ground.

Connector & terminal

Trouble code 22 / (B100) No. 11 — Chassis ground:

Trouble code 24 / (B100) No. 2 — Chassis ground:

Trouble code 26 / Go to step 8I18.

Trouble code 28 / Go to step 8I18.

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 8I18.

NO : Repair shield harness.

8I18	CHECK ABSCM&H/U.
-------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8I19**.

8I19	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary noise interference.

**J: TROUBLE CODE 29
— ABNORMAL ABS SENSOR SIGNAL (ANY ONE OF FOUR) —**


DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty tone wheel
- Wheels turning freely for a long time

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



8J1	CHECK IF THE WHEELS HAVE TURNED FREELY FOR A LONG TIME.
------------	--

CHECK : *Check if the wheels have been turned freely for more than one minute, such as when the vehicle is jacked-up, under full-lock cornering or when tire is not in contact with road surface.*

YES : The ABS is normal. Erase the trouble code.

NOTE:

When the wheels turn freely for a long time, such as when the vehicle is towed or jacked-up, or when steering wheel is continuously turned all the way, this trouble code may sometimes occur.

NO : Go to step **8J2**.

8J2	CHECK TIRE SPECIFICATIONS.
------------	-----------------------------------

CHECK : *Are the tire specifications correct?*

YES : Go to step **8J3**.

NO : Replace tire.

8J3	CHECK WEAR OF TIRE.
------------	----------------------------

CHECK : *Is the tire worn excessively?*

YES : Replace tire.

NO : Go to step **8J4**.

8J4	CHECK TIRE PRESSURE.
------------	-----------------------------

CHECK : *Is the tire pressure correct?*

YES : Go to step **8J5**.

NO : Adjust tire pressure.

8J5	CHECK INSTALLATION OF ABS SENSOR.
------------	--

Tightening torque:

32±10 N·m (3.3±1.0 kg·m, 24±7 ft·lb)

CHECK : *Are the ABS sensor installation bolts tightened securely?*

YES : Go to step **8J6**.

NO : Tighten ABS sensor installation bolts securely.

8J6	CHECK INSTALLATION OF TONE WHEEL.
------------	--


Tightening torque:

13±3 N·m (1.3±0.3 kg-m, 9±2.2 ft-lb)

CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step 8J7.

NO : Tighten tone wheel installation bolts securely.



8J7	CHECK ABS SENSOR GAP.
------------	------------------------------

Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?


	Front wheel	Rear wheel
Specifications	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)

YES : Go to step 8J8.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.



8J8	CHECK OSCILLOSCOPE.
------------	----------------------------


CHECK : Is an oscilloscope available?

YES : Go to step 8J9.

NO : Go to step 8J10.

8J9	CHECK ABS SENSOR SIGNAL.
------------	---------------------------------

- 1) Raise all four wheels of ground.
- 2) Turn ignition switch OFF.
- 3) Connect the oscilloscope to the connector (F1) or connector (B100).
- 4) Turn ignition switch ON.



5) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

Connector & terminal

(B100) No. 12 (+) — No. 13 (-) (Front RH):

(B100) No. 3 (+) — No. 4 (-) (Front LH):

(F1) No. 4 (+) — No. 5 (-) (Rear RH):

(F1) No. 1 (+) — No. 2 (-) (Rear LH):

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : *Is oscilloscope pattern smooth, as shown in figure?*

YES : Go to step 8J13.

NO : Go to step 8J10.

8J10	CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL.
-------------	---

Remove disc rotor from hub.

CHECK : *Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?*

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to step 8J11.

8J11	CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL.
-------------	--

CHECK : *Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?*

YES : Replace ABS sensor or tone wheel.

NO : Go to step 8J12.

8J12	CHECK HUB RUNOUT.
-------------	--------------------------

Measure hub runout.

CHECK : *Is the runout less than 0.05 mm (0.0020 in)?*

YES : Go to step 8J13.

NO : Repair hub.

8J13	CHECK ABSCM&H/U.
-------------	-----------------------------

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8J14**.

8J14	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

K: TROUBLE CODE 31 (FRONT RH)
L: TROUBLE CODE 33 (FRONT LH)
M: TROUBLE CODE 35 (REAR RH)
N: TROUBLE CODE 37 (REAR LH)
— ABNORMAL INLET SOLENOID VALVE
CIRCUIT(S) IN ABSCM&H/U —


DIAGNOSIS:

- Faulty harness/connector
- Faulty inlet solenoid valve in ABSCM&H/U


TROUBLE SYMPTOM:

- ABS does not operate.


WIRING DIAGRAM:



B4M1245

**8N1****CHECK INPUT VOLTAGE OF ABSCM&H/U.**

- 1) Disconnect connector from ABSCM&H/U.
- 2) Run the engine at idle.
- 3) Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal**(F49) No. 1 (+) — Chassis ground (-):****CHECK** : *Is the voltage between 10 V and 15 V?***YES** : Go to step 8N2.**NO** : Repair harness connector between battery, ignition switch and ABSCM&H/U.**8N2****CHECK GROUND CIRCUIT OF ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal**(F49) No. 23 — Chassis ground:****CHECK** : *Is the resistance less than 0.5 Ω?***YES** : Go to step 8N3.**NO** : Repair ABSCM&H/U ground harness.**8N3****CHECK POOR CONTACT IN CONNECTORS.****CHECK** : *Is there poor contact in connectors between generator, battery and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>***YES** : Repair connector.**NO** : Go to step 8N4.

8N4	CHECK ABSCM&H/U.
------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8N5**.

8N5	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

O: TROUBLE CODE 32 (FRONT RH)
P: TROUBLE CODE 34 (FRONT LH)
Q: TROUBLE CODE 36 (REAR RH)
R: TROUBLE CODE 38 (REAR LH)
— ABNORMAL OUTLET SOLENOID VALVE CIRCUIT(S) IN ABSCM&H/U —


DIAGNOSIS:


- Faulty harness/connector
- Faulty outlet solenoid valve in ABSCM&H/U

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:





8R1 CHECK INPUT VOLTAGE OF ABSCM&H/U.

- 1) Disconnect connector from ABSCM&H/U.
- 2) Run the engine at idle.
- 3) Measure voltage between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 1 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 15 V?

YES : Go to step 8R2.

NO : Repair harness connector between battery, ignition switch and ABSCM&H/U.



8R2 CHECK GROUND CIRCUIT OF ABSCM&H/U.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal

(F49) No. 23 — Chassis ground:

CHECK : Is the resistance less than 0.5 Ω?

YES : Go to step 8R3.

NO : Repair ABSCM&H/U ground harness.

8R3 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between generator, battery and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8R4.

8R4 CHECK ABSCM&H/U.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM&H/U.

NO : Go to step 8R5.

8R5**CHECK ANY OTHER TROUBLE CODES
APPEARANCE.****CHECK**: *Are other trouble codes being output?***YES**

: Proceed with the diagnosis corresponding to the trouble code.

NO

: A temporary poor contact.

**S: TROUBLE CODE 41
— ABNORMAL ABS CONTROL MODULE —**


DIAGNOSIS:

- Faulty ABSCM&H/U.


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



B4M1246

**8S1****CHECK GROUND CIRCUIT OF ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM&H/U.
- 3) Measure resistance between ABSCM&H/U and chassis ground.

Connector & terminal**(F49) No. 23 — Chassis ground:**

- CHECK** : *Is the resistance less than 0.5 Ω?*
- YES** : Go to step **8S2**.
- NO** : Repair ABSCM&H/U ground harness.

8S2**CHECK POOR CONTACT IN CONNECTORS.**

- CHECK** : *Is there poor contact in connectors between battery, ignition switch and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>*
- YES** : Repair connector.
- NO** : Go to step **8S3**.

8S3**CHECK SOURCES OF SIGNAL NOISE.**

- CHECK** : *Is the car telephone or the wireless transmitter properly installed?*
- YES** : Go to step **8S4**.
- NO** : Properly install the car telephone or the wireless transmitter.

8S4**CHECK SOURCES OF SIGNAL NOISE.**

- CHECK** : *Are noise sources (such as an antenna) installed near the sensor harness?*
- YES** : Install the noise sources apart from the sensor harness.
- NO** : Go to step **8S5**.

8S5**CHECK ABSCM&H/U.**

- 1) Connect all connectors.
 - 2) Erase the memory.
 - 3) Perform inspection mode.
 - 4) Read out the trouble code.
- CHECK** : *Is the same trouble code as in the current diagnosis still being output?*
- YES** : Replace ABSCM&H/U.
- NO** : Go to step **8S6**.

8S6**CHECK ANY OTHER TROUBLE CODES
APPEARANCE.****CHECK**: *Are other trouble codes being output?***YES**

: Proceed with the diagnosis corresponding to the trouble code.

NO

: A temporary poor contact.

T: TROUBLE CODE 42

— SOURCE VOLTAGE IS ABNORMAL. —


DIAGNOSIS:

- Power source voltage of the ABSCM&H/U is low or high.


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



B4M1245



8T1 CHECK GENERATOR.

- 1) Start engine.
- 2) Idling after warm-up.
- 3) Measure voltage between generator B terminal and chassis ground.

Terminal

Generator B terminal — Chassis ground:

CHECK : *Is the voltage between 10 V and 17 V?*

YES : Go to step 8T2.

NO : Repair generator.


8T2 CHECK BATTERY TERMINAL.

Turn ignition switch to OFF.

CHECK : *Are the positive and negative battery terminals tightly clamped?*

YES : Go to step 8T3.

NO : Tighten the clamp of terminal.



8T3 CHECK INPUT VOLTAGE OF ABSCM&H/U.

- 1) Disconnect connector from ABSCM&H/U.
- 2) Run the engine at idle.
- 3) Measure voltage between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 1 (+) — Chassis ground (-):

CHECK : *Is the voltage between 10 V and 17 V?*

YES : Go to step 8T4.

NO : Repair harness connector between battery, ignition switch and ABSCM&H/U.

**8T4****CHECK GROUND CIRCUIT OF ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal**(F49) No. 23 — Chassis ground:****CHECK** : *Is the resistance less than 0.5 Ω?***YES** : Go to step 8T5.**NO** : Repair ABSCM&H/U ground harness.**8T5****CHECK POOR CONTACT IN CONNECTORS.****CHECK** : *Is there poor contact in connectors between generator, battery and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>***YES** : Repair connector.**NO** : Go to step 8T6.**8T6****CHECK ABSCM&H/U.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?***YES** : Replace ABSCM&H/U.**NO** : Go to step 8T7.**8T7****CHECK ANY OTHER TROUBLE CODES APPEARANCE.****CHECK** : *Are other trouble codes being output?***YES** : Proceed with the diagnosis corresponding to the trouble code.**NO** : A temporary poor contact.

**U: TROUBLE CODE 44
— A COMBINATION OF AT CONTROL
ABNORMAL —**


DIAGNOSIS:

- Combination of AT control faults


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



B4M1247




8U1 CHECK SPECIFICATIONS OF THE ABSCM.

Check specifications of the mark to the ABSCM&H/U.

Mark	Model
C3	AWD AT
C4	AWD MT

- CHECK** : *Is an ABSCM&H/U for AT model installed on a MT model?*
- YES** : Replace ABSCM&H/U.
- NO** : Go to step **8U2**.




8U2 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors from TCM.
- 3) Disconnect connector from ABSCM&H/U.
- 4) Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal (F49) No. 3 — Chassis ground:

- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **8U3**.
- NO** : Repair harness between TCM and ABSCM&H/U.




8U3 CHECK BATTERY SHORT OF HARNESS.

Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal (F49) No. 3 (+) — Chassis ground (-):

- CHECK** : *Is the voltage less than 1 V?*
- YES** : Go to step **8U4**.
- NO** : Repair harness between TCM and ABSCM&H/U.



8U4 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 3 (+) — Chassis ground (-):

(CHECK) : Is the voltage less than 1 V?

(YES) : Go to step 8U5.

(NO) : Repair harness between TCM and ABSCM&H/U.



8U5 CHECK TCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors to TCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between TCM connector terminal and chassis ground.

Connector & terminal

(B56) No. 5 (+) — Chassis ground (-):

(CHECK) : Is the voltage between 10 V and 15 V?

(YES) : Go to step 8U7.


(NO) : Go to step 8U6.

8U6 CHECK AT.

(CHECK) : Is the AT functioning normally?

(YES) : Replace TCM.

(NO) : Repair AT.

**8U7 CHECK OPEN CIRCUIT OF HARNESS.**

Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal

(F49) No. 3 (+) — Chassis ground (-):

(F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 15 V?

YES : Go to step 8U8.

NO : Repair harness/connector between TCM and ABSCM&H/U.

8U8 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between TCM and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8U9.

8U9 CHECK ABSCM&H/U.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM&H/U.

NO : Go to step 8U10.

8U10 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

**V: TROUBLE CODE 51
— ABNORMAL VALVE RELAY —**


DIAGNOSIS:

- Faulty valve relay


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



B4M1253



8V1 **CHECK INPUT VOLTAGE OF ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM&H/U.
- 3) Run the engine at idle.
- 4) Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal


(F49) No. 1 (+) — Chassis ground (-):

(F49) No. 24 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 15 V?

YES : Go to step 8V2.

NO : Repair harness connector between battery and ABSCM&H/U.



8V2 **CHECK GROUND CIRCUIT OF ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 23 — Chassis ground:

CHECK : Is the resistance less than 0.5 Ω?

YES : Go to step 8V3.

NO : Repair ABSCM&H/U ground harness.



8V3 **CHECK VALVE RELAY IN ABSCM&H/U.**

Measure resistance between ABSCM&H/U and terminals.

Terminals

No. 23 (+) — No. 24 (-):

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step 8V4.

NO : Replace ABSCM&H/U.

8V4	CHECK POOR CONTACT IN CONNECTORS.
------------	--

CHECK : *Is there poor contact in connectors between generator, battery and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **8V5**.

8V5	CHECK ABSCM&H/U.
------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8V6**.

8V6	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

**W: TROUBLE CODE 52
— ABNORMAL MOTOR AND/OR MOTOR RELAY —**


DIAGNOSIS:

- Faulty motor
- Faulty motor relay
- Faulty harness connector


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



B4M1255



8W1

CHECK INPUT VOLTAGE OF ABSCM&H/U.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM&H/U.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 25 (+) — Chassis ground (-):

CHECK : *Is the voltage between 10 V and 15 V?*

YES : Go to step **8W2**.

NO : Repair harness/connector between battery and ABSCM&H/U and check fuse SBF6.



8W2

CHECK GROUND CIRCUIT OF MOTOR.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 26 — Chassis ground:


CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **8W3**.

NO : Repair ABSCM&H/U ground harness.

**8W3****CHECK INPUT VOLTAGE OF ABSCM&H/U.**

- 1) Run the engine at idle.
- 2) Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal**(F49) No. 1 (+) — Chassis ground (-):****(CHECK)** : Is the voltage between 10 V and 15 V?**(YES)** : Go to step 8W4.**(NO)** : Repair harness connector between battery, ignition switch and ABSCM&H/U.**8W4****CHECK GROUND CIRCUIT OF ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal**(F49) No. 23 — Chassis ground:****(CHECK)** : Is the resistance less than 0.5 Ω?**(YES)** : Go to step 8W5.**(NO)** : Repair ABSCM&H/U ground harness.**8W5****CHECK MOTOR OPERATION.**

Operate the sequence control. <Ref. to 4-4 [W20D0].>

NOTE:

Use the diagnosis connector to operate the sequence control.

(CHECK) : Can motor revolution noise (buzz) be heard when carrying out the sequence control?**(YES)** : Go to step 8W6.**(NO)** : Replace ABSCM&H/U.

8W6	CHECK POOR CONTACT IN CONNECTORS.
------------	--

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connector between generator, battery and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **8W7**.

8W7	CHECK ABSCM&H/U.
------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8W8**.

8W8	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

**X: TROUBLE CODE 54
— ABNORMAL STOP LIGHT SWITCH —**


DIAGNOSIS:

- Faulty stop light switch

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




B4M1258

8X1	CHECK STOP LIGHTS COME ON.
------------	-----------------------------------

Depress the brake pedal.

- CHECK** : *Do stop lights come on?*
- YES** : Go to step **8X2**.
- NO** : Repair stop lights circuit.



8X2	CHECK OPEN CIRCUIT IN HARNESS.
------------	---------------------------------------

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM&H/U.
- 3) Depress brake pedal.
- 4) Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal
(F49) No. 2 (+) — Chassis ground (-):

- CHECK** : *Is the voltage between 10 V and 15 V?*
- YES** : Go to step **8X3**.
- NO** : Repair harness between stop light switch and ABSCM&H/U.

8X3	CHECK POOR CONTACT IN CONNECTORS.
------------	--

CHECK : *Is there poor contact in connector between stop light switch and ABSCM&H/U? <Ref. to FOREWORD [T3C1].>*

- YES** : Repair connector.
- NO** : Go to step **8X4**.

8X4	CHECK ABSCM&H/U.
------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

- YES** : Replace ABSCM&H/U.
- NO** : Go to step **8X5**.

8X5	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------------	--

CHECK : *Are other trouble codes being output?*

- YES** : Proceed with the diagnosis corresponding to the trouble code.
- NO** : A temporary poor contact.

**Y: TROUBLE CODE 56
— ABNORMAL G SENSOR OUTPUT
VOLTAGE —**


DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




B4M1260

8Y1	CHECK ALL FOUR WHEELS FOR FREE TURNING.
------------	--

CHECK : *Have the wheels been turned freely such as when the vehicle is lifted up, or operated on a rolling road?*

YES : The ABS is normal. Erase the trouble code.

NO : Go to step **8Y2**.



8Y2	CHECK SPECIFICATIONS OF ABSCM&H/U.
------------	---

Check specifications of the mark to the ABSCM&H/U.

Mark	Model
C3	AWD AT
C4	AWD MT


CHECK : *Is an ABSCM for AWD model installed on a FWD model?*

CAUTION:

Be sure to turn ignition switch to OFF when removing ABSCM&H/U.

YES : Replace ABSCM&H/U.

NO : Go to step **8Y3**.



8Y3	CHECK INPUT VOLTAGE OF G SENSOR.
------------	---

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect G sensor from body. (Do not disconnect connector.)
- 4) Turn ignition switch to ON.
- 5) Measure voltage between G sensor connector terminals.


Connector & terminal

(P11) No. 1 (+) — No. 3 (-):

CHECK : *Is the voltage between 4.75 and 5.25 V?*

YES : Go to step **8Y4**.

NO : Repair harness/connector between G sensor and ABSCM&H/U.




8Y4 **CHECK OPEN CIRCUIT IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM&H/U.
- 3) Measure resistance between ABSCM&H/U connector terminals.

Connector & terminal
(F49) No. 30 — No. 28:

- CHECK** : Is the resistance between 4.3 and 4.9 kΩ?
- YES** : Go to step 8Y5.
- NO** : Repair harness/connector between G sensor and ABSCM&H/U.




8Y5 **CHECK GROUND SHORT IN G SENSOR OUTPUT HARNESS.**

- 1) Disconnect connector from G sensor.
- 2) Measure resistance between ABSCM&H/U connector and chassis ground.

Connector & terminal
(F49) No. 6 — Chassis ground:

- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 8Y6.
- NO** : Repair harness between G sensor and ABSCM&H/U.




8Y6 **CHECK BATTERY SHORT OF HARNESS.**

Measure voltage between ABSCM&H/U connector and chassis ground.

Connector & terminal
(F49) No. 6 (+) — Chassis ground (-):

- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 8Y7.
- NO** : Repair harness between G sensor and ABSCM&H/U.



8Y7 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 6 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **8Y8**.

NO : Repair harness between G sensor and ABSCM&H/U.



8Y8 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM&H/U connector and chassis ground.


Connector & terminal

(F49) No. 28 — Chassis ground:

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step **8Y9**.

NO : Repair harness between G sensor and ABSCM&H/U.
Replace ABSCM&H/U.

**8Y9 CHECK G SENSOR.**


- 1) Turn ignition switch to OFF.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Connect connector to ABSCM&H/U.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between G sensor connector terminals.

Connector & terminal**(P11) No. 2 (+) — No. 1 (-):**

CHECK : *Is the voltage between 2.1 and 2.4 V when G sensor is horizontal?*

YES : Go to step 8Y10.

NO : Replace G sensor.

**8Y10 CHECK G SENSOR.**


Measure voltage between G sensor connector terminals.

Connector & terminal**(P11) No. 2 (+) — No. 1 (-):**

CHECK : *Is the voltage between 3.7 and 4.1 V when G sensor is inclined forwards to 90°?*

YES : Go to step 8Y11.

NO : Replace G sensor.

**8Y11 CHECK G SENSOR.**

Measure voltage between G sensor connector terminals.

Connector & terminal**(P11) No. 2 (+) — No. 1 (-):**

CHECK : *Is the voltage between 0.5 and 0.9 V when G sensor is inclined backwards to 90°?*

YES : Go to step 8Y12.

NO : Replace G sensor.

8Y12 CHECK POOR CONTACT IN CONNECTORS.

CHECK : *Is there poor contact in connector between ABSCM&H/U and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 8Z12.

8Y13	CHECK ABSCM&H/U.
-------------	-----------------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM&H/U.

NO : Go to step **8Y14**.

8Y14	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.