

## 10. Diagnostic Chart with Trouble Code for LHD Vehicles

### A: DIAGNOSTIC TROUBLE CODE (DTC) LIST

DTC No.	Abbreviation (Subaru Select Monitor)	Item	Page
P0101	QA—RLOW	Mass air flow sensor circuit range/performance problem (low input)	132
P0102	QA—LOW	Mass air flow sensor circuit low input	134
P0103	QA—HI	Mass air flow sensor circuit high input	138
P0106	PS—R2	Pressure sensor circuit range/performance problem	141
P0107	P—SLOW	Pressure sensor circuit low input	145
P0108	P—SHI	Pressure sensor circuit high input	149
P0116	TW—LOW	Engine coolant temperature sensor circuit low input	154
P0117	TW—HI	Engine coolant temperature sensor circuit high input	157
P0121	TH—RHI	Throttle position sensor circuit range/performance problem (high input)	160
P0122	THV—LOW	Throttle position sensor circuit low input	162
P0123	THV—HI	Throttle position sensor circuit high input	167
P0125	TW—CL	Insufficient coolant temperature for closed loop fuel control	170
P0130	FO2—V	Front oxygen sensor circuit malfunction	172
P0133	FO2—R	Front oxygen sensor circuit slow response	175
P0135	FO2H	Front oxygen sensor heater circuit malfunction	177
P0136	RO2—V	Rear oxygen sensor circuit malfunction	181
P0139	RO2—R	Rear oxygen sensor circuit slow response	184
P0141	RO2H	Rear oxygen sensor heater circuit malfunction	186
P0170	FUEL	Fuel trim malfunction	190
P0181	TNKT—F	Fuel temperature sensor A circuit range/performance problem	195
P0182	TNKT—LOW	Fuel temperature sensor A circuit low input	197
P0183	TNKT—HI	Fuel temperature sensor A circuit high input	200
P0261	INJ1	Fuel injector circuit low input - #1	203
P0262	INJ1—HI	Fuel injector circuit high input - #1	207
P0264	INJ2	Fuel injector circuit low input - #2	203
P0265	INJ2—HI	Fuel injector circuit high input - #2	207
P0267	INJ3	Fuel injector circuit low input - #3	203
P0268	INJ3—HI	Fuel injector circuit high input - #3	207
P0270	INJ4	Fuel injector circuit low input - #4	203
P0271	INJ4—HI	Fuel injector circuit high input - #4	207
P0301	MIS—1	Cylinder 1 misfire detected	211
P0302	MIS—2	Cylinder 2 misfire detected	211
P0303	MIS—3	Cylinder 3 misfire detected	211
P0304	MIS—4	Cylinder 4 misfire detected	211
P0325	KNOCK	Knock sensor circuit malfunction	219
P0335	CRANK	Crankshaft position sensor circuit malfunction	222
P0336	CRANK—R	Crankshaft position sensor circuit range/performance problem	225
P0340	CAM	Camshaft position sensor circuit malfunction	227

DTC No.	Abbreviation (Subaru Select Monitor)	Item	Page
P0341	CAM—R	Camshaft position sensor circuit range/performance problem	230
P0400	EGR	Exhaust gas recirculation flow malfunction	232
P0403	EGRSOL	Exhaust gas recirculation circuit low input	237
P0420	CAT	Catalyst system efficiency below threshold	240
P0440	EVAP	Evaporative emission control system malfunction	242
P0441	CPC—F	Evaporative emission control system incorrect purge flow	246
P0443	CPC	Evaporative emission control system purge control valve circuit low input	248
P0446	VCMSOL—LO	Evaporative emission control system vent control low input	251
P0451	TNKP—F	Evaporative emission control system pressure sensor range/performance problem	254
P0452	TNKP—LOW	Evaporative emission control system pressure sensor low input	256
P0453	TNKP—HI	Evaporative emission control system pressure sensor high input	261
P0461	FLVL—R	Fuel level sensor circuit range/performance problem	267
P0462	FLVL—LOW	Fuel level sensor circuit low input	269
P0463	FLVL—HI	Fuel level sensor circuit high input	275
P0500	VSP	Vehicle speed sensor malfunction	281
P0505	ISC	Idle control system malfunction	283
P0506	ISC—RLOW	Idle control system RPM lower than expected	289
P0507	ISC—RHI	Idle control system RPM higher than expected	291
P0600	—	Serial communication link malfunction	293
P0601	RAM	Internal control module memory check sum error	295
P0703	ATBRK	Brake switch input malfunction	296
P0705	ATRNG	Transmission range sensor circuit malfunction	299
P0710	ATF	Transmission fluid temperature sensor circuit malfunction	311
P0720	ATVSP	Output speed sensor (vehicle speed sensor 1) circuit malfunction	312
P0725	ATNE	Engine speed input circuit malfunction	313
P0731	ATGR1	Gear 1 incorrect ratio	314
P0732	ATGR2	Gear 2 incorrect ratio	314
P0733	ATGR3	Gear 3 incorrect ratio	314
P0734	ATGR4	Gear 4 incorrect ratio	314
P0740	ATLU—F	Torque converter clutch system malfunction	317
P0743	ATLU	Torque converter clutch system electrical	321
P0748	ATPL	Pressure control solenoid electrical	322
P0753	ATSFT1	Shift solenoid A electrical	323
P0758	ATSFT2	Shift solenoid B electrical	324
P0760	ATOVR—F	Shift solenoid C malfunction	325
P0763	ATOVR	Shift solenoid C electrical	328
P1100	ST—SWOFF	Starter switch circuit low input	329
P1101	N—SW	Neutral position switch circuit malfunction [MT vehicles]	331
P1101	N—SWOFF	Neutral position switch circuit high input [AT vehicles]	335
P1102	BR	Pressure sources switching solenoid valve circuit low input	340
P1103	TRQ	Engine torque control signal circuit malfunction	343
P1104	TCS—LOW	TCS signal circuit low input	346

DTC No.	Abbreviation (Subaru Select Monitor)	Item	Page
P1120	ST-SWON	Starter switch circuit high input	348
P1121	N-SWON	Neutral position switch circuit low input [AT vehicles]	350
P1122	BR-HI	Pressure sources switching solenoid valve circuit high input	354
P1124	TCS-HI	TCS signal circuit high input	357
P1141	QA-RHI	Mass air flow sensor circuit range/performance problem (high input)	360
P1142	TH-RLOW	Throttle position sensor circuit range/performance problem (low input)	362
P1143	PS-RLOW	Pressure sensor circuit range/performance problem (low input)	364
P1144	PS-RHI	Pressure sensor circuit range/performance problem (high input)	368
P1400	PCVSOL-LO	Fuel tank pressure control solenoid valve circuit low input	370
P1420	PCVSOL-HI	Fuel tank pressure control solenoid valve circuit high input	374
P1421	EGRSOL-HI	Exhaust gas recirculation circuit high input	377
P1422	CPC-HI	Evaporative emission control system purge control valve circuit high input	380
P1423	VCMSOL-HI	Evaporative emission control system vent control high input	383
P1440	PCV-FLOW	Fuel tank pressure control system function problem (low input)	386
P1441	PCV-FHI	Fuel tank pressure control system function problem (high input)	390
P1442	FLVL-R2	Fuel level sensor circuit range/performance problem 2	393
P1500	FAN-1	Radiator fan relay 1 circuit low input	395
P1502	FAN-F	Radiator fan function problem	401
P1507	ISC-SHI	Idle control system malfunction (fail-safe)	403
P1520	FAN-1HI	Radiator fan relay 1 circuit high input	405
P1540	VSP-S	Vehicle speed sensor malfunction 2	407
P1700	ATTH	Throttle position sensor circuit malfunction for automatic transmission	409
P1701	ATCRS	Cruise control set signal circuit malfunction for automatic transmission	411
P1702	ATDIAG-LO	Automatic transmission diagnosis input signal circuit low input	413
P1722	ATDIAG-HI	Automatic transmission diagnosis input signal circuit high input	416
P1742	ATDIAG-2	Automatic transmission diagnosis input signal circuit malfunction	419

OBD (FB1)  
 P0101 <QA\_RLOW>  
 B2M1056

**B: DTC P0101  
 — MASS AIR FLOW SENSOR CIRCUIT  
 RANGE/PERFORMANCE PROBLEM  
 (LOW INPUT) —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**WIRING DIAGRAM:**



B2M1057

**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10B1****CHECK DTC P0102 OR P0103 ON DISPLAY.**

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0102 or P0103?*

**YES** : Inspect DTC P0102 or P0103 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0101.

**NO** : Replace mass air flow sensor.

OBD (FB1)  
 P0102 <QA\_LOW>  
 B2M1058

**C: DTC P0102**  
**— MASS AIR FLOW SENSOR CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance


**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>



10C1

**CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Start engine.

5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F06**

- F06: Mass air flow and voltage input from mass air flow sensor are shown on display at the same time.

**CHECK** : *Is the value equal to or more than 1.3 g/sec or 0.3 V and equal to or less than 250 g/sec or 5.0 V in function mode F06?*

Probable cause: Poor connect of connectors, circuit and grounding line.

**YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the mass air flow sensor.

**NOTE:**

In this case, repair the following:


- Open or ground short circuit in harness between mass air flow sensor and ECM connector
- Poor contact in mass air flow sensor or ECM connector

**NO** : Go to step **10C2**.

QA ( F06 )

1 . 67g / s 2 . 02V

B2M0481

**10C2**


**CHECK INPUT SIGNAL FOR ECM.  
(USING VOLTAGE METER AND SUBARU  
SELECT MONITOR.)**

Measure voltage between ECM connector and chassis ground while engine is idling.

**CHECK** : **Connector & terminal  
(B84) No. 5 (+) — Chassis ground (-):  
Is the voltage less than 0.3 V?**

**YES** : Go to step **10C3**.

**NO** : Go to next **CHECK** .




**CHECK** : **Does the voltage change more than 0.3 V by  
shaking harness and connector of ECM  
while monitoring the value with Subaru  
select monitor?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**10C3**

**CHECK POWER SUPPLY TO MASS AIR  
FLOW SENSOR.**


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from mass air flow sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between mass air flow sensor connector and engine ground.

**CHECK** : **Connector & terminal  
(B3) No. 1 (+) — Engine ground (-):  
Is the voltage more than 10 V?**

**YES** : Go to step **10C4**.

**NO** : Repair open circuit in harness between main relay and mass air flow sensor connector.





**10C4 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and mass air flow sensor connector.

**CHECK** : **Connector & terminal (B84) No. 5 — (B3) No. 4:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and mass air flow sensor connector
- Poor contact in mass air flow sensor connector
- Poor contact in ECM connector

**CHECK** : **Connector & terminal (B84) No. 53 — (B3) No. 3:**  
**Is the resistance less than 1 Ω?**


**YES** : Go to step 10C5.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and mass air flow sensor connector
- Poor contact in mass air flow sensor connector
- Poor contact in ECM connector



**10C5 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.**

Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 5 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Replace mass air flow sensor.

**NO** : Repair ground short circuit in harness between ECM and mass air flow sensor connector.

OBD (FB1)  
 P0103 <QA\_HI>  
 B2M1061

**D: DTC P0103  
 — MASS AIR FLOW SENSOR CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**WIRING DIAGRAM:**




B2M1057

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>



**10D1**      **CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Start engine.

QA                      ( F06 )

1 . 67g / s      2 . 02V

B2M0481

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F06**

- F06: Mass air flow and voltage input from mass air flow sensor are shown on display at the same time.

**CHECK** : *Is the value equal to or more than 1.3 g/sec or 0.3 V and equal to or less than 250 g/sec or 5.0 V in function mode F06?*

Probable cause: Poor connect of connectors, circuit and grounding line.

**YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**NO** : Go to step **10D2**.

QA	( F06 )
1 . 67g / s	2 . 02V
B2M0481	

10D2

**CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.
- 2) Disconnect connector from mass air flow sensor.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Read data on Subaru select monitor or OBD-II general scan tool.

- Subaru Select Monitor
- Designate mode using function key.

**Function mode: F06**

**CHECK** : *Is the value more than 250 g/sec or 5 V in function mode F06?*

**YES** : Repair battery short circuit in harness between mass air flow sensor and ECM connector. After repair, replace ECM.

**NO** : Replace mass air flow sensor.

- OBD-II general scan tool


For detailed operation procedures, refer to OBD-II General Scan Tool Instruction Manual.

OBD (FB1)  
 P0106 <PS\_R2>  
 B2M1062

**E: DTC P0106**  
**— PRESSURE SENSOR CIRCUIT**  
**RANGE/PERFORMANCE PROBLEM —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10E1</b>	<b>CHECK DTC P0107, P0108, P1102 OR P1122 ON DISPLAY.</b>
-------------	---


**CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0107, P0108, P1102 OR P1122?

**YES** : Inspect DTC P0107, P0108, P1102 OR P1122 using "10. Diagnostics Chart with Trouble Code".  
<Ref. to 2-7 [T10A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0106.

**NO** : Go to step **10E2**.



<b>10E2</b>	<b>CHECK DATA FOR CONTROL.</b>
-------------	--------------------------------

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch ON and Subaru Select Monitor or the OBD-II general scan tool switch ON.
- 4) Start engine.

5) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F21 and F20**

- F21: Display shows pressure signal value sent from the pressure sensor.
- F20: Display shows pressure signal value sent from the pressure sensor.

**CHECK** : Is the value more than 85 kPa in function mode F21?

**YES** : Go to step **10E3**.

**NO** : Go to next **CHECK** .

MANI.P (F 2 1)

29kPa218mmHg

B2M0756

BARO. P (F 20)

100kPa752mmHg

B2M0755


- CHECK** : Is the value less than 32 kPa in function mode F20?
- YES** : Go to step 10E4.
- NO** : Go to next **CHECK** .

BARO. P (F 20)

100kPa752mmHg

B2M0755

- CHECK** : Is the value more than 133 kPa in function mode F20?
- YES** : Replace pressure sensor.
- NO** : Repair poor contact in pressure sensor connector, pressure sources switching solenoid valve connector, and ECM connector.
- OBD-II general scan tool
- For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



**10E3** | **CHECK VACUUM HOSE.**



- CHECK** : Is there a fault in vacuum hose?


NOTE:

Check the following items.

- Disconnection of the vacuum hose from pressure sources switching solenoid valve to intake manifold
- Holes in the vacuum hose between pressure sources switching solenoid valve to intake manifold
- Clogging of the vacuum hose between pressure sources switching solenoid valve to intake manifold
- Disconnection of the vacuum hose from pressure sensor to pressure sources switching solenoid valve
- Holes in the vacuum hose between pressure sensor and pressure sources switching solenoid valve
- Clogging of the vacuum hose between pressure sensor and pressure sources switching solenoid valve
- Clogging of the filter

- YES** : Repair or replace hoses or filter.
- NO** : Go to step 10E4.





10E4

**CHECK PRESSURE SOURCES SWITCHING SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.
- 3) Turn ignition switch to ON.

**CHECK** : **Does pressure sources switching solenoid valve produce operating sound? (ON ↔ OFF each 1.5 sec.)**

**NOTE:**

Pressure sources switching solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD10). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Replace pressure sensor.

**NO** : Replace pressure sources switching solenoid valve.




OBD (FB1)  
 P0107 <P\_SLOW>  
 B2M1064



**F: DTC P0107  
 — PRESSURE SENSOR CIRCUIT LOW  
 INPUT —**

- DTC DETECTING CONDITION:**
- Immediately at fault recognition

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



10F1

**CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Start engine.

5) Read the data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F21**

- F21: Display shows pressure signal value sent from pressure sensor.


**CHECK** : *Is the value less than 0 kPa in function mode F21?*

**YES** : Go to step 10F2.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



10F2


**CHECK INPUT SIGNAL FOR ECM. (USING VOLTAGE METER AND SUBARU SELECT MONITOR.)**

- 1) Measure voltage between ECM connector and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 21 (+) — Chassis ground (-): Is the voltage more than 4.5 V?*

**YES** : Go to next step 2).

**NO** : Go to next **CHECK** .




**CHECK** : Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 26 (+) — Chassis ground (-): Is the voltage less than 0.2 V?**

**YES** : Go to step 10F3.

**NO** : Go to next step 3).



3) Read data on Subaru Select Monitor.

- Subaru Select Monitor Designate mode using function key.


**Function mode: F20**

- F20: Display shows pressure signal value sent from pressure sensor.

**CHECK** : Does the value change more than 0 kPa by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?

**YES** : Repair poor contact in ECM connector.

**NO** : Go to step 10F3.




**10F3 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between pressure sensor connector and engine ground.

**CHECK** : **Connector & terminal**  
**(B2) No. 3 (+) — Engine ground (-):**  
**Is the voltage more than 4.5 V?**

**YES** : Go to next step 5).

**NO** : Repair open circuit in harness between ECM and pressure sensor connector.




5) Turn ignition switch to OFF.  
 6) Disconnect connector from ECM.  
 7) Measure resistance of harness between ECM and pressure sensor connector.

**CHECK** : **Connector & terminal**  
**(B84) No. 20 — (B2) No. 1:**  
**Is the resistance less than 1  $\Omega$ ?**

**YES** : Go to next step 8).

**NO** : Repair open circuit in harness between ECM and pressure sensor connector.



8) Measure resistance of harness between pressure sensor connector and engine ground.

**CHECK** : **Connector & terminal**  
**(B2) No. 2 — Engine ground:**  
**Is the resistance more than 500 k $\Omega$ ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between ECM and pressure sensor connector.

**CHECK** : **Is there poor contact in pressure sensor connector?**

**YES** : Repair poor contact in pressure sensor connector.


**NO** : Replace pressure sensor.

OBD (FB1)  
 P0108 <P\_SHI>  
 B2M1066



**G: DTC P0108**  
**— PRESSURE SENSOR CIRCUIT HIGH INPUT —**

- DTC DETECTING CONDITION:**
- Immediately at fault recognition

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10G1**
**CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Start engine.

5) Read the data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F21**

- F21: Display shows pressure signal value sent from pressure sensor.


**CHECK** : *Is the value more than 140 kPa in function mode F21?*

**YES** : Go to step **10G4**.

**NO** : Go to step **10G2**.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


**10G2**
**CHECK INPUT SIGNAL FOR ECM. (USING VOLTAGE METER AND SUBARU SELECT MONITOR.)**

- 1) Measure voltage between ECM connector and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 21 (+) — Chassis ground (-): Is the voltage more than 4.5 V?*

**YES** : Go to next step 2).

**NO** : Go to next **CHECK** .




**CHECK** : Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 26 (+) — Chassis ground (-): Is the voltage less than 0.2 V?**

**YES** : Go to step 10G3.

**NO** : Go to next step 3).



3) Read data on Subaru Select Monitor.

- Subaru Select Monitor Designate mode using function key.


**Function mode: F20**

- F20: Display shows pressure signal value sent from pressure sensor.

**CHECK** : Does the value change more than 0 kPa by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?

**YES** : Repair poor contact in ECM connector.

**NO** : Go to step 10G3.


**10G3****CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between pressure sensor connector and engine ground.

**CHECK** : **Connector & terminal (B2) No. 3 (+) — Engine ground (-): Is the voltage more than 4.5 V?**

**YES** : Go to next step 5).

**NO** : Repair open circuit in harness between ECM and pressure sensor connector.



- 5) Turn ignition switch to OFF.
- 6) Disconnect connector from ECM.
- 7) Measure resistance of harness between ECM and pressure sensor connector.

**CHECK** : **Connector & terminal (B84) No. 26 — (B2) No. 2: Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between ECM and pressure sensor connector.

**CHECK** : **Connector & terminal (B84) No. 20 — (B2) No. 1: Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between ECM and pressure sensor connector.

**CHECK** : **Is there poor contact in pressure sensor connector?**

**YES** : Repair poor contact in pressure sensor connector.

**NO** : Replace pressure sensor.



MANI.P (F 2 1)

29kPa218mmHg

B2M0756

10G4

**CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.
- 2) Disconnect connector from pressure sensor.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Read data on Subaru select monitor or the OBD-II general scan tool.

- Subaru Select Monitor

Designate mode using function key.

**Function mode: F21**

**CHECK** : **Is the value more than 140 kPa in function mode F21?**

**YES** : Repair battery short circuit in harness between ECM and pressure sensor connector.

**NO** : Replace pressure sensor.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

OBD (FB1)  
 P0116 <TW\_LOW>  
 B2M1067

**H: DTC P0116**  
**— ENGINE COOLANT TEMPERATURE**  
**SENSOR CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition


**TROUBLE SYMPTOM:**

- Hard to start
- Erroneous idling
- Poor driving performance

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10H1**      **CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

TW	( F04 )
80 ° C	176 ° F

B2M0479

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F04**

- F04: Water temperature is indicated in “°C” and “°F”.

**CHECK** : *Is the value greater than 150°C or 300°F in function mode F04?*

**YES** : Go to step **10H2**.


**NO** : Repair poor contact.

**NOTE:**

In this case, repair the following:


- Poor contact in engine coolant temperature sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



**10H2**      **CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove idle air control solenoid valve by-pass air hose.
- 3) Disconnect connector from engine coolant temperature sensor.



- 4) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 5) Turn ignition switch and Subaru Select Monitor or OBD-II general scan tool switch to ON.

TW	( F04 )
80 ° C	176 ° F
B2M0479	

6) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F04**

- F04: Water temperature is indicated in “°C” and “°F”.

**CHECK** : *Is the value less than -40°C or -40°F in function mode F04?*

**YES** : Replace engine coolant temperature sensor.

**NO** : Repair ground short circuit in harness between engine coolant temperature sensor and ECM connector.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


OBD (FB1)  
 P0117 <TW\_HI>  
 B2M1068

**I: DTC P0117**  
**— ENGINE COOLANT TEMPERATURE**  
**SENSOR CIRCUIT HIGH INPUT —**



**DTC DETECTING CONDITION:**  
 ● Immediately at fault recognition

**TROUBLE SYMPTOM:**  
 ● Hard to start  
 ● Erroneous idling  
 ● Poor driving performance

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



1011

### CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

#### Function mode: F04

- F04: Water temperature is indicated in "°C" and "°F".

**CHECK** : Is the value less than  $-40^{\circ}\text{C}$  or  $-40^{\circ}\text{F}$  in function mode F04?

**YES** : Go to step 1013.


**NO** : Repair poor contact.

#### NOTE:

In this case, repair the following:

- Poor contact in engine coolant temperature sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



1012

### CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.


- 1) Turn ignition switch to OFF.
- 2) Remove idle air control solenoid valve by-pass air hose.
- 3) Disconnect connector from engine coolant temperature sensor.


- 4) Measure voltage between engine coolant temperature sensor connector and engine ground.

**CHECK** : **Connector & terminal (E8) No. 1 (+) — Engine ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.

**NO** : Go to next step 5).






- 5) Turn ignition switch to ON.
- 6) Measure voltage between engine coolant temperature sensor connector and engine ground.

**CHECK** : **Connector & terminal (E8) No. 1 (+) — Engine ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.

**NO** : Go to step 10I3.



**10I3 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Measure voltage between engine coolant temperature sensor connector and engine ground.

**CHECK** : **Connector & terminal (E8) No. 1 (+) — Engine ground (-): Is the voltage more than 4 V?**


**YES** : Go to next step 2).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and engine coolant temperature sensor connector
- Poor contact in engine coolant temperature sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)



- 2) Turn ignition switch to OFF.
- 3) Measure resistance of harness between engine coolant temperature sensor connector and engine ground.

**CHECK** : **Connector & terminal (E8) No. 2 — Engine ground: Is the resistance less than 5 Ω?**

**YES** : Replace engine coolant temperature sensor.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and engine coolant temperature sensor connector
- Poor contact in engine coolant temperature sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

OBD (FB1)  
 P0121 <TH\_RHI>  
 B2M1069

**J: DTC P0121**  
**— THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10J1****CHECK DTC P0122 OR P0123 ON DISPLAY.****CHECK****: Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0122 or P0123?****YES****: Inspect DTC P0122 or P0123 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>****NOTE:****In this case, it is not necessary to inspect DTC P0121.****NO****: Replace throttle position sensor.**


OBD (FB1)  
 P0122 <THV\_LOW>  
 B2M1070

**K: DTC P0122**  
**— THROTTLE POSITION SENSOR CIRCUIT**  
**LOW INPUT —**


- DTC DETECTING CONDITION:**
- Immediately at fault recognition

- TROUBLE SYMPTOM:**
- Erroneous idling
  - Engine stalls.
  - Poor driving performance

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10K1**      **CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

THV                      ( F07 )

0% 0.21V

B2M0482

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor Designate mode using function key.

**Function mode: F07**

- F07: Throttle position sensor output signal is indicated.

**CHECK** : **Is the value less than 0.1 V in function mode F07?**

**YES** : Go to step **10G2**.


**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.

**NOTE:**

In this case, repair the following:

- Poor contact in throttle position sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



10K2

**CHECK INPUT SIGNAL FOR ECM.  
(USING VOLTAGE METER AND SUBARU  
SELECT MONITOR.)**

1) Measure voltage between ECM connector and chassis ground while throttle valve is fully closed.

**CHECK** : **Connector & terminal  
(B84) No. 21 (+) — Chassis ground (-):  
Is the voltage more than 4.5 V?**

**YES** : Go to next step 2).

**NO** : Go to next **CHECK** .


**CHECK** : **Does the voltage change more than 4.5 V by  
shaking harness and connector of ECM  
while monitoring the value with voltage  
meter?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



2) Measure voltage between ECM connector and chassis ground.

**CHECK** : **Connector & terminal  
(B84) No. 6 (+) — Chassis ground (-):  
Is the voltage less than 0.1 V?**

**YES** : Go to step 10K3.

**NO** : Go to next **CHECK** .

**CHECK** : **Does the voltage change more than 0.1 V by  
shaking harness and connector of ECM  
while monitoring the value with Subaru  
select monitor?**


**YES** : Repair poor contact in ECM connector.

**NO** : Go to step 10K3.

THV (F07)

0% 0.21V

B2M0482



**10K3**      **CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from throttle position sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between throttle position sensor connector and engine ground.

**CHECK** : **Connector & terminal (E13) No. 3 (+) — Engine ground (-): Is the voltage more than 4.5 V?**


**YES** : Go to next step 5).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between throttle position sensor and ECM connector
- Poor contact in throttle position sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)



- 5) Turn ignition switch to OFF.
- 6) Measure resistance of harness between ECM connector and throttle position sensor connector.

**CHECK** : **Connector & terminal (B84) No. 6 — (E13) No. 2: Is the resistance less than 1 Ω?**


**YES** : Go to next step 7).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between throttle position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in throttle position sensor connector
- Poor contact in coupling connector (B21)



7) Measure resistance of harness between throttle position sensor connector and engine ground.

**CHECK** : **Connector & terminal (E13) No. 2 — Engine ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between throttle position sensor and ECM connector.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in throttle position sensor connector?**

**YES** : Repair poor contact in throttle position sensor connector.

**NO** : Replace throttle position sensor.


OBD (FB1)  
 P0123 <THV\_HI>  
 B2M1071

**L: DTC P0123**  
**— THROTTLE POSITION SENSOR CIRCUIT**  
**HIGH INPUT —**



**DTC DETECTING CONDITION:**  
 ● Immediately at fault recognition

**TROUBLE SYMPTOM:**  
 ● Erroneous idling  
 ● Engine stalls.  
 ● Poor driving performance

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10L1**
**CONNECT SUBARU SELECT MONITOR  
OR THE OBD-II GENERAL SCAN TOOL,  
AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F07**

- F07: Throttle position sensor output signal is indicated.

**CHECK** : **Is the value more than 4.9 V in function mode F07?**

**YES** : Go to step **10L2**.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.


**NOTE:**

In this case, repair the following:

- Poor contact in throttle position sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.





10L2


**CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND BODY CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from throttle position sensor.
- 3) Measure resistance of harness between throttle position sensor connector and engine ground.

**CHECK** : **Connector & terminal (E13) No. 1 — Engine ground: Is the resistance less than 5 Ω?**

**YES** : Go to next step 4).

**NO** : Repair open circuit in harness between throttle position sensor and ECM connector.



- 4) Turn ignition switch to ON.
- 5) Measure voltage between throttle position sensor connector and engine ground.

**CHECK** : **Connector & terminal (E13) No. 2 (+) — Engine ground (-): Is the voltage more than 4.9 V?**

**YES** : Repair battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace ECM.

**NO** : Replace throttle position sensor.

OBD	(FB1)
P0125	<TW_CL>
OBD0191	

**M: DTC P0125**  
**— INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Engine would not return to idling.

**WIRING DIAGRAM:**



B2M0539

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

**10M1****CHECK DTC P0116 OR P0117 ON DISPLAY.****CHECK****: Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0116 or P0117?****YES****: Inspect DTC P0116 or P0117 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>****NOTE:****In this case, it is not necessary to inspect DTC P0125.****NO****: Replace engine coolant temperature sensor.**

OBD (FB1)

P0130 <FO2\_V>


OBD0199

**N: DTC P0130  
— FRONT OXYGEN SENSOR CIRCUIT  
MALFUNCTION —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M1072

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10N1</b>	<b>CHECK FOR OTHER CAUSES AFFECTING EXHAUST GAS.</b>
-------------	--


**CHECK** : *Is CO % more than 2 % after engine warm-up?*

**YES** : Check fuel system.

NOTE:

- Check for use of improper fuel.
- Check if engine oil or coolant level is extremely low.

**NO** : Go to step **10N2**.



<b>10N2</b>	<b>CHECK FRONT OXYGEN SENSOR DATA.</b>
-------------	--

- 1) Turn ignition switch to OFF.
- 2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Start engine and Turn the Subaru Select Monitor and the OBD-II general scan tool switch to ON.
- 4) Warm-up the engine until coolant temperature is above 70°C (160°F) and keep the engine speed at 2,000 rpm to 3,000 rpm for one minute.

5) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor Designate mode using function key.

**Function mode: F12**

- F12: Front oxygen sensor max. and min. output signals are indicated at the same time.

**CHECK** : *Is the difference of voltage less than 0.1 V between the value of max. output and min. output with function mode F12?*

**YES** : Go to step **10N3**.


**NO** : Replace front oxygen sensor.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

<b>O2max - min ( F12 )</b>	
<b>0 . 80V</b>	<b>0 . 10V</b>

B2M0487

**10N3****CHECK HARNESS BETWEEN FRONT OXYGEN SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from front oxygen sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between front oxygen sensor harness connector and engine ground.

**CHECK** : **Connector & terminal (B18) No. 3 (+) — Engine ground (-): Is the voltage more than 0.2 V?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and front oxygen sensor connector
- Poor contact in the ECM connector

**CHECK** : **Is there poor contact in front oxygen sensor connector?**

**YES** : Repair poor contact in front oxygen sensor connector.

**NO** : Replace front oxygen sensor.


OBD	(FB1)
P0133	<FO2_R>
OBD0209	

**O: DTC P0133**  
**— FRONT OXYGEN SENSOR CIRCUIT SLOW RESPONSE —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M1072

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>1001</b>	<b>CHECK DTC P0130 ON DISPLAY.</b>
-------------	------------------------------------

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0130?*

**YES** : Inspect DTC P0130 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0133.

**NO** : Go to step **1002**.

<b>1002</b>	<b>CHECK EXHAUST SYSTEM.</b>
-------------	------------------------------

**CHECK** : *Is there a fault in exhaust system?*

NOTE:

Check the following items.

- Loose installation of front portion of exhaust pipe onto cylinder heads
- Loose connection between front exhaust pipe and front catalytic converter
- Damage of exhaust pipe resulting in a hole

**YES** : Repair exhaust system.

**NO** : Replace front oxygen sensor.



OBD (FB1)


P0135 <FO2H>

OBD0212

**P: DTC P0135**  
**— FRONT OXYGEN SENSOR HEATER**  
**CIRCUIT MALFUNCTION —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**




**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10P1</b>	<b>CHECK DTC P0141 ON DISPLAY.</b>
-------------	------------------------------------

**CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0135 and P0141 at the same time?

**YES** : Go to next step 1).

**NO** : Go to step **10P2**.



- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 42 — Chassis ground: Is the resistance less than 5 Ω?**


**YES** : Repair poor contact in ECM connector.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and coupling connector (B22)
- Open circuit in harness between coupling connector (B22) and engine grounding terminal
- Poor contact in front oxygen sensor connector
- Poor contact in coupling connector (B22)



<b>10P2</b>	<b>CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b>
-------------	--

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

FO2H ( F32 )

1 . 00 A

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

● Subaru Select Monitor  
Designate mode using function key.

**Function mode: F32**

- F32: Front oxygen sensor heater current is indicated.

**CHECK** : Is the value more than 0.2 A in function mode F32?

**YES** : Repair connector.

B2M0497

NOTE:


In this case, repair the following:

- Poor contact in front oxygen sensor connector
- Poor contact in ECM connector

**(NO)** : Go to step **10P3**.

- OBD-II scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



**10P3**    **CHECK OUTPUT SIGNAL FROM ECM. (USING VOLTAGE METER.)**

- 1) Start and idle the engine.
- 2) Measure voltage between ECM connector and chassis ground.

**(CHECK)** : **Connector & terminal (B84) No. 38 (+) — Chassis ground (-): Is the voltage less than 1.0 V?**


**(YES)** : Go to step **10P4**.

**(NO)** : Go to next **(CHECK)** .

**(CHECK)** : **Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**

**(YES)** : Repair poor contact in ECM connector.

**(NO)** : Go to next step 3).




- 3) Disconnect connector from front oxygen sensor.
- 4) Measure voltage between ECM connector and chassis ground.

**(CHECK)** : **Connector & terminal (B84) No. 38 (+) — Chassis ground (-): Is the voltage less than 1.0 V?**

**(YES)** : Replace ECM.

**(NO)** : Repair battery short circuit in harness between ECM and front oxygen sensor connector. After repair, replace ECM.



**10P4**    **CHECK POWER SUPPLY TO FRONT OXYGEN SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from front oxygen sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between front oxygen sensor connector and engine ground.

**(CHECK)** : **Connector & terminal (B18) No. 2 (+) — Engine ground (-): Is the voltage more than 10 V?**


**YES** : Go to step **10P5**.

**NO** : Repair power supply line.

NOTE:

In this case, repair the following:

- Open circuit in harness between main relay and front oxygen sensor connector
- Poor contact in front oxygen sensor connector
- Poor contact in main relay connector



<b>10P5</b>	<b>CHECK FRONT OXYGEN SENSOR.</b>
-------------	-----------------------------------

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between front oxygen sensor connector terminals.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
**Is the resistance less than 30 Ω?**

**YES** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between front oxygen sensor and ECM connector
- Poor contact in front oxygen sensor connector
- Poor contact in ECM connector

**NO** : Replace front oxygen sensor.

OBD (FB1)


P0136 <RO2\_V>

OBD0220

**Q: DTC P0136**  
**— REAR OXYGEN SENSOR CIRCUIT MALFUNCTION —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M1077

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10Q1</b>	<b>CHECK DTC P0130 ON DISPLAY.</b>
-------------	------------------------------------

**CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0130?

**YES** : Go to step 10Q2.

**NO** : Go to step 10Q3.

<b>10Q2</b>	<b>CHECK FAILURE CAUSE OF P0130.</b>
-------------	--------------------------------------

Perform the step 1 of DTC P0130.


**CHECK** : Is the failure cause of P0130 in the fuel system?

**YES** : Check fuel system.

NOTE:

In this case, it is not necessary to inspect DTC P0136.

**NO** : Go to step 10Q3.



<b>10Q3</b>	<b>CHECK REAR OXYGEN SENSOR DATA.</b>
-------------	---------------------------------------

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or OBD-II general scan tool to data link connector.
- 3) Start the engine, and turn Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Warm-up the engine until engine coolant temperature is above 70°C (160°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for two minutes.

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F13**

- F13: Rear oxygen sensor output signal is indicated.

**CHECK** : Does the value fluctuate in function mode F13?

**YES** : Go to step 10Q5.

**NO** : Go to next **CHECK** .

RO2 ( F13 )

0 . 60 V


B2M0488

RO2 ( F13 )

0 . 60 V

B2M0488

- CHECK** : *Is the value fixed between 0.2 and 0.4 V in function mode F13?*
- YES** : Go to step 10Q4.
- NO** : Replace rear oxygen sensor.
- OBD-II general scan tool
- For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



**10Q4 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from rear oxygen sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between rear oxygen sensor harness connector and engine ground or chassis ground.

- CHECK** : **Connector & terminal**
- **2200 cc California spec. vehicles (B19) No. 4 (+) — Engine ground (-):**
  - **Except 2200 cc California spec. vehicles (T6) No. 4 (+) — Chassis ground (-):**
- Is the voltage more than 0.2 V?*

- YES** : Replace rear oxygen sensor.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between rear oxygen sensor and ECM connector
- Poor contact in rear oxygen sensor connector
- Poor contact in ECM connector
- Poor contact in rear oxygen sensor connecting harness connector (Except 2200 cc California spec. vehicles)

**10Q5 CHECK EXHAUST SYSTEM.**

- CHECK** : *Is there a fault in exhaust system?*

**NOTE:**

Check the following items.

- Loose installation of portions
- Damage (crack, hole etc.) of parts
- Looseness and ill fitting of parts between front oxygen sensor and rear oxygen sensor


- YES** : Repair or replace faulty parts.
- NO** : Replace rear oxygen sensor.

OBD	(FB1)
P0139	<RO2_R>
OBD0229	

**R: DTC P0139**  
**— REAR OXYGEN SENSOR CIRCUIT SLOW RESPONSE —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M1077

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



10R1	CHECK DTC P0136 ON DISPLAY.
------	-----------------------------

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0136?*

**YES** : Inspect DTC P0136 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0139.


**NO** : Replace rear oxygen sensor.

OBD	(FB1)
P0141	<RO2H>
OBD0232	

**S: DTC P0141**  
**— REAR OXYGEN SENSOR HEATER**  
**CIRCUIT MALFUNCTION —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M1078


**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10S1</b>	<b>CHECK DTC P0135 ON DISPLAY.</b>
-------------	------------------------------------

**CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0141 and P0135 at the same time?

**YES** : Go to next step 1).

**NO** : Go to step **10S2**.



- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 42 — Chassis ground: Is the resistance less than 5 Ω?**


**YES** : Repair poor contact in ECM connector.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and coupling connector (B22)
- Open circuit in harness between coupling connector (B22) and engine grounding terminal
- Poor contact in rear oxygen sensor connector
- Poor contact in rear oxygen sensor connecting harness connector (B19)
- Poor contact in coupling connector (B22)



<b>10S2</b>	<b>CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b>
-------------	--

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

RO2H	( F33 )
1.00 A	

B2M0498

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.
  - Subaru Select Monitor Designate mode using function key.

**Function mode: F33**

- F33: Rear oxygen sensor heater current is indicated.

**CHECK** : Is the value more than 0.2 A in function mode F33?

**YES** : Repair connector.

## NOTE:


In this case, repair the following:

- Poor contact in rear oxygen sensor connector
- Poor contact in rear oxygen sensor connecting harness connector
- Poor contact in ECM connector

**(NO)** : Go to step **10S3**.

- OBD-II scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**10S3****CHECK OUTPUT SIGNAL FROM ECM.  
(USING VOLTAGE METER.)**

- 1) Start and idle the engine.
- 2) Measure voltage between ECM connector and chassis ground.

**(CHECK)** : **Connector & terminal (B84) No. 37 (+) — Chassis ground (-): Is the voltage less than 1.0 V?**


**(YES)** : Go to step **10S4**.

**(NO)** : Go to next **(CHECK)** .

**(CHECK)** : **Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**

**(YES)** : Repair poor contact in ECM connector.

**(NO)** : Go to next step 3).




- 3) Disconnect connector from rear oxygen sensor.
- 4) Measure voltage between ECM connector and chassis ground.

**(CHECK)** : **Connector & terminal (B84) No. 37 (+) — Chassis ground (-): Is the voltage less than 1.0 V?**

**(YES)** : Replace ECM.

**(NO)** : Repair battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace ECM.

**10S4****CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from rear oxygen sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between rear oxygen sensor connector and engine ground or chassis ground.

**(CHECK)** : **Connector & terminal ● 2200 cc California spec. vehicles (B19) No. 2 (+) — Engine ground (-):**

- **Except 2200 cc California spec. vehicles (T6) No. 2 (+) — Chassis ground (-):**  
**Is the voltage more than 10 V?**


**YES** : Go to step 10S5.

**NO** : Repair power supply line.

NOTE:

In this case, repair the following:

- Open circuit in harness between main relay and rear oxygen sensor connector
- Poor contact in rear oxygen sensor connector
- Poor contact in rear oxygen sensor connecting harness connector (Except 2200 cc California spec. vehicles)



**10S5**

**CHECK REAR OXYGEN SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between rear oxygen sensor connector terminals.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
**Is the resistance less than 30 Ω?**

**YES** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between rear oxygen sensor and ECM connector
- Poor contact in rear oxygen sensor connector
- Poor contact in ECM connector
- Poor contact in rear oxygen sensor connecting harness connector

**NO** : Replace rear oxygen sensor.

OBD	(FB1)
P0170	<FUEL>
OBD0240	

**T: DTC P0170**  
**— FUEL TRIM MALFUNCTION —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODE**.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10T1</b>	<b>CHECK EXHAUST SYSTEM.</b>
-------------	------------------------------

**CHECK** : *Are there holes or loose bolts on exhaust system?*

**YES** : Repair exhaust system.


**NO** : Go to step **10T2**.

<b>10T2</b>	<b>CHECK AIR INTAKE SYSTEM.</b>
-------------	---------------------------------

**CHECK** : *Are there holes, loose bolts or disconnection of hose on air intake system?*

**YES** : Repair air intake system.


**NO** : Go to step **10T3**.




<b>10T3</b>	<b>CHECK FUEL PRESSURE.</b>
-------------	-----------------------------

1) Release fuel pressure.


(1) Remove fuel pump access hole lid located on the right rear of trunk compartment floor (Sedan) or luggage compartment floor (Wagon).




- (2) Disconnect connector from fuel tank.
- (3) Start the engine, and run it until it stalls.
- (4) After stopping the engine, crank the engine for 5 to 7 seconds to reduce fuel pressure.
- (5) Turn ignition switch to OFF.



- 2) Connect connector to fuel tank.



- 3) Disconnect fuel delivery hose from fuel filter, and connect fuel pressure gauge.



- 4) Start the engine and idle while gear position is neutral.
- 5) Measure fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold.

**CHECK** : *Is fuel pressure between 226 and 275 kPa (2.3 — 2.8 kg/cm<sup>2</sup>, 33 — 40 psi)?*

**YES** : Go to next step 6).

**NO** : Repair the following items.

Fuel pressure too high	<ul style="list-style-type: none"> <li>● Clogged fuel return line or bent hose</li> </ul>
Fuel pressure too low	<ul style="list-style-type: none"> <li>● Improper fuel pump discharge</li> <li>● Clogged fuel supply line</li> </ul>

6) After connecting pressure regulator vacuum hose, measure fuel pressure.

**CHECK** : Is fuel pressure between 157 and 206 kPa (1.6 — 2.1 kg/cm<sup>2</sup>, 23 — 30 psi)?

**YES** : Go to step 10T4.

**NO** : Repair the following items.


Fuel pressure too high	<ul style="list-style-type: none"> <li>● Faulty pressure regulator</li> <li>● Clogged fuel return line or bent hose</li> </ul>
Fuel pressure too low	<ul style="list-style-type: none"> <li>● Faulty pressure regulator</li> <li>● Improper fuel pump discharge</li> <li>● Clogged fuel supply line</li> </ul>

**WARNING:**

**Before removing fuel pressure gauge, release fuel pressure.**

**NOTE:**

- If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.
- If out of specification as measured at this step, check or replace pressure regulator and pressure regulator vacuum hose.



<b>10T4</b>	<p><b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b>  <b>&lt;REF. TO 2-7 H: DTC P0116 [T10H0] OR I: DTC P0117 [T10I0].&gt;</b></p>
-------------	--

- 1) Turn ignition switch to OFF.
- 2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Start the engine and warm-up completely.



<p>TW</p>  <p>80 ° C    176 ° F</p>	<p>( F04 )</p>
---	----------------

B2M0479

4) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F04**

- F04: Water temperature is indicated in “°C” and “°F”.


**CHECK** : *Is temperature greater than 60°C or 140°F in function mode F04?*

**YES** : Go to step **10T5**.

**NO** : Replace engine coolant temperature sensor.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



<b>10T5</b>	<b>CHECK MASS AIR FLOW SENSOR.</b>
-------------	------------------------------------

- 1) Turn ignition switch to OFF.
- 2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).
- 4) Place the selector lever in “N” or “P” position.
- 5) Turn A/C switch to OFF.
- 6) Turn all accessory switches to OFF.

QA ( F06 )

1 . 67g / s      2 . 02V

B2M0481

7) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F06**

- F06: Mass air flow and voltage input from mass air flow sensor are shown on display.

**CHECK** : *Is the voltage in function mode F06 within the specifications shown in the following table?*

Model	Engine speed	Specified value
2200 cc	Idling	1.7 — 3.3 (g/sec)
	2,500 rpm	7.1 — 14.2 (g/sec)
2500 cc	Idling	2.2 — 4.2 (g/sec)
	2,500 rpm	8.6 — 14.5 (g/sec)

**YES** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**NO** : Replace mass air flow sensor.

- OBD-II general scan tool


For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

OBD (FB1)  
 P0181 <TNKT\_F>  
 H2M1350

**U: DTC P0181**  
**— FUEL TEMPERATURE SENSOR A CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10U1</b>	<b>CHECK DTC P0182 OR P0183 ON DISPLAY.</b>
-------------	---

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0182 or P0183?*

**YES** : Inspect DTC P0182 or P0183 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0181.


**NO** : Replace fuel temperature sensor.

OBD (FB1)  
 P0182 <TNKT\_LOW>  
 B2M1079

**V: DTC P0182**  
**— FUEL TEMPERATURE SENSOR A CIRCUIT**  
**LOW INPUT —**



- DTC DETECTING CONDITION:**
- Immediately at fault recognition

**WIRING DIAGRAM:**



B2M0916

**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10V1**
**CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.

- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F44**

- F44: Fuel temperature is indicated in "°C" and "°F".


**CHECK** : *Is the value greater than 150°C or 300°F in function mode F44?*

**YES** : Go to step 10V2.


**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**10V2**
**CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove access hole lid.
- 3) Disconnect connector from fuel pump.



- 4) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.

- 5) Turn ignition switch and Subaru Select Monitor or OBD-II general scan tool switch to ON.

TNKT	( F 44 )
20 ° C	68 ° F
H2M1308	

6) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F44**

- F44: Fuel temperature is indicated in "°C" and "°F".

**CHECK** : *Is the value less than -40°C or -40°F in function mode F44?*

**YES** : Replace fuel temperature sensor.

**NO** : Repair ground short circuit in harness between fuel pump and ECM connector.

- OBD-II general scan tool


For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

OBD (FB1)  
 P0183 <TNKT\_HI>  
 B2M1080

**W: DTC P0183**  
**— FUEL TEMPERATURE SENSOR A CIRCUIT HIGH INPUT —**


- DTC DETECTING CONDITION:**
- Immediately at fault recognition

**WIRING DIAGRAM:**




**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>





**10W1**     **CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 4) Start engine.



- 5) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor Designate mode using function key.

**Function mode: F44**

- F44: Fuel temperature is indicated in "°C" and "°F".

**CHECK** : *Is the value less than -40°C or -40°F in function mode F44?*

**YES** : Go to step **10W2**.


**NO** : Repair poor contact.

**NOTE:**

In this case, repair the following:


- Poor contact in fuel pump connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B22, B98 and R57)
- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.



**10W2**     **CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove access hole lid.
- 3) Disconnect connector from fuel pump.




- 4) Measure voltage between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 6 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and fuel pump connector.

**NO** : Go to next step 5).




5) Turn ignition switch to ON.

6) Measure voltage between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 6 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and fuel pump connector.

**NO** : Go to step **10W3**.



### 10W3

### CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.

1) Measure voltage between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 6 (+) — Chassis ground (-): Is the voltage more than 4 V?**


**YES** : Go to next step 2).

**NO** : Repair harness and connector.

#### NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and fuel pump connector
- Poor contact in fuel pump connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B98 and R57)



2) Turn ignition switch to OFF.

3) Measure resistance of harness between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 5 — Chassis ground: Is the resistance less than 5 Ω?**

**YES** : Replace fuel temperature sensor.

**NO** : Repair harness and connector.

#### NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and fuel pump connector
- Poor contact in fuel pump connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B22, B98 and R57)

OBD (FB1)  
 P0261 <INJ 1>  
 B2M1081

**X: DTC P0261**  
 — FUEL INJECTOR CIRCUIT LOW INPUT - #1 —

OBD (FB1)  
 P0264 <INJ 2>  
 B2M1082

**Y: DTC P0264**  
 — FUEL INJECTOR CIRCUIT LOW INPUT - #2 —

OBD (FB1)  
 P0267 <INJ 3>  
 B2M1083

**Z: DTC P0267**  
 — FUEL INJECTOR CIRCUIT LOW INPUT - #3 —

OBD (FB1)  
 P0270 <INJ 4>  
 B2M1084

**AA: DTC P0270**  
 — FUEL INJECTOR CIRCUIT LOW INPUT - #4 —


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Failure of engine to start
- Engine stalls.
- Erroneous idling
- Rough driving


**WIRING DIAGRAM:**



B2M0555

**CAUTION:**

- Check or repair only faulty cylinders.
- After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
<Ref. to 2-7 [T3D0] and [T3E0].>



**10AA1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground on faulty cylinders.

**CHECK** : **Connector & terminal**  
 #1 (B84) No. 96 (+) — Chassis ground (-):  
 #2 (B84) No. 70 (+) — Chassis ground (-):  
 #3 (B84) No. 44 (+) — Chassis ground (-):  
 #4 (B84) No. 16 (+) — Chassis ground (-):  
**Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Go to step 10AA2.


**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




**10AA2 CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel injector on faulty cylinders.
- 3) Measure voltage between ECM connector and engine ground on faulty cylinders.

**CHECK** : **Connector & terminal**  
 #1 (E5) No. 1 — Engine ground:  
 #2 (E16) No. 1 — Engine ground:  
 #3 (E6) No. 1 — Engine ground:  
 #4 (E17) No. 1 — Engine ground:  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between fuel injector and ECM connector.

**NO** : Go to next step 4).




4) Measure resistance of harness connector between ECM connector and fuel injector on faulty cylinders.

**CHECK** : **Connector & terminal**  
**#1 (B84) No. 96 — (E5) No. 1:**  
**#2 (B84) No. 70 — (E16) No. 1:**  
**#3 (B84) No. 44 — (E6) No. 1:**  
**#4 (B84) No. 16 — (E17) No. 1:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to step 10AA3.

**NO** : Repair open circuit in harness between ECM and fuel injector connector.




### 10AA3 CHECK FUEL INJECTOR.

Measure resistance between fuel injector terminals on faulty cylinder.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
**Is the resistance between 5 and 20 Ω?**

**NO** : Replace faulty fuel injector.

**YES** : Go to step 10AA4.



### 10AA4 CHECK POWER SUPPLY LINE.

1) Turn ignition switch to ON.  
 2) Measure voltage between fuel injector and engine ground on faulty cylinders.

**CHECK** : **Connector & terminal**  
**#1 (E5) No. 2 (+) — Engine ground (-):**  
**#2 (E16) No. 2 (+) — Engine ground (-):**  
**#3 (E6) No. 2 (+) — Engine ground (-):**  
**#4 (E17) No. 2 (+) — Engine ground (-):**  
**Is the voltage more than 10 V?**

**YES** : Repair poor contact in all connectors in fuel injector circuit.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between main relay and fuel injector connector on faulty cylinders
- Poor contact in main relay connector
- Poor contact in fuel injector connector on faulty cylinders

OBD (FB1)  
P0262 <INJ 1\_HI>

B2M1085

**AB: DTC P0262**  
**— FUEL INJECTOR CIRCUIT HIGH INPUT - #1 —**

OBD (FB1)  
P0265 <INJ 2\_HI>

B2M1086

**AC: DTC P0265**  
**— FUEL INJECTOR CIRCUIT HIGH INPUT - #2 —**

OBD (FB1)  
P0268 <INJ 3\_HI>

B2M1087

**AD: DTC P0268**  
**— FUEL INJECTOR CIRCUIT HIGH INPUT - #3 —**

OBD (FB1)  
P0271 <INJ 4\_HI>

B2M1088

**AE: DTC P0271**  
**— FUEL INJECTOR CIRCUIT HIGH INPUT - #4 —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Failure of engine to start
- Engine stalls.
- Erroneous idling
- Rough driving

**WIRING DIAGRAM:**




B2M0555

**CAUTION:**

- Check or repair only faulty cylinders.
  - After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.
- <Ref. to 2-7 [T3D0] and [T3E0].>






**10AE1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground on faulty cylinders.

**CHECK** : **Connector & terminal**  
 #1 (B84) No. 96 (+) — Chassis ground (-):  
 #2 (B84) No. 70 (+) — Chassis ground (-):  
 #3 (B84) No. 44 (+) — Chassis ground (-):  
 #4 (B84) No. 16 (+) — Chassis ground (-):  
**Is the voltage more than 10 V?**

- YES** : Go to step 10AE2.  
**NO** : Go to next **CHECK** .  
**CHECK** : **Is there poor contact in ECM connector?**  
**YES** : Repair poor contact in ECM connector.  
**NO** : Replace ECM.




**10AE2 CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel injector on faulty cylinder.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM connector and chassis ground on faulty cylinders.

**CHECK** : **Connector & terminal**  
 #1 (B84) No. 96 (+) — Chassis ground (-):  
 #2 (B84) No. 70 (+) — Chassis ground (-):  
 #3 (B84) No. 44 (+) — Chassis ground (-):  
 #4 (B84) No. 16 (+) — Chassis ground (-):  
**Is the voltage more than 10 V?**

- YES** : Repair battery short circuit in harness between ECM and fuel injector. After repair, replace ECM.  
**NO** : Go to next step 5).



- 5) Turn ignition switch to OFF.
- 6) Measure resistance between fuel injector terminals on faulty cylinder.

**CHECK** : **Terminals**  
**No. 1 — No. 2 :**  
**Is the resistance less than 1 Ω?**  
**YES** : Replace faulty fuel injector and ECM.  
**NO** : Go to next **CHECK** .

- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM.

OBD	(FB1)
P0301	<MIS_1>
OBD0277	

**AF: DTC P0301**  
**— CYLINDER 1 MISFIRE DETECTED —**

OBD	(FB1)
P0302	<MIS_2>
OBD0278	

**AG: DTC P0302**  
**— CYLINDER 2 MISFIRE DETECTED —**

OBD	(FB1)
P0303	<MIS_3>
OBD0279	

**AH: DTC P0303**  
**— CYLINDER 3 MISFIRE DETECTED —**

OBD	(FB1)
P0304	<MIS_4>
OBD0280	

**AI: DTC P0304**  
**— CYLINDER 4 MISFIRE DETECTED —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)

**TROUBLE SYMPTOM:**

- Engine stalls.
- Erroneous idling
- Rough driving

**WIRING DIAGRAM:**



B2M1309

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>


<b>10A11</b>	<b>CHECK DTC P0101, P0102, P0103, P0116, P0117, P0125, P0261, P0262, P0264, P0265, P0267, P0268, P0270 OR P0271 ON DISPLAY.</b>
--------------	---

**CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0101, P0102, P0103, P0116, P0117, P0125, P0261, P0262, P0264, P0265, P0267, P0268, P0270 or P0271?

**YES** : Inspect DTC P0101, P0102, P0103, P0116, P0117, P0125, P0261, P0262, P0264, P0265, P0267, P0268, P0270 or P0271 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

**NOTE:**  
In this case, it is not necessary to inspect DTC P0301, P0302, P0303 and P0304.

**NO** : Go to step **10A12**.



<b>10A12</b>	<b>CONNECT SUBARU SELECT MONITOR AND READ DATA.</b>
--------------	---

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor to the data link connector.
- 3) Turn ignition switch to ON and turn Subaru Select Monitor switch to ON.

**EGRmax-min (F4 2 )**

**1 0 0 kPa      4 kPa**


B2M0759

- 4) Read data on Subaru Select Monitor. Designate mode use function key.


**Function mode: F42**

**NOTE:**  
F42: Maximum and minimum EGR system pressure value are indicated at the same time.

- 5) Print out the displayed data on paper.



- 6) Clear memory on Subaru Select Monitor. Designate mode use function key. Press [F], [C], [0], [ENT] in that order.



7) Start engine, and drive the vehicle more than 10 minutes.

**CHECK** : *Is the MIL coming on or blinking?*

**YES** : Go to step **10AI3**.

**NO** : Go to next **CHECK** .

**CHECK** : *Has the vehicle been run empty of fuel?*

**YES** : Finish diagnostics operation, if the engine has no abnormality.

**NO** : Go to next **CHECK** .

**CHECK** : *Was the cause of misfire diagnosed when the engine is running?*

NOTE:

Ex. Remove spark plug cord, etc.

**YES** : Finish diagnostics operation, if the engine has no abnormality.

**NO** : Repair connector.

NOTE:

In this case, repair the following:

- Poor contact in ignitor connector
- Poor contact in ignition coil connector
- Poor contact in fuel injector connector on faulty cylinders
- Poor contact in ECM connector
- Poor contact in coupling connector (B22)

### 10AI3

### CHECK AIR INTAKE SYSTEM.

**CHECK** : *Is there a fault in air intake system?*


NOTE:

Check the following items:

- Are there air leaks or air suction caused by loose or dislocated nuts and bolts?
- Are there cracks or any disconnection of hoses?

**YES** : Repair air intake system.


**NO** : Go to step **10AI4**.



### 10AI4

### CHECK MISFIRE SYMPTOM.

- 1) Turn ignition switch to OFF.
- 2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch to ON, and turn Subaru Select Monitor or OBD-II general scan tool switch to ON.



4) Read diagnostic trouble code (DTC).

- Subaru Select Monitor

Designate mode use function key.

**Function mode: FB1**

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.

NOTE:

Perform diagnosis according to the items listed below.

**CHECK** : **Does the Subaru select monitor or OBD-II general scan tool indicate only one DTC?**

**YES** : Go to step 10AI5.

**NO** : Go to next **CHECK** .

**CHECK** : **Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0301 and P0302?**

**YES** : Go to step 10AI6.

**NO** : Go to next **CHECK** .

**CHECK** : **Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0303 and P0304?**

**YES** : Go to step 10AI7.

**NO** : Go to next **CHECK** .

**CHECK** : **Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0301 and P0303?**

**YES** : Go to step 10AI8.

**NO** : Go to next **CHECK** .

**CHECK** : **Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0302 and P0304?**

**YES** : Go to step 10AI9.

**NO** : Go to step 10AI10.

<b>10A15</b>	<b>ONLY ONE CYLINDER</b>
--------------	--------------------------

**CHECK** : *Is there a fault in that cylinder?*

NOTE:

Check the following items.

- Spark plug
- Spark plug cord
- Fuel injector
- Compression ratio

**YES** : Repair or replace faulty parts.

**NO** : Go to step **10A11**.

<b>10A16</b>	<b>GROUP OF #1 AND #2 CYLINDERS</b>
--------------	-------------------------------------

**CHECK** : *Are there faults in #1 and #2 cylinders?*

NOTE:

● Check the following items.

- Spark plugs
- Fuel injectors
- Ignition coil
- If no abnormal is discovered, check for “D: IGNITION CONTROL SYSTEM” of #1 and #2 cylinders side. <Ref. to 2-7 [T8D0].>

**YES** : Repair or replace faulty parts.

**NO** : Go to step **10A11**.



<b>10AI7</b>	<b>GROUP OF #3 AND #4 CYLINDERS</b>
--------------	-------------------------------------

**CHECK** : *Are there faults in #3 and #4 cylinders?*

NOTE:

- Check the following items.
  - Spark plugs
  - Fuel injectors
  - Ignition coil
- If no abnormal is discovered, check for “D: IGNITION CONTROL SYSTEM” of #3 and #4 cylinders side. <Ref. to 2-7 [T8D0].>

**YES** : Repair or replace faulty parts.

**NO** : Go to step **10AI11**.

<b>10AI8</b>	<b>GROUP OF #1 AND #3 CYLINDERS</b>
--------------	-------------------------------------

**CHECK** : *Are there faults in #1 and #3 cylinders?*

NOTE:

Check the following items.

- Spark plugs
- Fuel injectors
- Skipping timing belt teeth

**YES** : Repair or replace faulty parts.

**NO** : Go to step **10AI11**.

<b>10AI9</b>	<b>GROUP OF #2 AND #4 CYLINDERS</b>
--------------	-------------------------------------

**CHECK** : *Are there faults in #2 and #4 cylinders?*

**NOTE:**

Check the following items.

- Spark plugs
- Fuel injectors
- Skipping timing belt teeth

**YES** : Repair or replace faulty parts.

**NO** : Go to step **10AI11**.

<b>10AI10</b>	<b>THE CYLINDER AT RANDOM</b>
---------------	-------------------------------

**CHECK** : *Is the engine idle rough?*

**YES** : Go to step **10AI11**.

**NO** : Go to DTC P0170. <Ref. to 2-7 [T10T3], [T10T4] and [T10T5].>

EGRmax-min (F4 2 )

1 0 0kPa      4 kPa

B2M0759

<b>10AI11</b>	<b>CHECK EGR SYSTEM.</b>
---------------	--------------------------

**CHECK** : *Is the minimum EGR system pressure value (value of function mode (F42) less than 1 kPa?*

**NOTE:**

Use the value read in step **10X2** for function mode F42.

**YES** : Clean EGR valve.

**CAUTION:**

**Do not use solvent when cleaning EGR valve assembly, as it can damage diaphragm.**

**NOTE:**

- Remove and blow away the exhaust deposits. Make sure the valve operates smoothly and the valve seat area is completely cleaned.
- Replace EGR valve as required.

**NO** : Go to DTC P0170. <Ref. to 2-7 [T10T3], [T10T4] and [T10T5].>

OBD (FB1)

P0325 <KNOCK>

OBD0283

**AJ: DTC P0325**  
**— KNOCK SENSOR CIRCUIT**  
**MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**


- Poor driving performance
- Knocking occurs.

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>


**10AJ1****CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance between ECM harness connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 3 — Chassis ground:**  
**Is the resistance more than 700 k $\Omega$ ?**

**YES** : Go to step **10AJ2**.


**NO** : Go to next **CHECK** .



**CHECK** : **Connector & terminal (B84) No. 2 — Engine ground:**  
**Is the resistance less than 400 k $\Omega$ ?**

**YES** : Go to step **10AJ3**.

**NO** : Go to step **10AJ4**.

**10AJ2****CHECK KNOCK SENSOR.**

- 1) Disconnect connector from knock sensor.
- 2) Measure resistance between knock sensor connector terminal and engine ground.

**CHECK** : **Terminal No. 2 — Engine ground:**  
**Is the resistance more than 700 k $\Omega$ ?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between knock sensor and ECM connector
- Poor contact in knock sensor connector
- Poor contact in coupling connector (B21)

**CHECK** : **Is the knock sensor installation bolt tightened securely?**

**YES** : Replace knock sensor.

**NO** : Tighten knock sensor installation bolt securely.



**10AJ3 CHECK KNOCK SENSOR.**

- 1) Disconnect connector from knock sensor.
- 2) Measure resistance between knock sensor connector terminal and engine ground.


**CHECK** : *Terminal No. 2 — Engine ground:*  
*Is the resistance less than 400 kΩ?*

**YES** : Replace knock sensor.

**NO** : Repair ground short circuit in harness between knock sensor connector and ECM connector.

**NOTE:**

The harness between both connectors is shielded. Repair short circuit of harness together with shield.



**10AJ4 CHECK INPUT SIGNAL FOR ECM.**

- 1) Connect connectors to ECM and knock sensor.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 3 (+) — Chassis ground (-):*  
*Is the voltage more than 2 V?*

**YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)

**NOTE:**

In this case, repair the following:

- Poor contact in knock sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

**NO** : Repair poor contact in ECM connector.

<p>OBD</p>  <p>P0335</p>	<p>(FB1)</p>  <p>&lt;CRANK&gt;</p>
--------------------------------	--

OBD0292

**AK: DTC P0335**  
**— CRANKSHAFT POSITION SENSOR**  
**CIRCUIT MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Engine stalls.
- Failure of engine to start


**WIRING DIAGRAM:**



B2M1294

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10AK1 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from crankshaft position sensor.
- 3) Measure resistance of harness between crankshaft position sensor connector and engine ground.

**CHECK** : **Connector & terminal (E10) No. 1 — Engine ground: Is the resistance more than 100 kΩ?**


**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between crankshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B20)

**NO** : Go to next **CHECK** .




**CHECK** : **Connector & terminal (E10) No. 1 — Engine ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between crankshaft position sensor and ECM connector.

**NOTE:**

The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.

**NO** : Go to next **CHECK** .



**CHECK** : **Connector & terminal (E10) No. 2 — Engine ground: Is the resistance less than 5 Ω?**

**YES** : Go to step 10AK2.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between crankshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B20)


10AK2

**CHECK CRANKSHAFT POSITION SENSOR.**

**CHECK** : *Is the crankshaft position sensor installation bolt tightened securely?*

**YES** : Go to next step 1).

**NO** : Tighten crankshaft position sensor installation bolt securely.



1) Remove crankshaft position sensor.

2) Measure resistance between connector terminals of crankshaft position sensor.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
*Is the resistance between 1 and 4 kΩ?*

**YES** : Repair poor contact in crankshaft position sensor connector.

**NO** : Replace crankshaft position sensor.




OBD (FB1)  
 P0336 <CRANK\_R>  
 B2M1091

**AL: DTC P0336**  
**— CRANKSHAFT POSITION SENSOR**  
**CIRCUIT RANGE/PERFORMANCE PROBLEM**  
 —

**DTC DETECTING CONDITION:**  
 • Immediately at fault recognition

**TROUBLE SYMPTOM:**  
 • Engine stalls.  
 • Failure of engine to start

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10AL1</b>	<b>CHECK DTC P0335 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0335?*
- YES** : Inspect DTC P0335 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>
- NO** : Replace crankshaft position sensor.

OBD	(FB1)
P0340	<CAM>

OBD0304

**AM: DTC P0340**  
**— CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Engine stalls.
- Failure of engine to start


**WIRING DIAGRAM:**



B2M1055

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to 2-7 [T3D0] and [T3E0].>

**10AM1**
**CHECK HARNESS BETWEEN CAM-SHAFT POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from camshaft position sensor.
- 3) Measure resistance of harness between camshaft position sensor connector and engine ground.

**CHECK** : **Connector & terminal (E15) No. 1 — Engine ground: Is the resistance more than 100 kΩ?**


**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between camshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B20)

**NO** : Go to next **CHECK** .




**CHECK** : **Connector & terminal (E15) No. 1 — Engine ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between camshaft position sensor connector and ECM connector.

**NOTE:**

The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.

**NO** : Go to next **CHECK** .



**CHECK** : **Connector & terminal (E15) No. 2 — Engine ground:**  
**Is the resistance less than 5 Ω?**

**YES** : Go to step **10AM2**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between camshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B20)

<b>10AM2</b>	<b>CHECK CAMSHAFT POSITION SENSOR.</b>
--------------	--

**CHECK** : **Is the camshaft position sensor installation bolt tightened securely?**

**YES** : Go to next step 1).

**NO** : Tighten camshaft position sensor installation bolt securely.



- 1) Remove camshaft position sensor.
- 2) Measure resistance between connector terminals of camshaft position sensor.

**CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance between 1 and 4 kΩ?**

**YES** : Repair poor contact in camshaft position sensor connector.

**NO** : Replace camshaft position sensor.

OBD (FB1)  
 P0341 <CAM\_R>  
 B2M1092

**AN: DTC P0341**  
**— CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Engine stalls.
- Failure of engine to start

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10AN1</b>	<b>CHECK DTC P0340 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0340?*
- YES** : Inspect DTC P0340 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>
- NO** : Replace camshaft position sensor.

OBD	(FB1)
P0400	<EGR>

OBD0315

**AO: DTC P0400**  
**— EXHAUST GAS RECIRCULATION FLOW MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Poor driving performance on low engine speed

**WIRING DIAGRAM:**



B2M1093

**CAUTION:**

Before confirmation of actual driving pattern, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



<b>10A01</b>	<b>CHECK ENGINE/TRANSMISSION TYPE.</b>
--------------	--

- CHECK** : *Is engine/transmission type 2200 cc/MT?*
- YES** : Check AT/MT identification circuit. <Ref. to 2-7 [T10DD0].>
- NO** : Go to step **10A02**.

<b>10A02</b>	<b>CHECK DTC P0106, P0107, P0108, P0403, P1102, P1122 OR P1421 ON DISPLAY.</b>
--------------	--

- CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P0403, P1102, P1122 or P1421?*
- YES** : ● Inspect DTC P0106, P0107, P0108, P0403, P1102, P1122 or P1421 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>  
● Manually check that EGR valve diaphragm is not stuck.

**WARNING:**





**Be careful when checking EGR valve, since it may be extremely hot.**

**NOTE:**

In this case, it is not necessary to inspect DTC P0400.

After checking the above item, go to **CONFIRMATION OF ACTUAL DRIVING PATTERN.**

- NO** : Go to step **10A03**.



**10A03 CHECK VACUUM LINE.**

**CHECK** : *Is there a fault in vacuum line?*

**NOTE:**

Check the following items.

- Disconnection, leakage and clogging of the two vacuum hoses and pipes between throttle body and BPT
- Disconnection, leakage and clogging of the vacuum hose and pipe between EGR solenoid valve and BPT
- Disconnection, leakage and clogging of the vacuum hose between EGR solenoid valve and EGR valve
- Disconnection, leakage and clogging of BPT pressure transmitting hose

**YES** : Repair or replace hoses and pipes.

And after the checking and repairing, go to **CONFIRMATION OF ACTUAL DRIVING PATTERN.**

**NO** : Go to step **10A04.**

**10A04 CHECK OPERATION OF EGR SYSTEM.**

- 1) Turn ignition switch to OFF.
- 2) Connect the test mode connector.
- 3) Turn ignition switch to ON.


**CHECK** : *Does EGR solenoid valve produce operating sound?*

**NOTE:**

EGR control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD05). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to next step 4).

**NO** : Replace EGR solenoid valve.



- 4) Turn ignition switch to OFF.
- 5) Disconnect connector from EGR solenoid valve.
- 6) Connect 12 V battery's ground  $\ominus$  terminal to one terminal of the EGR solenoid valve. Then connect 12 V battery's  $\oplus$  terminal to the other terminal of it.

**CAUTION:**

**Do not use the 12 V battery installed in the vehicle, because the electrical system may be damaged.**

- 7) Start the engine.

**CHECK** : ***Does EGR valve operate at a throttle valve opening of 5 to 10 degrees with visually check?***

**YES** : Possibly EGR valve malfunction may be due to freezing or clogging by foreign matter. At this point in time do not replace EGR valve, since it is not faulty. And after the checking, go to **CONFIRMATION OF ACTUAL DRIVING PATTERN.**

**NOTE:**

If malfunction is detected again in the confirmation of actual driving pattern, EGR valve is faulty. Go to next step 8).

**NO** : Go to next step 8).

- 8) Turn ignition switch to OFF.

**CHECK** : ***Is there clogging in the gas outlets of intake manifold or cylinder head, checking by breathing into the outlets?***

**YES** : Repair or replace intake manifold or cylinder head. And go to **CONFIRMATION OF ACTUAL DRIVING PATTERN.**


**NO** : Clean EGR valve. And go to **CONFIRMATION OF ACTUAL DRIVING PATTERN.**

**CAUTION:**

**Do not use solvent when cleaning EGR valve assembly, as it can damage diaphragm.**


**NOTE:**

- Remove and blow away the exhaust deposits. Make sure the valve operates smoothly and the valve seat area is completely cleaned.
- Replace EGR valve as required.




**CONFIRMATION OF ACTUAL DRIVING PATTERN.**


- 1) Conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to 2-7 [T3D0] and [T3E0].>
- 2) Connect Subaru select monitor to its data link connector.
- 3) Start and warm-up the engine until the radiator fan makes one complete rotation. (All accessory switches are OFF.)
- 4) Turn Subaru select monitor switch to ON.



- 5) Designate mode using function key.  
**Function mode: FA4**



- 6) Drive at 88±5 km/h (55±3 MPH) until the LED No. 2 comes on.  
NOTE:  
Keep the throttle valve opening at the same degree, since diagnosis will be interrupted when the opening varies.  
Diagnosis starts in 190 seconds after starting engine and takes 4 seconds.  
Put the gear to "D" range for the diagnosis.



- 7) Designate mode using function key.  
**Function mode: FB0**
- 8) Confirm the "No trouble" indication on Subaru select monitor.

OBD	(FB1)
P0403	<EGRSOL>
OBD0323	

**AP: DTC P0403**  
**— EXHAUST GAS RECIRCULATION CIRCUIT**  
**LOW INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Poor driving performance on low engine speed

**WIRING DIAGRAM:**




**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10AP1 CHECK ENGINE/TRANSMISSION TYPE.**

- CHECK** : *Is engine/transmission type 2200 cc/MT?*
- YES** : Check AT/MT identification circuit. <Ref. to 2-7 [T10DD0].>
- NO** : Go to step **10AP2**.


**10AP2 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
  - 2) Measure voltage between ECM and chassis ground.
- CHECK** : **Connector & terminal (B84) No. 71 (+) — Chassis ground (-): Is the voltage more than 10 V?**
- YES** : Go to next **CHECK** .
- NO** : Go to step **10AP3**.
- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)


**NOTE:**

In this case, repair the following:

- Poor contact in EGR solenoid valve connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

**10AP3 CHECK HARNESS BETWEEN EGR SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
  - 2) Disconnect connectors from EGR solenoid valve and ECM.
  - 3) Measure resistance of harness between EGR solenoid valve connector and engine ground.
- CHECK** : **Connector & terminal (E18) No. 2 — Engine ground: Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and EGR solenoid valve connector.
- NO** : Go to next step 4).



4) Measure resistance of harness between ECM and EGR solenoid valve connector.

**CHECK** : **Connector & terminal (B84) No. 71 — (E18) No. 2:**  
**Is the voltage less than 1 Ω?**


**YES** : Go to step 10AP4.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between EGR solenoid valve and ECM connector
- Poor contact in coupling connector (B21)
- Poor contact in EGR solenoid valve connector
- Poor contact in ECM connector




**10AP4 CHECK EGR SOLENOID VALVE.**

Measure resistance between EGR solenoid valve terminals.

**CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance between 10 and 100 Ω?**

**YES** : Go to step 10AP5.

**NO** : Replace EGR solenoid valve.



**10AP5 CHECK POWER SUPPLY TO EGR SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between EGR solenoid valve and engine ground.

**CHECK** : **Connector & terminal (E18) No. 1 (+) — Engine ground (-):**  
**Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between main relay and EGR solenoid valve connector.

**CHECK** : **Is there poor contact in EGR solenoid valve connector?**

**YES** : Repair poor contact in EGR solenoid valve connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD	(FB1)
P0420	<CAT>

OBD0329

**AQ: DTC P0420**  
**— CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition (2200 cc Federal spec. vehicles only)
- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Engine stalls.
- Idle mixture is out of specifications.

**WIRING DIAGRAM:**



B2M1097

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>



**10AQ1****CHECK ANY OTHER DTC P0130, P0133, P0135, P0136, P0139 AND P0141 ON DISPLAY.**

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0130, P0133, P0135, P0136, P0139 and P0141?*

**YES** : Inspect the relevant DTC using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0420.

**NO** : Go to step **10AQ2**.

**10AQ2****CHECK EXHAUST SYSTEM.**

Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes.

**CHECK** : *Is there a fault in exhaust system?*


**NOTE:**

Check the following positions.

- Between cylinder head and front exhaust pipe
- Between front exhaust pipe and front catalytic converter
- Between front catalytic converter and rear catalytic converter

**YES** : Repair or replace exhaust system.

**NO** : Go to step **10AQ3**.

**10AQ3****CHECK REAR CATALYTIC CONVERTER.**

1) Separate rear catalytic converter from rear exhaust pipe.

**CHECK** : *Is there damage at rear face of rear catalyst?*

**YES** : Replace front and rear catalytic converters.

**NO** : Go to next step 2).

2) Remove front catalytic converter.


**CHECK** : *Is there damage at rear face or front face of front catalyst?*

**YES** : Replace front catalytic converter.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



OBD (FB1)  
 P0440 <EVAP>  
 H2M1365

**AR: DTC P0440**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Gasoline smell

**WIRING DIAGRAM:**



B2M0919

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.


<Ref. to 2-7 [T3D0] and [T3E0].>

**10AR1** CHECK ANY OTHER DTC (BESIDES DTC P0440) ON DISPLAY.

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>
- NO** : Go to step **10AR2**.

**10AR2** CHECK FUEL FILLER CAP AND FUEL FILLER PIPE.

- 1) Turn ignition switch to OFF.
  - 2) Open the fuel flap.
- CHECK** : *Is the fuel filler cap tightened securely?*
  - YES** : Tighten fuel filler cap securely.
  - NO** : Go to next **CHECK** .
  - CHECK** : *Is there any damage to the seal between fuel filler cap and fuel filler pipe?*
  - YES** : Repair or replace fuel filler cap and fuel filler pipe.
  - NO** : Go to step **10AR3**.




**10AR3** CHECK VENT CONTROL SOLENOID VALVE.


- 1) Connect test mode connector.
- 2) Turn ignition switch to ON.

**CHECK** : *Does vent control solenoid valve produce operating sound?*

**NOTE:**  
Vent control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD08). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- YES** : Go to step **10AR4**.
- NO** : Replace vent control solenoid valve.





<b>10AR4</b>	<b>CHECK PURGE CONTROL SOLENOID VALVE.</b>
--------------	--


**CHECK** : *Does purge control solenoid valve produce operating sound?*

**NOTE:**

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD02). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10AR5**.

**NO** : Replace purge control solenoid valve.



<b>10AR5</b>	<b>CHECK PRESSURE CONTROL SOLENOID VALVE.</b>
--------------	---

**CHECK** : *Does pressure control solenoid valve produce operating sound?*

**NOTE:**

Pressure control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD07). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10AR6**.

**NO** : Replace pressure control solenoid valve.

10AR6	CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.
-------	---

Turn ignition switch to OFF.

**CHECK** : **Does fuel leak in fuel line?**

**YES** : Repair or replace fuel line.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there any damage at canister?**

**YES** : Repair or replace canister.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there any damage at fuel tank?**

**YES** : Repair or replace fuel tank.

**NO** : Go to next **CHECK** .

**CHECK** : **Are there holes, cracks, clogging or disconnections of hoses or pipes in evaporative emission control system?**

**YES** : Repair or replace hoses or pipes.

**NO** : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD  P0441	(FB1)  <CPC_F>
------------------	----------------------


OBD0331

**AS: DTC P0441**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM INCORRECT PURGE FLOW —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10AS1</b>	<b>CHECK DTC P0106, P0107, P0108, P0443, P1102, P1122 OR P1422 ON DISPLAY.</b>
--------------	--


**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P0443, P1102, P1122 or P1422?*

**YES** : Inspect the relevant DTC P0106, P0107, P0108, P0443, P1102, P1122 or P1422 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0441.

**NO** : Go to step **10AS2**.



<b>10AS2</b>	<b>CHECK PURGE CONTROL SOLENOID VALVE OPERATION.</b>
--------------	--

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.
- 3) Turn ignition switch to ON.

**CHECK** : *Does purge control solenoid valve produce operating sound at about 0.3 Hz?*

NOTE:

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD02). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to next step 4).

**NO** : Replace purge control solenoid valve.

- 4) Disconnect canister purge hose from canister.

**CHECK** : *Does pulsation occur by blowing through the canister purge hose?*

**YES** : Repair or replace evaporation line.

NOTE:

In this case, repair the following:

- Loose connections in evaporation line
- Cracks in evaporation line
- Clogging in evaporation line

**NO** : Replace purge control solenoid valve.

OBD	(FB1)
P0443	<CPC>
OBD0335	

**AT: DTC P0443**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling

**WIRING DIAGRAM:**




B2M1310

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>





**10AT1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.


**CHECK** : **Connector & terminal (B84) No. 72 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**NO** : Go to step 10AT2.




**10AT2 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from purge control solenoid valve and ECM.
- 3) Measure resistance of harness between purge control solenoid valve connector and engine ground.

**CHECK** : **Connector & terminal (E4) No. 2 — Engine ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and purge control solenoid valve connector.

**NO** : Go to next step 4).




- 4) Measure resistance of harness between ECM and purge control solenoid valve of harness connector.

**CHECK** : **Connector & terminal (B84) No. 72 — (E4) No. 2: Is the resistance less than 1 Ω?**

**YES** : Go to step 10AT3.

**NO** : Repair open circuit in harness between ECM and purge control solenoid valve connector.


**10AT3****CHECK PURGE CONTROL SOLENOID VALVE.**

- 1) Remove purge control solenoid valve.
- 2) Measure resistance between purge control solenoid valve terminals.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
**Is the resistance between 10 and 100 Ω?**

**YES** : Go to step 10AT4.

**NO** : Replace purge control solenoid valve.

**10AT4****CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between purge control solenoid valve and engine ground.

**CHECK** : **Connector & terminal**  
**(E4) No. 1 (+) — Engine ground (-):**  
**Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between main relay and purge control solenoid valve connector.

**CHECK** : **Is there poor contact in purge control solenoid valve connector?**

**YES** : Repair poor contact in purge control solenoid valve connector.

**NO** : Contact with SOA service.

**NOTE:**


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD (FB1)  
 P0446 <VCMSOL\_LO>  
 B2M1098

**AU: DTC P0446**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL LOW INPUT —**


- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M0920

**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10AU1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 35 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Go to step **AU2**.

**CHECK** : **Is there poor contact in ECM connector?**


**YES** : Repair poor contact in ECM connector.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)

**NOTE:**

In this case, repair the following:

- Poor contact in vent control solenoid valve connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B97, B98 and R57)


**10AU2 CHECK HARNESS BETWEEN VENT CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from vent control solenoid valve and ECM.
- 3) Measure resistance of harness between vent control solenoid valve connector and chassis ground.

**CHECK** : **Connector & terminal (R69) No. 2 — Chassis ground: Is the resistance less than 10  $\Omega$ ?**

**YES** : Repair ground short circuit in harness between ECM and vent control solenoid valve connector.

**NO** : Go to next step 4).



- 4) Measure resistance of harness between ECM and vent control solenoid valve connector.

**CHECK** : **Connector & terminal (B84) No. 35 — (R69) No. 2: Is the voltage less than 1  $\Omega$ ?**


**YES** : Go to step **10AU3**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and vent control solenoid valve connector
- Poor contact in coupling connectors (B98 and R57)



**10AU3 CHECK VENT CONTROL SOLENOID VALVE.**

Measure resistance between vent control solenoid valve terminals.

- CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance between 10 and 100 Ω?**
- YES** : Go to step 10AU4.
- NO** : Replace vent control solenoid valve.



**10AU4 CHECK POWER SUPPLY TO VENT CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between vent control solenoid valve and chassis ground.

- CHECK** : **Connector & terminal (R69) No. 1 (+) — Chassis ground (-):**  
**Is the voltage more than 10 V?**
- YES** : Go to next **CHECK** .
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between main relay and vent control solenoid valve
- Poor contact in coupling connectors (B97 and R57)
- Poor contact in main relay connector

**CHECK** : **Is there poor contact in vent control solenoid valve connector?**

**YES** : Repair poor contact in vent control solenoid valve connector.

**NO** : Contact with SOA service.

**NOTE:**


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD (FB1)  
 P0451 <TNKP\_F>  
 H2M1377

AV: DTC P0451  
 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE PROBLEM —

DTC DETECTING CONDITION:  
 • Two consecutive driving cycles with fault

WIRING DIAGRAM:



B2M0926

**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10AV1</b>	<b>CHECK PRESSURE/VACUUM LINE.</b>
--------------	------------------------------------

**CHECK** : *Is there a fault in pressure/vacuum line?*

**NOTE:**

Check the following items.

- Disconnection, leakage and clogging of the vacuum hoses and pipes between fuel tank pressure sensor and fuel tank
- Disconnection, leakage and clogging of air ventilation hoses and pipes between fuel filler pipe and fuel tank

**YES** : Repair or replace hoses and pipes.


**NO** : Replace fuel tank pressure sensor.

OBD (FB1)  
 P0452 <TNKP\_LOW>  
 B2M1099

**AW: DTC P0452**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT**  
**—**

**DTC DETECTING CONDITION:**  
 ● Immediately at fault recognition


**WIRING DIAGRAM:**



B2M0926

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>





**10AW1** **CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuel filler cap.
- 3) Install fuel filler cap.
- 4) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 5) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.

TNKP (F43)  
0.10kPa 1mmHg

H2M1326

- 6) Read the data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F43**

- F43: Display shows pressure signal value sent from fuel tank pressure sensor.


**CHECK** : *Is the value less than -2.8 kPa in function mode F43?*

**YES** : Go to step 10AW2.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.




**10AW2** **CHECK INPUT SIGNAL FOR ECM. (USING VOLTAGE METER AND SUBARU SELECT MONITOR.)**

- 1) Measure voltage between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 21 (+) — Chassis ground (-): Is the voltage more than 4.5 V?**

**YES** : Go to next step 2).

**NO** : Go to next **CHECK** .




**CHECK** : Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 4 (+) — Chassis ground (-): Is the voltage less than 0.2 V?**

**YES** : Go to step 10AW3.

**NO** : Go to next step 3).



3) Read data on Subaru Select Monitor.

● Subaru Select Monitor

Designate mode using function key.


**Function mode: F43**

● F43: Display shows pressure signal value sent from fuel tank pressure sensor.

**CHECK** : Does the value change more than -2.8 kPa by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 10AW3.



10AW3

**CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Detach right side trunk side trim panel (Sedan) or right side rear quarter trim panel (Wagon).
- 3) Remove right side rear quarter trim pocket (Wagon model only).
- 4) Detach right side rear quarter insulator (Wagon model only).



- 5) Disconnect connector from fuel tank pressure sensor.
- 6) Turn ignition switch to ON.
- 7) Measure voltage between fuel tank pressure sensor connector and chassis ground.

**CHECK** : **Connector & terminal (R47) No. 3 (+) — Chassis ground (-): Is the voltage more than 4.5 V?**

**YES** : Go to next step 8).

**NO** : Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure sensor connector
- Poor contact in coupling connector (B97)

8) Turn ignition switch to OFF.

9) Disconnect connector from ECM.

10) Measure resistance of harness between ECM and pressure sensor connector.



**CHECK** : **Connector & terminal (B84) No. 20 — (R47) No. 1: Is the resistance less than 1 Ω?**


**YES** : Go to next step 11).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure sensor connector
- Poor contact in coupling connector (B98)



11) Measure resistance of harness between fuel tank pressure sensor connector and chassis ground.

**CHECK** : **Connector & terminal (R47) No. 1 — Chassis ground:**  
**Is the resistance more than 500 kΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between ECM and fuel tank pressure sensor connector.

**CHECK** : **Is there poor contact in fuel tank pressure sensor connector?**

**YES** : Repair poor contact in fuel tank pressure sensor connector.


**NO** : Replace fuel tank pressure sensor.

OBD (FB1)  
 P0453 <TNKP\_HI>  
 B2M1100



**AX: DTC P0453**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT**  
**—**

- DTC DETECTING CONDITION:**
- Immediately at fault recognition

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10AX1**
**CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuel filler cap.
- 3) Install fuel filler cap.
- 4) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 5) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.

6) Read the data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F43**

- F43: Display shows pressure signal value sent from fuel tank pressure sensor.


**CHECK** : *Is the value more than 2.8 kPa in function mode F43?*

**YES** : Go to step **10AX4**.

**NO** : Go to step **10AX2**.

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


**10AX2**
**CHECK INPUT SIGNAL FOR ECM. (USING VOLTAGE METER AND SUBARU SELECT MONITOR.)**

- 1) Measure voltage between ECM connector and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 21 (+) — Chassis ground (-): Is the voltage more than 4.5 V?*

**YES** : Go to next step 2).


**NO** : Go to next **CHECK** .



**CHECK** : Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.




2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 4 (+) — Chassis ground (-): Is the voltage less than 0.2 V?**

**YES** : Go to step 10AX3.

**NO** : Go to next step 3).



3) Read data on Subaru Select Monitor.

- Subaru Select Monitor Designate mode using function key.


**Function mode: F43**

- F43: Display shows pressure signal value sent from fuel tank pressure sensor.

**CHECK** : Does the value change more than -2.8 kPa by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 10AX3.



10AX3

**CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Detach right side trunk side trim panel (Sedan) or right side rear quarter trim panel (Wagon).
- 3) Remove right side rear quarter trim pocket (Wagon model only).
- 4) Detach right side rear quarter insulator (Wagon model only).



- 5) Disconnect connector from fuel tank pressure sensor.
- 6) Turn ignition switch to ON.
- 7) Measure voltage between fuel tank pressure sensor connector and chassis ground.

**CHECK** : **Connector & terminal (R47) No. 3 (+) — Chassis ground (-): Is the voltage more than 4.5 V?**


**YES** : Go to next step 8).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure sensor connector
- Poor contact in coupling connector (B97)



- 8) Turn ignition switch to OFF.
- 9) Disconnect connector from ECM.
- 10) Measure resistance of harness between ECM and pressure sensor connector.

**CHECK** : **Connector & terminal (B84) No. 4 — (R47) No. 2: Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .


**NO** : Repair harness and connector.



NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure sensor connector
- Poor contact in coupling connector (B98)



**CHECK** : **Connector & terminal (B84) No. 20 — (R47) No. 1:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure sensor connector
- Poor contact in coupling connector (B98)

**CHECK** : **Is there poor contact in fuel tank pressure sensor connector?**

**YES** : Repair poor contact in fuel tank pressure sensor connector.

**NO** : Replace fuel tank pressure sensor.



**10AX4 CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.
- 2) Detach right side trunk side trim panel (Sedan) or right side rear quarter trim panel (Wagon).
- 3) Remove right side rear quarter trim pocket (Wagon model only).
- 4) Detach right side rear quarter insulator (Wagon model only).

TNKP	( F 4 3 )
0 . 1 0 k P a	1 m m H g

H2M1326

- 5) Disconnect connector from fuel tank pressure sensor.
- 6) Remove fuel filler cap.
- 7) Install fuel filler cap.
- 8) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 9) Read data on Subaru select monitor or the OBD-II general scan tool.

- Subaru Select Monitor

Designate mode using function key.

**Function mode: F43**

**CHECK** : *Is the value more than 2.8 kPa in function mode F43?*

**YES** : Repair battery short circuit in harness between ECM and fuel tank pressure sensor connector.

**NO** : Replace fuel tank pressure sensor.

- OBD-II general scan tool


For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

OBD (FB1)  
 P0461 <FLVL\_R>  
 B2M1101

**AY: DTC P0461**  
**— FUEL LEVEL SENSOR CIRCUIT RANGE/**  
**PERFORMANCE PROBLEM —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>


**10AY1****CHECK DTC P0462 OR P0463 ON DISPLAY.****CHECK****: Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0462 or P0463?****YES****: Inspect DTC P0462 or P0463 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>****NOTE:****In this case, it is not necessary to inspect this trouble.****NO****: Replace fuel sending unit and fuel sub meter unit.**

OBD (FB1)  
 P0462 <FLVL\_LOW>  
 B2M1102

**AZ: DTC P0462**  
**— FUEL LEVEL SENSOR CIRCUIT LOW INPUT —**

**DTC DETECTING CONDITION:**  
 ● Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M0933


**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10AZ1</b>	<b>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</b>
--------------	---

**CHECK** : *Does speedometer and tachometer operate normally?*


**YES** : Go to step 10AZ3.

**NO** : Go to step 10AZ2.



<b>10AZ2</b>	<b>CHECK GROUND CIRCUIT OF COMBINATION METER.</b>
--------------	---

- 1) Turn ignition switch to OFF.
- 2) Pull out combination meter from instrument panel. <Ref. to 6-2 [W13A1].>
- 3) Disconnect connector from combination meter.



- 4) Measure resistance of harness between combination meter connector and chassis ground.

**CHECK** : **Connector & terminal (i12) No. 1 — Chassis ground: Is resistance less than 5 Ω?**


**YES** : Repair or replace combination meter.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between combination meter connector and grounding terminal
- Poor contact in combination meter connector
- Poor contact in grounding terminal




**10AZ3 CHECK INPUT SIGNAL FOR ECM. (USING VOLTAGE METER AND SUBARU SELECT MONITOR.)**

- 1) Turn ignition switch to ON. (Engine OFF)
- 2) Measure voltage between ECM connector and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 27 (+) — Chassis ground (-): Is the voltage less than 0.12 V?*

**YES** : Go to step 10AZ4.

**NO** : Go to next **CHECK** .



**CHECK** : *Does the value change less than 0.12 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?*

- Subaru Select Monitor Designate mode using function key.

**Function mode: F45**

- F45: Fuel level sensor output signal is indicated.


**YES** : Repair poor contact in ECM connector.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.

**NOTE:**


In this case, repair the following:

- Poor contact in fuel pump connector
- Poor contact in combination meter connector
- Poor contact in ECM connector
- Poor contact in coupling connector (i3, B99, B22, B98 and R57)



**10AZ4 CHECK HARNESS BETWEEN ECM, COMBINATION METER AND FUEL PUMP CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuel pump access hole lid located on the right rear of trunk compartment floor (Sedan) or luggage compartment floor (Wagon).




- 3) Disconnect connector from fuel pump.
- 4) Measure resistance of harness between fuel pump connector and chassis ground.


**CHECK** : **Connector & terminal (R58) No. 3 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Go to next step 5).

**NO** : Go to step 10AZ5.



- 5) Remove service hole cover located on the left rear of trunk compartment floor (Sedan) or luggage compartment floor (Wagon).




- 6) Disconnect connector from fuel sub meter unit.
- 7) Measure resistance of harness between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 3 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between fuel pump and fuel sub meter unit connector.

**NO** : Go to next step 8).




- 8) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15).
- 9) Measure resistance of harness between fuel sub meter unit connector and chassis ground.

**CHECK** : **Connector & terminal (R59) No. 1 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in fuel tank cord.

**NO** : Go to next step 10).




- 10) Separate rear wiring harness connector (R2) and bulkhead wiring harness connector (B98).
- 11) Measure resistance of harness between rear wiring harness connector and chassis ground.

**CHECK** : **Connector & terminal (R15) No. 3 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Go to next step 12).

**NO** : Repair ground short circuit in bulkhead wiring harness.






- 12) Separate rear wiring harness connector (R3) and bulkhead wiring harness connector (B99).
- 13) Measure resistance of harness between rear wiring harness connector and chassis ground.

**CHECK** : **Connector & terminal (R3) No. 20 — Chassis ground:**  
**Is the resistance less than 10 Ω?**


- YES** : Repair ground short circuit in rear wiring harness.
- NO** : Go to next step 14).



- 14) Separate bulkhead wiring harness connector (B38) and instrument panel wiring harness connector (i3).
- 15) Measure resistance of harness between bulkhead wiring harness connector and chassis ground.


**CHECK** : **Connector & terminal (B99) No. 20 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

- YES** : Repair ground short circuit in bulkhead wiring harness.
- NO** : Repair ground short circuit in instrument panel wiring harness.



<b>10AZ5</b>	<b>CHECK HARNESS BETWEEN COMBINATION METER AND FUEL PUMP CONNECTOR.</b>
--------------	---

- 1) Connect connector to fuel pump.
- 2) Pull out combination meter from instrument panel. <Ref. to 6-2 [W13A1].>
- 3) Disconnect connector from combination meter.



4) Measure resistance of harness between combination meter connector and chassis ground.

**CHECK** : **Connector & terminal (i10) No. 3 — Chassis ground:**  
**Is the resistance less than 200 Ω?**

**YES** : Go to step 10AZ6.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between combination meter connector and junction A on rear wiring harness
- Poor contact in coupling connectors (i3 and B99)

<b>10AZ6</b>	<b>CHECK COMBINATION METER.</b>
--------------	---------------------------------

1) Disconnect speedometer cable from combination meter and remove combination meter.

**CHECK** : **Is the fuel meter installation screw tightened securely?**

**YES** : Go to next step 2).

**NO** : Tighten fuel meter installation screw securely.

2) Remove printed circuit plate assembly from combination meter assembly.

**CHECK** : **Is there flaw or burning on printed circuit plate assembly?**

**YES** : Replace printed circuit plate assembly.


**NO** : Replace fuel meter assembly.

OBD (FB1)  
 P0463 <FLVL\_HI>  
 B2M1103


**BA: DTC P0463**  
**— FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BA1****CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.****CHECK** : *Does speedometer and tachometer operate normally?***YES** : Go to step 10BA3.**NO** : Go to step 10BA2.**10BA2****CHECK GROUND CIRCUIT OF COMBINATION METER.**


- 1) Turn ignition switch to OFF.
- 2) Pull out combination meter from instrument panel. <Ref. to 6-2 [W13A1].>
- 3) Disconnect connector from combination meter.


- 4) Measure resistance of harness between combination meter connector and chassis ground.

**CHECK** : **Connector & terminal (i12) No. 1 — Chassis ground:**  
**Is resistance less than 5 Ω?****YES** : Repair or replace combination meter.**NO** : Repair harness and connector.**NOTE:**

In this case, repair the following:

- Open circuit in harness between combination meter connector and grounding terminal
- Poor contact in combination meter connector
- Poor contact in grounding terminal





**10BA3 CHECK INPUT SIGNAL FOR ECM. (USING VOLTAGE METER AND SUBARU SELECT MONITOR.)**


- 1) Turn ignition switch to ON. (Engine OFF)
- 2) Measure voltage between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 27 (+) — Chassis ground (-): Is the voltage more than 4.75 V?**

- YES** : Go to step 10BA4.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.


**NOTE:**  
In this case, repair the following:

- Poor contact in fuel pump connector
- Poor contact in combination meter connector
- Poor contact in ECM connector
- Poor contact in coupling connector (i3, B99, B22, B98 and R57)



**10BA4 CHECK FUEL LEVEL SENSOR.**


- 1) Turn ignition switch to OFF.
- 2) Remove fuel pump access hole lid located on the right rear of trunk compartment floor (Sedan) or luggage compartment floor (Wagon).



- 3) Disconnect connector from fuel pump.
- 4) Measure resistance between connector terminals of fuel pump.


**CHECK** : **Terminals No. 3 — No. 5: Is the resistance less than 100 Ω?**

- YES** : Go to step 10BA5.
- NO** : Replace fuel sending unit.



**10BA5 CHECK FUEL SUB LEVEL SENSOR.**

- 1) Remove service hole cover located on the left rear of trunk compartment floor (Sedan) or luggage compartment floor (Wagon).




- 2) Disconnect connector from fuel sub meter unit.
- 3) Measure resistance between connector terminals of fuel sub meter unit.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
**Is the resistance less than 100 Ω?**

**YES** : Go to step 10BA6.

**NO** : Replace fuel sub meter unit.




**10BA6 CHECK HARNESS BETWEEN FUEL PUMP AND FUEL SUB METER UNIT CONNECTOR.**

Measure resistance of harness between fuel pump and fuel sub meter unit connector.

**CHECK** : **Connector & terminal**  
**(R58) No. 3 — (R59) No. 2:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to step 10BA7.

**NO** : Repair open circuit in harness between fuel pump and fuel sub meter unit connector.


**10BA7 CHECK GROUND CIRCUIT OF FUEL LEVEL SENSOR.**

Measure resistance of harness between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 5 — Chassis ground: Is the resistance less than 5 Ω?**


**YES** : Go to step 10BA8.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between fuel pump connector and chassis grounding terminal
- Poor contact in fuel pump connector
- Poor contact in coupling connectors (R57, B98 and B22)


**10BA8 CHECK HARNESS BETWEEN ECM AND FUEL PUMP CONNECTOR.**

- 1) Connect connector to fuel sub meter unit.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between fuel pump connector and chassis ground.

**CHECK** : **Connector & terminal (R58) No. 3 (+) — Chassis ground (-): Is the voltage less than 1 V?**


**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between fuel pump connector and junction A on rear wiring harness
- Poor contact in fuel sub meter unit connector
- Poor contact in fuel pump connector
- Poor contact in coupling connector (R57)

**NO** : Go to next step 4).



- 4) Turn ignition switch to OFF.
- 5) Disconnect connector from ECM.
- 6) Turn ignition switch to ON.
- 7) Measure voltage between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 27 (+) — Chassis ground: Is the voltage less than 1 V?**

**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM connector and junction A on rear wiring harness
- Poor contact in coupling connector (B98)

**NO** : Repair connector.

**NOTE:**

In this case, repair the following:

- Poor contact in fuel pump connector
- Poor contact in fuel sub meter unit
- Poor contact in ECM connector




OBD	(FB1)
P0500	<VSP>

OBD0340

**BB: DTC P0500**  
**— VEHICLE SPEED SENSOR MALFUNCTION**  
**—**

**DTC DETECTING CONDITION:**  
 ● Immediately at fault recognition

**WIRING DIAGRAM:**



B2M1285


**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BB1</b>	<b>CHECK SPEEDOMETER OPERATION IN COMBINATION METER.</b>
--------------	--

**CHECK** : *Does speedometer operate normally?*

**YES** : Go to step **10BB2**.

**NO** : Check speedometer and vehicle speed sensor <Ref. to 6-2 [K3A0].>.



<b>10BB2</b>	<b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b>
--------------	---

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from TCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 83 (+) — Chassis ground (-): Is the voltage more than 2 V?**


**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and combination meter connector
- Poor contact in ECM connector
- Poor contact in combination meter connector
- Poor contact in coupling connector (B37)

**NO** : Go to step **10BB3**.



<b>10BB3</b>	<b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b>
--------------	---

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 83 — Chassis ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and combination meter connector.

**NO** : Repair poor contact in ECM connector.

OBD	(FB1)
P0505	<ISC>
OBD0358	

**BC: DTC P0505**  
**— IDLE CONTROL SYSTEM MALFUNCTION**  
**—**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Engine breathing

**WIRING DIAGRAM:**



B2M1311

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BC1 CHECK AIR INTAKE SYSTEM.**

- 1) Turn ignition switch to ON.
- 2) Start engine, and idle it.

**CHECK** : *Is there a fault in air intake system?*


NOTE:

Check the following items.

- Loose installation of intake manifold, idle air control solenoid valve and throttle body
- Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket
- Loose connections and cracks of idle air control solenoid valve by-pass hoses
- Disconnections of vacuum hoses

**YES** : Repair or replace air intake system.

**NO** : Go to step **10BC2**.

**10BC2 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 13 (+) — Chassis ground (-): Is the voltage more than 3 V?**


**YES** : Go to next **CHECK** .

**NO** : Go to step **10BC4**.

**CHECK** : **Connector & terminal (B84) No. 14 (+) — Chassis ground (-): Is the voltage more than 3 V?**

**YES** : Go to next step 3).

**NO** : Go to step **10BC4**.



- 3) Turn ignition switch to OFF.
- 4) Disconnect connector from idle air control solenoid valve.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 13 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Connector & terminal (B84) No. 14 (+) — Chassis ground (-): Is the voltage more than 10 V?**


**YES** : Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Go to step **10BC3**.


**10BC3 CHECK IDLE AIR CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between idle air control solenoid valve connector terminals.

**CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance more than 20 Ω?**

**YES** : Replace idle air control solenoid valve.

**NO** : Go to next **CHECK** .

**CHECK** : **Terminals No. 2 — No. 3:**  
**Is the resistance more than 20 Ω?**

**YES** : Replace idle air control solenoid valve.

**NO** : Go to next **CHECK** .

**CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance less than 5 Ω?**


**YES** : Replace idle air control solenoid valve and ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Terminals No. 2 — No. 3:**  
**Is the resistance less than 5 Ω?**

**YES** : Replace idle air control solenoid valve and ECM.

**NO** : Go to next step 3).



- 3) Remove idle air control solenoid valve. <Ref. to 2-7 [W12A0].>

- 4) Check operation of idle air control solenoid valve.

**CHECK** : **Is idle air control solenoid valve fully opened when applying the battery to terminals No. 2 (+) and No. 1 (-)?**


**YES** : Go to next **CHECK** .


**NO** : Clean idle air control solenoid valve. <Ref. to 2-7 [W12B0].>

**CHECK** : **Is idle air control solenoid valve fully closed when applying the battery to terminals No. 2 (+) and No. 3 (-)?**

**YES** : Go to step 10BC4.

**NO** : Clean idle air control solenoid valve. <Ref. to 2-7 [W12B0].>






**10BC4 CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from idle air control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between idle air control solenoid valve and engine ground.

**CHECK** : **Connector & terminal (E7) No. 2 (+) — Engine ground (-): Is the voltage more than 10 V?**

**YES** : Go to step 10BC5.

**NO** : Repair open circuit in harness between idle air control solenoid valve and main relay connector.



**10BC5 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and idle air control solenoid valve connector.

**CHECK** : **Connector & terminal (B84) No. 14 — (E7) No. 1: Is the resistance less than 1 Ω?**


**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between ECM and idle air control solenoid valve connector.

**CHECK** : **Connector & terminal (B84) No. 13 — (E7) No. 3: Is the resistance less than 1 Ω?**

**YES** : Go to next step 4).

**NO** : Repair open circuit in harness between ECM and idle air control solenoid valve connector.



- 4) Measure resistance of harness between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 13 — Chassis ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.

**NO** : Go to next **CHECK** .

- CHECK** : **Connector & terminal  
(B84) No. 14 — Chassis ground:  
Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.
- NO** : Go to next **CHECK** .
- CHECK** : **Is there poor contact in idle air control solenoid valve connector?**
- YES** : Repair poor contact in idle air control solenoid valve connector.
- NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



OBD (FB1)  
 P0506 <ISC\_RLOW>  
 B2M1104

**BD: DTC P0506**  
**— IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Engine is difficult to start.
- Engine does not start.
- Erroneous idling
- Engine stalls.

**WIRING DIAGRAM:**



B2M1311

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BD1</b>	<b>CHECK DTC P0505 ON DISPLAY.</b>
--------------	------------------------------------

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0505?*

**YES** : Inspect DTC P0505 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0506.

**NO** : Go to step **10BD2**.

<b>10BD2</b>	<b>CHECK AIR INTAKE SYSTEM.</b>
--------------	---------------------------------

1) Turn ignition switch to ON.

2) Start engine, and idle it.

**CHECK** : *Is clogging the by-pass line between by-pass hose and intake duct?*

**YES** : Repair the by-pass line.

**NO** : Replace idle air control solenoid valve.

OBD (FB1)  
 P0507 <ISC\_RHI>  
 B2M1105

**BE: DTC P0507  
 — IDLE CONTROL SYSTEM RPM HIGHER  
 THAN EXPECTED —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.

**WIRING DIAGRAM:**



B2M1311

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BE1</b>	<b>CHECK DTC P0505 ON DISPLAY.</b>
--------------	------------------------------------

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0505?*

**YES** : Inspect DTC P0505 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0507.

**NO** : Go to step **10BE2**.

<b>10BE2</b>	<b>CHECK AIR INTAKE SYSTEM.</b>
--------------	---------------------------------

1) Turn ignition switch to ON.

2) Start engine, and idle it.

**CHECK** : *Is there a fault in air intake system?*

**NOTE:**

Check the following items.

- Loose installation of intake manifold, idle air control solenoid valve and throttle body
- Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket
- Loose connections and cracks of idle air control solenoid valve by-pass hoses
- Disconnections of vacuum hoses

**YES** : Repair air suction and leaks.


**NO** : Replace idle air control solenoid valve.

**BF: DTC P0600  
— SERIAL COMMUNICATION LINK  
MALFUNCTION —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**




B2M1312

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>




**10BF1 CHECK HARNESS BETWEEN ECM AND DATA LINK CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and data link connector (for Subaru Select Monitor & OBD-II general scan tool).

**CHECK** : **Connector & terminal (B84) No. 93 — (B40) No. 10: Is the resistance less than 1 Ω?**

**YES** : Go to next step 4).

**NO** : Repair open circuit in harness between ECM and data link connector.



- 4) Measure resistance of harness between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 93 — Chassis ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and data link connector.

**NO** : Repair poor contact in ECM connector and data link connector.

OBD  P0601	(FB1)  <RAM>
------------------	--------------------

OBD0376

**BG: DTC P0601**  
**— INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Engine does not start.
- Engine stalls.

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BG1</b>	<b>CHECK DTC P0601 ON DISPLAY.</b>
--------------	------------------------------------

**CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0601?

**YES** : Replace ECM.

**NO** : It is not necessary to inspect DTC P0601.


OBD (FB1)  
 P0703 <ATBRK>  
 B2M0655

**BH: DTC P0703**  
**— BRAKE SWITCH INPUT MALFUNCTION —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>




**10BH1 CHECK OPERATION OF BRAKE LIGHT.**

**CHECK** : Does brake light come on when depressing the brake pedal?

**YES** : Go to step 10BH2.

**NO** : Repair or replace brake light circuit.



**10BH2 CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.**

1) Disconnect connectors from TCM and brake light switch.

2) Measure resistance of harness between TCM and brake light switch connector.

**CHECK** : **Connector & terminal**  
**(B56) No. 7 — (B64) No. 2:**  
**(B56) No. 7 — (B65) No. 3 (With cruise control):**  
**(B56) No. 7 — (B67) No. 2 (With traction control):**  
**Is the resistance less than 1 Ω?**


**YES** : Go to next step 3).

**NO** : Repair or replace harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between TCM and brake light switch connector
- Poor contact in TCM connector
- Poor contact in brake light switch connector




3) Measure resistance of harness between TCM and chassis ground.

**CHECK** : **Connector & terminal**  
**(B56) No. 7 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to step 10BH3.

**NO** : Repair ground short circuit in harness between TCM and brake light switch connector.

**10BH3 CHECK INPUT SIGNAL FOR TCM.**

- 1) Connect connectors to TCM and brake light switch.
- 2) Measure voltage between TCM and chassis ground.

**CHECK** : **Connector & terminal (B56) No. 7 (+) — Chassis ground (-): Is the voltage less than 1 V when releasing the brake pedal?**

**YES** : Go to next **CHECK** .

**NO** : Adjust or replace brake light switch.

**CHECK** : **Connector & terminal (B56) No. 7 (+) — Chassis ground (-): Is the voltage more than 10 V when depressing the brake pedal?**


**YES** : Go to next **CHECK** .

**NO** : Adjust or replace brake light switch.

**CHECK** : **Is there poor contact in TCM connector?**

**YES** : Repair poor contact in TCM connector.

**NO** : Replace TCM.



OBD (FB1)  
 P0705 <ATRNG>  
 B2M0656

**BI: DTC P0705**  
**— TRANSMISSION RANGE SENSOR CIRCUIT MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**


- Starter does not rotate when selector lever is in “P” or “N” range.
- Starter rotates when selector lever is in “R”, “D”, “3”, “2” or “1” range.
- Engine brake is not effected when selector lever is in “3” range.
- Shift characteristics are erroneous.

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BI1 CHECK INHIBITOR SWITCH TYPE.****CHECK** : *Is inhibitor switch type plastic body?***YES** : Go to step 10BI2.**NO** : Go to step 10BI4.**10BI2 CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and transmission.
- 3) Measure resistance of harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B56) No. 9 — (T7) No. 8:**  
**Is the resistance less than 1 Ω?****YES** : Go to next **CHECK** .**NO** : Repair harness and connector.**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)

**CHECK** : **Connector & terminal**  
**(B56) No. 10 — (T7) No. 9:**  
**Is the resistance less than 1 Ω?****YES** : Go to next **CHECK** .**NO** : Repair harness and connector.**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)

**CHECK** : **Connector & terminal**  
**(B56) No. 8 — (T7) No. 5:**  
**Is the resistance less than 1 Ω?****YES** : Go to next **CHECK** .**NO** : Repair harness and connector.**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector.
- Poor contact in coupling connector (B12)

**CHECK** : **Connector & terminal**  
**(B54) No. 1 — (T7) No. 6:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)

**CHECK** : **Connector & terminal**  
**(B54) No. 2 — (T7) No. 4:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)

**CHECK** : **Connector & terminal**  
**(B54) No. 3 — (T7) No. 11:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)

**CHECK** : **Connector & terminal**  
**(B54) No. 4 — (T7) No. 3:**  
**Is the resistance less than 1 Ω?**


**YES** : Go to next step 4).

**NO** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)



OBD0597A

4) Measure resistance of harness between TCM and chassis ground.

**CHECK** : **Connector & terminal (B56) No. 9 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B56) No. 10 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B56) No. 8 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B54) No. 1 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B54) No. 2 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B54) No. 3 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**


**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B54) No. 4 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to step 10BI3.

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.



**10BI3 CHECK INHIBITOR SWITCH.**

Measure resistance between inhibitor switch connector receptacle's terminals.

**CHECK** : **Terminals No. 8 — No. 10**

- Is the resistance less than 1 Ω in "P" position?
- Is the resistance more than 1 MΩ in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Terminals No. 9 — No. 10**

- Is the resistance less than 1 Ω in "R" position?
- Is the resistance more than 1 MΩ in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Terminals No. 5 — No. 10**

- Is the resistance less than 1 Ω in "N" position?
- Is the resistance more than 1 MΩ in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Terminals No. 6 — No. 10**

- Is the resistance less than 1 Ω in "D" position?
- Is the resistance more than 1 MΩ in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Terminals No. 4 — No. 10**


- Is the resistance less than 1 Ω in "3" position?
- Is the resistance more than 1 MΩ in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

- CHECK** : **Terminals**  
**No. 11 — No. 10**
- **Is the resistance less than 1  $\Omega$  in “2” position?**
  - **Is the resistance more than 1 M $\Omega$  in other positions?**
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .
- CHECK** : **Terminals**  
**No. 3 — No. 10**
- **Is the resistance less than 1  $\Omega$  in “1” position?**
  - **Is the resistance more than 1 M $\Omega$  in other positions?**
- YES** : Go to step **10BI6**.
- NO** : Go to **CHECK1** .
- CHECK1** : **Is there faulty connection in the selector cable?**
- YES** : Repair connection of selector cable.
- NO** : Replace inhibitor switch.





**10B14 CHECK HARNESS BETWEEN TCM AND TRANSMISSION HARNESS CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and transmission harness connector.
- 3) Measure resistance of harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B56) No. 9 — (B12) No. 3:**  
**Is the resistance less than 1 Ω?**

- YES** : Go to next **CHECK** .
- NO** : Repair open circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B56) No. 10 — (B12) No. 2:**  
**Is the resistance less than 1 Ω?**

- YES** : Go to next **CHECK** .
- NO** : Repair open circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B56) No. 8 — (B12) No. 1:**  
**Is the resistance less than 1 Ω?**

- YES** : Go to next **CHECK** .
- NO** : Repair open circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B54) No. 1 — (B12) No. 8:**  
**Is the resistance less than 1 Ω?**

- YES** : Go to next **CHECK** .
- NO** : Repair open circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal (B54) No. 2 — (B12) No. 7:**  
**Is the resistance less than 1 Ω?**

- YES** : Go to next **CHECK** .
- NO** : Repair open circuit in harness between TCM and transmission harness connector.


**CHECK** : **Connector & terminal (B54) No. 3 — (B12) No. 6:**  
**Is the resistance less than 1 Ω?**

- YES** : Go to next **CHECK** .
- NO** : Repair open circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B54) No. 4 — (B12) No. 5:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next step 4).

**NO** : Repair open circuit in harness between TCM and transmission harness connector.



4) Measure resistance of harness between TCM and chassis ground.

**CHECK** : **Connector & terminal**  
**(B56) No. 9 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B56) No. 10 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B56) No. 8 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B54) No. 1 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B54) No. 2 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**

**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**  
**(B54) No. 3 — Chassis ground:**  
**Is the resistance more than 1 MΩ?**


**YES** : Go to next **CHECK** .

**NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

**CHECK** : **Connector & terminal**

**(B54) No. 4 — Chassis ground:  
Is the resistance more than 1 MΩ?**

- YES** : Go to step 10BI5.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.




<b>10BI5</b>	<b>CHECK INHIBITOR SWITCH.</b>
--------------	--------------------------------

Measure resistance between transmission harness connector receptacle's terminals.

- CHECK** : **Connector & terminal (T3) No. 3 — No. 4**
  - Is the resistance less than 1 Ω in "P" position?
  - Is the resistance more than 1 MΩ in other positions?
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .
- CHECK** : **Connector & terminal (T3) No. 2 — No. 4**
  - Is the resistance less than 1 Ω in "R" position?
  - Is the resistance more than 1 MΩ in other positions?
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .
- CHECK** : **Connector & terminal (T3) No. 1 — No. 4**
  - Is the resistance less than 1 Ω in "N" position?
  - Is the resistance more than 1 MΩ in other positions?
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .
- CHECK** : **Connector & terminal (T3) No. 8 — No. 4**
  - Is the resistance less than 1 Ω in "D" position?
  - Is the resistance more than 1 MΩ in other positions?
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .

- CHECK** : **Connector & terminal (T3) No. 7 — No. 4**
- **Is the resistance less than 1  $\Omega$  in “3” position?**
  - **Is the resistance more than 1 M $\Omega$  in other positions?**
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .
- CHECK** : **Connector & terminal (T3) No. 6 — No. 4**
- **Is the resistance less than 1  $\Omega$  in “2” position?**
  - **Is the resistance more than 1 M $\Omega$  in other positions?**
- YES** : Go to next **CHECK** .
- NO** : Go to **CHECK1** .
- CHECK** : **Connector & terminal (T3) No. 5 — No. 4**
- **Is the resistance less than 1  $\Omega$  in “1” position?**
  - **Is the resistance more than 1 M $\Omega$  in other positions?**
- YES** : Go to step **10B16**.
- NO** : Go to **CHECK1** .
- CHECK1** : **Is there faulty connection in the selector cable?**
- YES** : Repair connection of selector cable.
- NO** : Replace inhibitor switch.



**10B16 CHECK INPUT SIGNAL FOR TCM.**

- 1) Turn ignition switch to OFF.
- 2) Connect connector to TCM and transmission.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between TCM and chassis ground.

**CHECK** : **Connector & terminal (B56) No. 9 (+) — Chassis ground (-):**

- Is the voltage less than 1 V in “P” and “N” positions?
- Is the voltage more than 8 V in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Connector & terminal (B56) No. 10 (+) — Chassis ground (-):**

- Is the voltage less than 1 V in “R” position?
- Is the voltage more than 6 V in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Connector & terminal (B56) No. 8 (+) — Chassis ground (-):**

- Is the voltage less than 1 V in “N” and “P” positions?
- Is the voltage more than 8 V in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Connector & terminal (B54) No. 1 (+) — Chassis ground (-):**

- Is the voltage less than 1 V in “D” position?
- Is the voltage more than 6 V in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Connector & terminal (B54) No. 2 (+) — Chassis ground (-):**

- Is the voltage less than 1 V in “3” position?
- Is the voltage more than 6 V in other positions?

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Connector & terminal**  
**(B54) No. 3 (+) — Chassis ground (–):**

- **Is the voltage less than 1 V in “2” position?**
- **Is the voltage more than 6 V in other positions?**

**YES** : Go to next **CHECK** .

**NO** : Go to **CHECK1** .

**CHECK** : **Connector & terminal**  
**(B54) No. 4 (+) — Chassis ground (–):**

- **Is the voltage less than 1 V in “1” position?**
- **Is the voltage more than 6 V in other positions?**

**YES** : Repair poor contact in TCM connector.

**NO** : Go to **CHECK1** .

**CHECK1** : **Is there poor contact in TCM connector?**

**YES** : Repair poor contact in TCM connector.

**NO** : Replace TCM.

OBD	(FB1)
P0710	<ATF>
OBD0380	

**BJ: DTC P0710**  
**— TRANSMISSION FLUID TEMPERATURE**  
**SENSOR CIRCUIT MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No shift up to 4th speed (after engine warm-up)
- No lock-up (after engine warm-up)
- Excessive shift shock

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BJ1</b>	<b>CHECK DTC P0710 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0710?
- YES** : Check ATF temperature sensor circuit. <Ref. to 3-2 [T7F0].>
- NO** : It is not necessary to inspect DTC P0710.

OBD  P0720	(FB1)  <ATVSP>
------------------	----------------------

OBD0392

**BK: DTC P0720**  
**— OUTPUT SPEED SENSOR (VEHICLE SPEED SENSOR 1) CIRCUIT MALFUNCTION**  
 —


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No shift or excessive tight corner “braking”

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BK1</b>	<b>CHECK DTC P0720 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0720?
- YES** : Check vehicle speed sensor 1 circuit. <Ref. to 3-2 [T7L0].>
- NO** : It is not necessary to inspect DTC P0720.



OBD	(FB1)
P0725	<ATNE>
OBD0404	

**BL: DTC P0725**  
**— ENGINE SPEED INPUT CIRCUIT**  
**MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No lock-up (after engine warm-up)
- AT diagnostic indicator light (AT OIL TEMP indicator light) remains on when vehicle speed is "0".

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BL1</b>	<b>CHECK DTC P0725 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0725?
- YES** : Check engine speed input signal circuit. <Ref. to 3-2 [T7H0].>
- NO** : It is not necessary to inspect DTC P0725.

OBD	( FB 1 )
P0731	<ATGR1>
B2M0657	

**BM: DTC P0731**  
**— GEAR 1 INCORRECT RATIO —**

OBD	( FB 1 )
P0732	<ATGR2>
B2M0658	

**BN: DTC P0732**  
**— GEAR 2 INCORRECT RATIO —**

OBD	( FB 1 )
P0733	<ATGR3>
B2M0659	

**BO: DTC P0733**  
**— GEAR 3 INCORRECT RATIO —**

OBD	( FB 1 )
P0734	<ATGR4>
B2M0660	

**BP: DTC P0734**  
**— GEAR 4 INCORRECT RATIO —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effected in "3" range; excessive shift shock; excessive tight corner "braking"

WIRING DIAGRAM:



B2M1287

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BP1</b>	<b>CHECK ANY OTHER DTC (BESIDES DTC P0731, P0732, P0733, P0734) ON DISPLAY.</b>
--------------	---

- CHECK** : Is there any other DTC on display?
- YES** : Inspect relevant DTC using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>
- NO** : Go to step **10BP2**.

**10BP2****CHECK THROTTLE POSITION SENSOR CIRCUIT.**

Check throttle position sensor circuit. &lt;Ref. to 3-2 [T7K0].&gt;

**CHECK** : ***Is there any trouble in throttle position sensor circuit?*****YES** : Repair or replace throttle position sensor circuit.**NO** : Go to step **10BP3**.**10BP3****CHECK VEHICLE SPEED SENSOR 1 CIRCUIT.**

Check vehicle speed sensor 1 circuit. &lt;Ref. to 3-2 [T7L0].&gt;

**CHECK** : ***Is there any trouble in vehicle speed sensor 1 circuit?*****YES** : Repair or replace vehicle speed sensor 1 circuit.**NO** : Go to step **10BP4**.**10BP4****CHECK VEHICLE SPEED SENSOR 2 CIRCUIT.**

Check vehicle speed sensor 2 circuit. &lt;Ref. to 3-2 [T7M0].&gt;

**CHECK** : ***Is there any trouble in vehicle speed sensor 2 circuit?*****YES** : Repair or replace vehicle speed sensor 2 circuit.**NO** : Go to step **10BP5**.**10BP5****CHECK ENGINE SPEED INPUT CIRCUIT.**

Check engine speed input circuit. &lt;Ref. to 3-2 [T7H0].&gt;

**CHECK** : ***Is there any trouble in engine speed input circuit?*****YES** : Repair or replace engine speed input circuit.**NO** : Go to next **CHECK** .**CHECK** : ***Is there poor contact in TCM connector?*****YES** : Repair poor contact in TCM connector.**NO** : Go to next **CHECK** .**CHECK** : ***Is there any mechanical trouble in automatic transmission?*****YES** : Repair or replace automatic transmission.**NO** : Replace TCM.

OBD (FB1)  
 P0740 <ATLU\_F>  
 B2M0661

**BQ: DTC P0740**  
**— TORQUE CONVERTER CLUTCH SYSTEM**  
**MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No lock-up (after engine warm-up)
- No shift or excessive tight corner “braking”

**WIRING DIAGRAM:**



B2M1109

**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BQ1</b>	<b>CHECK ANY OTHER DTC (BESIDES DTC P0740) ON DISPLAY.</b>
--------------	--

**CHECK** : *Is there any other DTC on display?*

**YES** : Inspect the relevant DTC using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

**NO** : Go to step **10BQ2**.

<b>10BQ2</b>	<b>CHECK DUTY SOLENOID B CIRCUIT.</b>
--------------	---------------------------------------

Check duty solenoid B circuit. <Ref. to 3-2 [T7B0].>

**CHECK** : *Is there any trouble in duty solenoid B circuit?*

**YES** : Repair or replace duty solenoid B circuit.

**NO** : Go to step **10BQ3**.

<b>10BQ3</b>	<b>CHECK THROTTLE POSITION SENSOR CIRCUIT.</b>
--------------	--

Check throttle position sensor circuit. <Ref. to 3-2 [T7K0].>

**CHECK** : *Is there any trouble in throttle position sensor circuit?*

**YES** : Repair or replace throttle position sensor circuit.

**NO** : Go to step **10BQ4**.

<b>10BQ4</b>	<b>CHECK VEHICLE SPEED SENSOR 1 CIRCUIT.</b>
--------------	--

Check vehicle speed sensor 1 circuit. <Ref. to 3-2 [T7L0].>

**CHECK** : *Is there any trouble in vehicle speed sensor 1 circuit?*

**YES** : Repair or replace vehicle speed sensor 1 circuit.

**NO** : Go to step **10BQ5**.

<b>10BQ5</b>	<b>CHECK VEHICLE SPEED SENSOR 2 CIRCUIT.</b>
--------------	--

Check vehicle speed sensor 2 circuit. <Ref. to 3-2 [T7M0].>

**CHECK** : *Is there any trouble in vehicle speed sensor 2 circuit?*

**YES** : Repair or replace vehicle speed sensor 2 circuit.

**NO** : Go to step **10BQ6**.

<b>10BQ6</b>	<b>CHECK ENGINE SPEED INPUT CIRCUIT.</b>
--------------	--

Check engine speed input circuit. <Ref. to 3-2 [T7H0].>

**CHECK** : *Is there any trouble in engine speed input circuit?*

**YES** : Repair or replace engine speed input circuit.

**NO** : Go to step **10BQ7**.

<b>10BQ7</b>	<b>CHECK INHIBITOR SWITCH CIRCUIT.</b>
--------------	--

Check inhibitor switch circuit. <Ref. to 2-7 [T10BI0].>

**CHECK** : *Is there any trouble in inhibitor switch circuit?*

**YES** : Repair or replace inhibitor switch circuit.

**NO** : Go to step **10BQ8**.

<b>10BQ8</b>	<b>CHECK BRAKE LIGHT SWITCH CIRCUIT.</b>
--------------	--

Check brake light switch circuit. <Ref. to 2-7 [T10BH0].>

**CHECK** : *Is there any trouble in brake light switch circuit?*

**YES** : Repair or replace brake light switch circuit.

**NO** : Go to step **10BQ9**.

**10BQ9****CHECK ATF TEMPERATURE SENSOR CIRCUIT.**

Check ATF temperature sensor circuit. <Ref. to 3-2 [T7F0].>

**CHECK** : ***Is there any trouble in ATF temperature sensor circuit?***

**YES** : Repair or replace ATF temperature sensor circuit.

**NO** : Go to next **CHECK** .

**CHECK** : ***Is there poor contact in TCM connector?***

**YES** : Repair poor contact in TCM connector.

**NO** : Go to next **CHECK** .

**CHECK** : ***Is there any mechanical trouble in automatic transmission?***

**YES** : Repair or replace automatic transmission.

**NO** : Replace TCM.



OBD (FB1)  
 P0743 <ATLU>

B2M0662

**BR: DTC P0743**  
**— TORQUE CONVERTER CLUTCH SYSTEM**  
**(DUTY SOLENOID B) ELECTRICAL —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No lock-up (after engine warm-up)

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BR1 CHECK DTC P0743 ON DISPLAY.**

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0743?
- YES** : Check duty solenoid B circuit. <Ref. to 3-2 [T7B0].>
- NO** : It is not necessary to inspect DTC P0743.

OBD (FB1)  
 P0748 <ATPL>  
 B2M0663

**BS: DTC P0748**  
**— PRESSURE CONTROL SOLENOID (DUTY SOLENOID A) ELECTRICAL —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Excessive shift shock

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BS1</b>	<b>CHECK DTC P0748 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0748?
- YES** : Check duty solenoid A circuit. <Ref. to 3-2 [T7A0].>
- NO** : It is not necessary to inspect DTC P0748.

OBD (FB1)  
 P0753 <ATSFT1>  
 B2M0664

**BT: DTC P0753**  
**— SHIFT SOLENOID A (SHIFT SOLENOID 1)**  
**ELECTRICAL —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No shift

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BT1</b>	<b>CHECK DTC P0753 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0753?
- YES** : Check shift solenoid 1 circuit. <Ref. to 3-2 [T7E0].>
- NO** : It is not necessary to inspect DTC P0753.

OBD (FB1)  
 P0758 <ATSFT2>

B2M0665

**BU: DTC P0758  
 — SHIFT SOLENOID B (SHIFT SOLENOID 2)  
 ELECTRICAL —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No shift

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10BU1</b>	<b>CHECK DTC P0758 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0758?
- YES** : Check shift solenoid 2 circuit. <Ref. to 3-2 [T7D0].>
- NO** : It is not necessary to inspect DTC P0758.

OBD (FB1)  
 P0760<ATOVR\_F>  
 B2M0666

**BV: DTC P0760**  
**— SHIFT SOLENOID C (SHIFT SOLENOID 3) MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Ineffective engine brake with selector lever in “3”

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to 2-7 [T3D0] and [T3E0].>

**10BV1 CHECK ANY OTHER DTC (BESIDES DTC P0760) ON DISPLAY.**

- CHECK** : Is there any other DTC on display?
- YES** : Inspect relevant DTC using “10. Diagnostics Chart with Trouble Code”. <Ref. to 2-7 [T10A0].>
- NO** : Go to step **10BV2**.


**10BV2 CHECK INHIBITOR SWITCH CIRCUIT.**

Check inhibitor switch circuit. <Ref. to 2-7 [T10BI0].>

**CHECK** : *Is there any trouble in inhibitor switch circuit?*

**YES** : Repair or replace inhibitor switch circuit.

**NO** : Go to step **10BV3**.

**10BV3 CHECK GEAR POSITION.**

- 1) Turn ignition switch to OFF.
- 2) Connect the Subaru select monitor to data link connector.
- 3) Lift-up or raise the vehicle and support with safety stands.

**CAUTION:**

**On AWD models, raise all wheels off ground.**

- 4) Start and warm-up the engine and transmission.

- 5) Subaru select monitor switch to ON.

- 6) Select AT mode using function key.

Press the function key [ / ], and change to AT mode.


- 7) Press the function key [ 0 ].

SELECT SYSTEM  
EGi Y : 0 , N : /



SELECT SYSTEM  
AT Y : 0 , N : /

H2M1150



- 8) Designate mode using function key.

**Function mode for AT: F10**

GEAR (F10)

1 st

OBD0615

- 9) Move selector lever to "D" and drive the vehicle.

- 10) Read data on Subaru select monitor.

**CHECK** : *Does gear position change according to throttle position and vehicle speed?*

**YES** : Go to next **CHECK** .

**NO** : Go to step **10BV4**.

**CHECK** : *Is there poor contact in TCM connector?*

**YES** : Repair poor contact in TCM connector.

**NO** : Go to next **CHECK** .

**CHECK** : *Is there any mechanical trouble in automatic transmission?*

**YES** : Repair or replace automatic transmission.

**NO** : Replace TCM.

<b>10BV4</b>	<b>CHECK SHIFT SOLENOID 1 CIRCUIT.</b>
--------------	--

Check shift solenoid 1 circuit. <Ref. to 3-2 [T7E0].>

**CHECK** : *Is there any trouble in shift solenoid 1 circuit?*

**YES** : Repair or replace shift solenoid 1 circuit.

**NO** : Go to step **10BV5**.

<b>10BV5</b>	<b>CHECK SHIFT SOLENOID 2 CIRCUIT.</b>
--------------	--

Check shift solenoid 2 circuit. <Ref. to 3-2 [T7D0].>

**CHECK** : *Is there any trouble in shift solenoid 2 circuit?*

**YES** : Repair or replace shift solenoid 2 circuit.

**NO** : Go to step **10BV6**.

<b>10BV6</b>	<b>CHECK SHIFT SOLENOID 3 CIRCUIT.</b>
--------------	--

Check shift solenoid 3 circuit. <Ref. to 3-2 [T7C0].>

**CHECK** : *Is there any trouble in shift solenoid 3 circuit?*

**YES** : Repair or replace shift solenoid 3 circuit.

**NO** : Go to next **CHECK** .

**CHECK** : *Is there poor contact in TCM connector?*

**YES** : Repair poor contact in TCM connector.

**NO** : Go to next **CHECK** .

**CHECK** : *Is there any mechanical trouble in automatic transmission?*

**YES** : Repair or replace automatic transmission.

**NO** : Replace TCM.

OBD (FB1)  
 P0763 <ATOVR>

B2M0667

**BW: DTC P0763  
 — SHIFT SOLENOID C (SHIFT SOLENOID 3)  
 ELECTRICAL —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Ineffective engine brake with selector lever in “3”

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

10BW1	CHECK DTC P0763 ON DISPLAY.
-------	-----------------------------

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0763?
- YES** : Check shift solenoid 3 circuit. <Ref. to 3-2 [T7C0].>
- NO** : It is not necessary to inspect DTC P0763.




OBD (FB1)  
 P1100 <ST\_SWOFF>  
 B2M1113

**BX: DTC P1100**  
**— STARTER SWITCH CIRCUIT LOW INPUT**

**DTC DETECTING CONDITION:**  
 ● Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**  
 ● Failure of engine to start

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BX1****CHECK OPERATION OF STARTER MOTOR.**

**CHECK** : *Does starter motor operate when ignition switch to "ST"?*

NOTE:

- On AT vehicles, place the inhibitor switch in the "P" or "N" position.
- On MT vehicles, depress the clutch pedal.

**YES** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open or ground short circuit in harness between ECM and starter motor connector.
- Poor contact in ECM connector.

**NO** : Check starter motor circuit. <Ref. to 2-7 [T8B0].>

OBD (FB1)  
 P1101 <N\_SW>  
 B2M1114

**BY: DTC P1101**  
**— NEUTRAL POSITION SWITCH CIRCUIT MALFUNCTION [MT VEHICLES] —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling



**WIRING DIAGRAM:**



B2M0588

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BY1 CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 (+) — Chassis ground (-): Is the voltage between 4.5 and 5.5 V in neutral position?**

**YES** : Go to next **CHECK** .

**NO** : Go to step **10BY2**.

**CHECK** : **Connector & terminal (B84) No. 82 (+) — Chassis ground (-): Is the voltage less than 1 V in other positions?**

**YES** : Go to next **CHECK** .

**NO** : Go to step **10BY2**.


**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**10BY2 CHECK NEUTRAL POSITION SWITCH.**


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from transmission harness.
- 3) Measure resistance between transmission harness and connector terminals.

**CHECK** : **Connector & terminal (T2) No. 1 — No. 2:**  
**Is the resistance more than 1 MΩ in neutral position?**

**YES** : Go to next **CHECK** .  
**NO** : Repair short circuit in transmission harness or replace neutral position switch.

**CHECK** : **Connector & terminal (T2) No. 1 — No. 2:**  
**Is the resistance less than 1 Ω in other positions?**

**YES** : Go to step **10BY3**.  
**NO** : Repair open circuit in transmission harness or replace neutral position switch.




**10BY3 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH.**

- 1) Disconnect connector from ECM.
- 2) Measure resistance of harness between ECM and transmission harness connector.

**CHECK** : **Connector & terminal (B84) No. 82 — (B25) No. 1:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to next step 3).  
**NO** : Repair open circuit in harness between ECM and transmission harness connector.




- 3) Measure resistance between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and transmission harness connector.

**NO** : Go to next step 4).



4) Measure resistance of harness between transmission harness connector and engine ground.

**CHECK** : **Connector & terminal (B25) No. 2 — Engine ground:**  
**Is the resistance less than 5 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between transmission harness connector and engine grounding terminal
- Poor contact in coupling connector (B22)

**CHECK** : **Is there poor contact in transmission harness connector?**

**YES** : Repair poor contact in transmission harness connector.

**NO** : Replace ECM.

OBD (FB1)  
 P1101 <N\_SWOFF>  
 B2M1115

**BZ: DTC P1101**  
**— NEUTRAL POSITION SWITCH CIRCUIT**  
**HIGH INPUT [AT VEHICLES] —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling


**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10BZ1 CHECK DTC P0705 ON DISPLAY.**

- CHECK** : Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0705?
- YES** : Inspect DTC P0705 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>
- NO** : Go to step **10BZ2**.

**10BZ2 CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 (+) — Chassis ground (-): Is the voltage less than 1 V in "N" and "P" positions?**


- YES** : Go to next **CHECK** .
- NO** : Go to step **10BZ3**.

**CHECK** : **Connector & terminal (B84) No. 82 (+) — Chassis ground (-): Is the voltage between 4.5 and 5.5 V in other positions?**

- YES** : Go to next **CHECK** .
- NO** : Go to step **10BZ3**.

**CHECK** : **Is there poor contact in ECM connector?**


- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM.

**10BZ3 CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 (+) — Chassis ground (-): Is the voltage more than 10 V?**


- YES** : Repair battery short circuit in harness between ECM and inhibitor switch connector.
- NO** : Go to step **10BZ4**.

**10BZ4 CHECK INHIBITOR SWITCH TYPE.**

**CHECK** : **Is inhibitor switch type plastic body?**

- YES** : Go to step **10BZ5**.
- NO** : Go to step **10BZ7**.





**10BZ5 CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and inhibitor switch.
- 3) Measure resistance of harness between ECM and inhibitor switch connector.

**CHECK** : **Connector & terminal (B84) No. 82 — (T7) No. 1:**  
**Is the resistance less than 1 Ω?**


**YES** : Go to next step 4).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)
- Poor contact in inhibitor switch connector
- Poor contact in ECM connector




- 4) Measure resistance of harness between inhibitor switch connector and engine ground.

**CHECK** : **Connector & terminal (T7) No. 2 — Engine ground:**  
**Is the resistance less than 5 Ω?**

**YES** : Go to step 10BZ6.

**NO** : Repair open circuit in inhibitor switch ground line.

**10BZ6 CHECK INHIBITOR SWITCH.**

Measure resistance between inhibitor switch connector receptacle's terminals.

**CHECK** : **Terminals**

**No. 1 — No. 2:**

**Is the resistance less than 1 Ω in "N" and "P" positions?**


**YES** : Go to next **CHECK** .

**NO** : Replace inhibitor switch.

**CHECK** : **Is there any fault in selector cable connection to inhibitor switch?**

**YES** : Repair selector cable connection. <Ref. to 3-2 [W2B2].>

**NO** : Replace ECM.

**10BZ7 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and transmission harness connector.
- 3) Measure resistance of harness between ECM and transmission harness connector.

**CHECK** : **Connector & terminal**

**(B84) No. 82 — (B12) No. 12:**

**Is the resistance less than 1 Ω?**


**YES** : Go to next step 4).

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and transmission harness connector
- Poor contact in transmission harness connector
- Poor contact in ECM connector



- 4) Measure resistance of harness between transmission harness connector and engine ground.


**CHECK** : **Connector & terminal**

**(B12) No. 11 — Engine ground:**

**Is the resistance less than 5 Ω?**

**YES** : Go to step **10BZ8**.

**NO** : Repair open circuit in inhibitor switch ground line.

**10BZ8 CHECK INHIBITOR SWITCH.**

Measure resistance between transmission harness connector receptacle's terminals.

- CHECK** : **Connector & terminal (T3) No. 12 — No. 11:**  
**Is the resistance less than 1 Ω in "N" and "P" positions?**
- YES** : Go to next **CHECK** .
- NO** : Replace inhibitor switch.
- CHECK** : **Is there any fault in selector cable connection to inhibitor switch?**
- YES** : Repair selector cable connection. <Ref. to 3-2 [W2B2].>
- NO** : Replace ECM.

OBD	(FB1)
P1102	 

OBD0481

**CA: DTC P1102**  
**— PRESSURE SOURCES SWITCHING SOLENOID VALVE CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Failure of engine to start


**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODE**.

<Ref. to 2-7 [T3D0] and [T3E0].>



**10CA1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal**  
**(B84) No. 15 (+) — Chassis ground (-):**  
**Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Go to step **10CA2**.


**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




**10CA2 CHECK HARNESS BETWEEN ECM AND PRESSURE SOURCES SWITCHING SOLENOID VALVE CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from pressure sources switching solenoid valve and ECM.
- 3) Measure resistance of harness between pressure sources switching solenoid valve connector and engine ground.

**CHECK** : **Connector & terminal (B1) No. 1 — Engine ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and pressure sources switching solenoid valve connector.

**NO** : Go to next step 4).




- 4) Measure resistance of harness between ECM and pressure sources switching solenoid valve connector.

**CHECK** : **Connector & terminal (B84) No. 15 — (B1) No. 1:**  
**Is the resistance less than 1 Ω?**

**YES** : Go to step 10CA3.

**NO** : Repair open circuit in harness between ECM and pressure sources switching solenoid valve connector.




**10CA3 CHECK PRESSURE SOURCES SWITCHING SOLENOID VALVE.**

Measure resistance between pressure sources switching solenoid valve connector terminals.

**CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance between 10 and 100 Ω?**

**YES** : Go to step 10CA4.

**NO** : Replace pressure sources switching solenoid valve.



10CA4

### CHECK POWER SUPPLY TO PRESSURE SOURCES SWITCHING SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between pressure sources switching solenoid valve harness connector and engine ground.

**CHECK** : **Connector & terminal (B1) No. 2 (+) — Engine ground (-): Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between main relay and pressure sources switching solenoid valve connector.

**CHECK** : **Is there poor contact in pressure sources switching solenoid valve connector?**

**YES** : Repair poor contact in pressure sources switching solenoid valve connector.

**NO** : Contact with SOA service.

#### NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD	(FB1)
P1103	<TRQ>
OBD0489	

**CB: DTC P1103**  
**— ENGINE TORQUE CONTROL SIGNAL**  
**CIRCUIT MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Excessive shift shock


**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

**10CB1 CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 79 (+) — Chassis ground (-): Is the voltage more than 4.5 V?**


**YES** : Go to next **CHECK** .

**NO** : Go to step **10CB2**.

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.

**10CB2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**


- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and TCM connector.

**CHECK** : **Connector & terminal (B84) No. 79 — (B55) No. 16: Is the resistance less than 1 Ω?**

**YES** : Go to next step 4).

**NO** : Repair open circuit in harness between ECM and TCM connector.





4) Measure resistance of harness between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 79 — Chassis ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and TCM connector.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in TCM connector?**

**YES** : Repair poor contact in TCM connector.

**NO** : Replace TCM.

OBD (FB1)  
 P1104 <TCS\_LOW>  
 B2M1121

**CC: DTC P1104**  
**— TCS SIGNAL CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**TROUBLE SYMPTOM:**

- No operation TCS
- TCS warning light remains illuminated.

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>




**10CC1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 61 (+) — Chassis ground (-): Is the voltage more than 2 V?**

**YES** : Repair poor contact in ECM connector.

**NO** : Go to step **10CC2**.



**10CC2 CHECK HARNESS BETWEEN ECM AND TCS C/M CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove front passenger side seat.
- 3) Tear off the floor mat.
- 4) Disconnect connectors from ECM and TCS C/M.
- 5) Measure resistance of harness between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 61 — Chassis ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and TCS C/M connector.

**NO** : Replace TCS C/M.

OBD (FB1)  
 P1120 <ST\_SWON>  
 B2M1122

**CD: DTC P1120**  
**— STARTER SWITCH CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Failure of engine to start

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

10CD1

**CHECK OPERATION OF STARTER MOTOR.**

**CHECK** : *Does starter motor operate when ignition switch to "ON"?*

## NOTE:

- On AT vehicles, place the inhibitor switch in each position.
- On MT vehicles, depress or release the clutch pedal.

**YES** : Repair battery short circuit in starter motor circuit. After repair, replace ECM.

**NO** : Check starter motor circuit. <Ref. to 2-7 [T8B0].>

OBD (FB1)  
 P1121 <N\_SWON>  
 B2M1123

**CE: DTC P1121**  
**— NEUTRAL POSITION SWITCH CIRCUIT**  
**LOW INPUT [AT VEHICLES] —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling

**WIRING DIAGRAM:**




**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10CE1 CHECK DTC P0705 ON DISPLAY.**

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0705?*

**YES** : Inspect DTC P0705 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

**NO** : Go to step **10CE2**.



**10CE2 CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 (+) — Chassis ground (-): Is the voltage between 4.5 and 5.5 V in other positions?**

**YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time.


**NO** : Go to step **10CE3**.

**10CE3 CHECK INHIBITOR SWITCH TYPE.**

**CHECK** : *Is inhibitor switch type plastic body?*

**YES** : Go to step **10CE4**.

**NO** : Go to step **10CE7**.

**10CE4****CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and transmission harness connector.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 — Chassis ground:**  
**Is the resistance less than 10  $\Omega$ ?**

**YES** : Repair ground short circuit in harness between ECM and transmission harness connector.

**NO** : Go to step **10CE5**.


**10CE5****CHECK TRANSMISSION HARNESS CONNECTOR.**

- 1) Disconnect connector from inhibitor switch.
- 2) Measure resistance of harness between transmission harness connector and engine ground.

**CHECK** : **Connector & terminal (T3) No. 12 — Engine ground:**  
**Is the resistance less than 10  $\Omega$ ?**

**YES** : Repair ground short circuit in harness between transmission harness and inhibitor switch connector.

**NO** : Go to step **10CE6**.

**10CE6****CHECK INHIBITOR SWITCH.**

Measure resistance between inhibitor switch connector receptacle's terminals.

**CHECK** : **Terminals No. 1 — No. 2:**  
**Is the resistance more than 1 M $\Omega$  in other positions?**

**YES** : Go to next **CHECK** .

**NO** : Replace inhibitor switch.




**CHECK** : *Is there any fault in selector cable connection to inhibitor switch?*

**YES** : Repair selector cable connection. <Ref. to 3-2 [W2B2].>

**NO** : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




**10CE7 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and transmission harness connector.
- 3) Measure resistance of harness between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 82 — Chassis ground:**  
*Is the resistance less than 10 Ω?*

**YES** : Repair short circuit in harness between ECM and transmission harness connector.

**NO** : Go to step 10CE8.



**10CE8 CHECK INHIBITOR SWITCH.**

Measure resistance between transmission harness connector receptacle's terminals.

**CHECK** : **Connector & terminal (T3) No. 12 — No. 11:**  
*Is the resistance more than 1 MΩ in other positions?*

**YES** : Go to next **CHECK** .

**NO** : Replace inhibitor switch.

**CHECK** : *Is there any fault in selector cable connection to inhibitor switch?*

**YES** : Repair selector cable connection. <Ref. to 3-2 [W2B2].>

**NO** : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD (FB1)  
 P1122 <BR\_HI>  
 B2M1124

**CF: DTC P1122**  
**— PRESSURE SOURCES SWITCHING SOLENOID VALVE CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Failure of engine to start

**WIRING DIAGRAM:**




B2M1308

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODE.

<Ref. to 2-7 [T3D0] and [T3E0].>



**10CF1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 15 (+) — Chassis ground (-): Is the voltage more than 10 V?**


**YES** : Go to step 10CF2.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.




**10CF2 CHECK HARNESS BETWEEN ECM AND PRESSURE SOURCES SWITCHING SOLENOID VALVE CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from pressure sources switching solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 15 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and pressure sources switching solenoid valve connector. After repair, replace ECM.

**NO** : Go to next step 5).



- 5) Turn ignition switch to OFF.
- 6) Measure resistance between pressure sources switching solenoid valve connector terminals.

**CHECK** : **Terminals**

**No. 1 — No. 2:**

**Is the resistance less than 1 Ω?**

**YES** : Replace pressure sources switching solenoid valve and ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.

OBD (FB1)  
 P1124 <TCS\_HI>  
 B2M1125

**CG: DTC P1124**  
**— TCS SIGNAL CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- No operation TCS
- TCS warning light remains illuminated.

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.


<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10CG1</b>	<b>CHECK IF THE VEHICLE IS EQUIPPED WITH TCS.</b>
--------------	---

**CHECK** : *Is the vehicle equipped with TCS?*

**YES** : Go to step **10CG2**.

**NO** : Go to step **10CG5**.



<b>10CG2</b>	<b>CHECK OUTPUT SIGNAL FROM ECM.</b>
--------------	--------------------------------------


1) Turn ignition switch to ON.

2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 61 (+) — Chassis ground (-): Is the voltage more than 2 V?**

**YES** : Go to step **10CG3**.

**NO** : Go to step **10CG4**.



<b>10CG3</b>	<b>CHECK HARNESS BETWEEN ECM AND TCS C/M CONNECTOR.</b>
--------------	---

1) Turn ignition switch to OFF.

2) Remove front passenger side seat.

3) Tear off the floor mat.


4) Disconnect connectors from ECM and TCS C/M.

5) Measure voltage between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 61 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and TCS C/M connector.

**NO** : Go to next step 6).




6) Turn ignition switch to ON.

7) Measure voltage between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 61 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and TCS C/M connector.

**NO** : Repair poor contact in ECM connector.



**10CG4 CHECK HARNESS BETWEEN ECM AND TCS C/M CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove front passenger side seat.
- 3) Tear off the floor mat.
- 4) Disconnect connectors from ECM and TCS C/M.
- 5) Measure resistance of harness between ECM and TCS C/M connector.

**CHECK** : **Connector & terminal (B84) No. 61 — (P6) No. 4:**  
*Is the resistance less than 1 Ω?*


**YES** : Repair poor contact in TCS C/M connector.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and TCS C/M connector
- Poor contact in ECM connector
- Poor contact in TCS C/M connector
- Poor contact in S.M.J. connector (B63)



**10CG5 CHECK ECM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 75 (+) — Chassis ground (-):**  
*Is the voltage more than 2 V?*

**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM connector and engine grounding terminal
- Poor contact in engine grounding terminal
- Poor contact in coupling connector (B22)

**NO** : Repair poor contact in ECM connector.

OBD (FB1)  
 P1141 <QA\_RHI>  
 B2M1126

**CH: DTC P1141**  
**— MASS AIR FLOW SENSOR CIRCUIT**  
**RANGE/PERFORMANCE PROBLEM (HIGH**  
**INPUT) —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**WIRING DIAGRAM:**



B2M1057

**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10CH1****CHECK DTC P0102 OR P0103 ON DISPLAY.****CHECK****: Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0102 or P0103?****YES****: Inspect DTC P0102 or P0103 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>****NOTE:****In this case, it is not necessary to inspect DTC P1141.****NO****: Replace mass air flow sensor.**

OBD (FB1)  
 P1142 <TH\_RLOW>  
 B2M1127

**CI: DTC P1142**  
**— THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>


**10C11****CHECK DTC P0122 OR P0123 ON DISPLAY.****CHECK****: Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0122 or P0123?****YES****: Inspect DTC P0122 or P0123 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>****NOTE:****In this case, it is not necessary to inspect DTC P1142.****NO****: Replace throttle position sensor.**

OBD (FB1)  
 P1143 <PS\_RLOW>  
 B2M1128

**CJ: DTC P1143**  
**— PRESSURE SENSOR CIRCUIT**  
**RANGE/PERFORMANCE PROBLEM (LOW**  
**INPUT) —**



- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M1308

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10CJ1 CHECK DATA FOR CONTROL.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch ON and Subaru Select Monitor or the OBD-II general scan tool switch ON.
- 4) Start engine.
- 5) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F20**

- F20: Display shows pressure signal value sent from the pressure sensor.

**CHECK** : *Is the value less than 32 kPa in function mode F20?*

**YES** : Go to step **10CJ3**.

**NO** : Go to step **10CJ2**.

- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

BARO. P (F 2 0)

1 0 0 kPa 752 mmHg

B2M0755

**10CJ2 CHECK PRESSURE SENSOR.**

- 1) Measure actual atmospheric pressure.
- 2) Read data on Subaru Select Monitor or OBD-II general scan tool.

- Subaru Select Monitor
- Designate mode using function key.

**Function mode: F20**

- F20: Display shows pressure signal value sent from the pressure sensor.


**CHECK** : *Is the difference between absolute value of Subaru Selector Monitor indication and actual atmospheric pressure greater than 10 kPa (0.102 kg/cm<sup>2</sup>, 1.45 psi)?*

**YES** : Replace pressure sensor.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**2200 cc AWD except Taiwan spec. vehicles****10CJ3 CHECK VACUUM HOSE.**

**CHECK** : *Is there a fault in vacuum hose?*


**NOTE:**



Check the following item.

Incorrect hose connections in line between the pressure sources switching solenoid valve and pressure sensor, intake manifold and/or CPC solenoid valve.

**YES** : Repair or replace hoses or filter.

**NO** : Go to step **10CJ4**.

**2200 cc FWD and Taiwan spec. vehicles**



**10CJ4 CHECK PRESSURE SOURCES SWITCHING SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.
- 3) Turn ignition switch to ON.

**CHECK** : **Does pressure sources switching solenoid valve produce operating sound? (ON ↔ OFF each 1.5 sec.)**

**NOTE:**  
 Pressure sources switching solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD10). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>


- YES** : Replace pressure sensor.
- NO** : Replace pressure sources switching solenoid valve.

OBD (FB1)  
 P1144 <PS\_RHI>  
 B2M1129

**CK: DTC P1144**  
**— PRESSURE SENSOR CIRCUIT**  
**RANGE/PERFORMANCE PROBLEM (HIGH**  
**INPUT) —**

**DTC DETECTING CONDITION:**  
 ● Two consecutive driving cycles with fault


**WIRING DIAGRAM:**



B2M1308

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>





**10CK1 CHECK DATA FOR CONTROL.**

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.
- 3) Turn ignition switch ON and Subaru Select Monitor or the OBD-II general scan tool switch ON.
- 4) Start engine.
- 5) Read data on Subaru Select Monitor or the OBD-II general scan tool.

- Subaru Select Monitor  
Designate mode using function key.

**Function mode: F20**

- F20: Display shows pressure signal value sent from the pressure sensor.

BARO. P ( F 2 0 )

1 0 0kPa752mmHg

B2M0755

**CHECK** : *Is the value more than 133 kPa in function mode F20?*

**YES** : Replace pressure sensor.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.


- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

OBD (FB1)  
 P1400<PCVSOL\_LO>  
 B2M1130

**CL: DTC P1400**  
**— FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —**


- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M0928

**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10CL1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 10 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Go to step **10CL2**.


**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




**10CL2 CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from fuel tank pressure control solenoid valve and ECM.
- 3) Measure resistance of harness between fuel tank pressure control solenoid valve connector and chassis ground.

**CHECK** : **Connector & terminal (R68) No. 2 — Chassis ground: Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between ECM and fuel tank pressure control solenoid valve connector.

**NO** : Go to next step 4).



4) Measure resistance of harness between ECM and fuel tank pressure control solenoid valve connector.

**CHECK** : **Connector & terminal**  
**(B84) No. 10 — (R68) No. 2:**  
**Is the voltage less than 1 Ω?**


**YES** : Go to step 10CL3.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure control solenoid valve connector
- Poor contact in coupling connectors (B98 and R57)




<b>10CL3</b>	<b>CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.</b>
--------------	---

Measure resistance between fuel tank pressure control solenoid valve terminals.

**CHECK** : **Terminals**  
**No. 1 — No. 2:**  
**Is the resistance between 10 and 100 Ω?**

**YES** : Go to step 10CL4.

**NO** : Replace fuel tank pressure control solenoid valve.

**10CL4****CHECK POWER SUPPLY TO FUEL TANK PRESSURE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between fuel tank pressure control solenoid valve and chassis ground.

**CHECK** : **Connector & terminal (R68) No. 1 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between main relay and fuel tank pressure control solenoid valve connector
- Poor contact in coupling connectors (B97 and R57)
- Poor contact in main relay connector

**CHECK** : **Is there poor contact in fuel tank pressure control solenoid valve connector?**

**YES** : Repair poor contact in fuel tank pressure control solenoid valve connector.

**NO** : Contact with SOA service.

**NOTE:**


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD (FB1)  
 P1420<PCVSOL\_HI>  
 B2M1131

**CM: DTC P1420**  
**— FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —**


- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M0928

**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10CM1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 10 (+) — Chassis ground (-): Is the voltage more than 10 V?**


**YES** : Go to step **10CM2**.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.




**10CM2 CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel tank pressure control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 10 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and fuel tank pressure control solenoid valve connector. After repair, replace ECM.

**NO** : Go to next step 5).



- 5) Turn ignition switch to OFF.
- 6) Measure resistance between fuel tank pressure control solenoid valve terminals.

**CHECK** : **Terminals**

**No. 1 — No. 2:**

**Is the resistance less than 1 Ω?**

**YES** : Replace fuel tank pressure control solenoid valve and ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.



OBD (FB1)  
 P1421<EGRSOL\_HI>  
 B2M1132

**CN: DTC P1421**  
**— EXHAUST GAS RECIRCULATION CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Poor driving performance on low engine speed


**WIRING DIAGRAM:**




**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10CN1 CHECK ENGINE/TRANSMISSION TYPE.**


- CHECK** : *Is engine/transmission type 2200 cc/MT?*
- YES** : Check AT/MT identification circuit. <Ref. to 2-7 [T10DD0].>
- NO** : Go to step **10CN2**.

**10CN2 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
  - 2) Measure voltage between ECM and chassis ground.
- CHECK** : **Connector & terminal (B84) No. 71 (+) — Chassis ground (-): Is the voltage more than 10 V?**
- YES** : Go to step **10CN3**.
- NO** : Go to next **CHECK** .
- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM.

**10CN3 CHECK HARNESS BETWEEN EGR SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
  - 2) Disconnect connector from EGR solenoid valve.
  - 3) Turn ignition switch to ON.
  - 4) Measure voltage between ECM and chassis ground.
- CHECK** : **Connector & terminal (B84) No. 71 (+) — Chassis ground (-): Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and EGR solenoid valve connector. After repair, replace ECM.
- NO** : Go to next step 5).



- 5) Turn ignition switch to OFF.  
 6) Measure resistance between EGR solenoid valve terminals.

**CHECK** : **Terminals**

**No. 1 — No. 2:**

**Is the resistance less than 1 Ω?**

**YES** : Replace EGR solenoid valve and ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.

OBD ( FB1 )  
P1422 <CPC\_HI>  
B2M1133

CO: DTC P1422  
— EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH INPUT —


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

TROUBLE SYMPTOM:


- Erroneous idling

WIRING DIAGRAM:



B2M1310

**CAUTION:**  
After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
<Ref. to 2-7 [T3D0] and [T3E0].>



**10C01 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 72 (+) — Chassis ground (-): Is the voltage more than 10 V?**


**YES** : Go to step 10C02.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.




**10C02 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from purge control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 72 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace ECM.

**NO** : Go to next step 5).



- 5) Turn ignition switch to OFF.
- 6) Measure resistance between purge control solenoid valve terminals.

**CHECK** : **Terminals**

**No. 1 — No. 2:**

**Is the resistance less than 1 Ω?**

**YES** : Replace purge control solenoid valve and ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.


**NO** : Replace ECM.

OBD (FB1)  
 P1423 <VCMSOL\_HI>  
 B2M1134


**CP: DTC P1423**  
**— EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL HIGH INPUT —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10CP1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 35 (+) — Chassis ground (-): Is the voltage more than 10 V?*


**YES** : Go to step **10CP2**.

**NO** : Go to next **CHECK** .

**CHECK** : *Is there poor contact in ECM connector?*

**YES** : Repair poor contact in ECM connector.

**NO** : Replace ECM.

**10CP2 CHECK HARNESS BETWEEN VENT CONTROL SOLENOID VALVE AND ECM CONNECTOR.**


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from vent control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**CHECK** : *Connector & terminal (B84) No. 35 (+) — Chassis ground (-): Is the voltage more than 10 V?*

**YES** : Repair battery short circuit in harness between ECM and vent control solenoid valve connector. After repair, replace ECM.

**NO** : Go to next step 5).





5) Turn ignition switch to OFF.

6) Measure resistance between vent control solenoid valve terminals.

**CHECK** : **Terminals**

**No. 1 — No. 2:**

**Is the resistance less than 1 Ω?**

**YES** : Replace vent control solenoid valve and ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.


**NO** : Replace ECM.

OBD (FB1)  
 P1440 <PCV\_FLOW>  
 B2M1135

**CQ: DTC P1440**  
**— FUEL TANK PRESSURE CONTROL SYSTEM FUNCTION PROBLEM (LOW INPUT)**  
 —


**DTC DETECTING CONDITION:**  
 ● Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M0928

**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



<b>10CQ1</b>	<b>CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.</b>
--------------	---

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.
- 3) Turn ignition switch to ON.

**CHECK** : **Does fuel tank pressure control solenoid valve produce operating sound?**

**NOTE:**

Fuel tank pressure control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD07). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CQ2**.

**NO** : Replace fuel tank pressure control solenoid valve.

<b>10CQ2</b>	<b>CHECK FUEL FILLER CAP AND FUEL FILLER PIPE.</b>
--------------	--

- 1) Turn ignition switch to OFF.
- 2) Open the fuel flap.

**CHECK** : **Is the fuel filler cap tightened securely?**


**YES** : Tighten fuel filler cap securely.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there any damage to the seal between fuel filler cap and fuel filler pipe?**

**YES** : Repair or replace fuel filler cap and fuel filler pipe.

**NO** : Go to step **10CQ3**.



<b>10CQ3</b>	<b>CHECK VENT CONTROL SOLENOID VALVE.</b>
--------------	---

Turn ignition switch to ON.


**CHECK** : *Does vent control solenoid valve produce operating sound?*

**NOTE:**

Vent control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD08). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CQ4**.

**NO** : Replace vent control solenoid valve.



<b>10CQ4</b>	<b>CHECK PURGE CONTROL SOLENOID VALVE.</b>
--------------	--

**CHECK** : *Does purge control solenoid valve produce operating sound?*

**NOTE:**

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD02). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CQ5**.

**NO** : Replace purge control solenoid valve.

**10CQ5****CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.**

Turn ignition switch to OFF.

**CHECK** : ***Does fuel leak in fuel line?***

**YES** : Repair or replace fuel line.

**NO** : Go to next **CHECK** .

**CHECK** : ***Is there any damage at canister?***

**YES** : Repair or replace canister.

**NO** : Go to next **CHECK** .

**CHECK** : ***Is there any damage at fuel tank?***

**YES** : Repair or replace fuel tank.

**NO** : Go to next **CHECK** .

**CHECK** : ***Are there holes, cracks or disconnections of hoses or pipes in evaporative emission control system?***

**YES** : Repair or replace hoses or pipes.

**NO** : Contact with SOA service.

NOTE:


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

OBD (FB1)  
 P1441 <PCV\_FHI>  
 B2M1136

**CR: DTC P1441**  
**— FUEL TANK PRESSURE CONTROL SYSTEM FUNCTION PROBLEM (HIGH INPUT)**  
 —


**DTC DETECTING CONDITION:**  
 ● Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



B2M0928

**CAUTION:**  
 After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>



**10CR1 CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.
- 3) Turn ignition switch to ON.

**CHECK** : *Does fuel tank pressure control solenoid valve produce operating sound?*

**NOTE:**

Fuel tank pressure control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD07). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CR2**.

**NO** : Replace fuel tank pressure control solenoid valve.


**10CR2 CHECK FUEL FILLER CAP AND FUEL FILLER PIPE.**

- 1) Turn ignition switch to OFF.
- 2) Open the fuel flap.

**CHECK** : *Is there any damage at fuel filler cap and fuel filler pipe?*

**YES** : Repair or replace fuel filler cap and fuel filler pipe.

**NO** : Go to step **10CR3**.



**10CR3 CHECK VENT CONTROL SOLENOID VALVE.**

Turn ignition switch to ON.


**CHECK** : *Does vent control solenoid valve produce operating sound?*

**NOTE:**

Vent control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD08). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CR4**.

**NO** : Replace vent control solenoid valve.



<b>10CR4</b>	<b>CHECK PURGE CONTROL SOLENOID VALVE.</b>
--------------	--

**CHECK** : *Does purge control solenoid valve produce operating sound?*

**NOTE:**

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor (Function mode: FD02). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CR5**.

**NO** : Replace purge control solenoid valve.

<b>10CR5</b>	<b>CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.</b>
--------------	--

Turn ignition switch to OFF.

**CHECK** : *Is there any damage at canister?*

**YES** : Repair or replace canister.

**NO** : Go to next **CHECK** .

**CHECK** : *Is there any damage at fuel tank?*

**YES** : Repair or replace fuel tank.

**NO** : Go to next **CHECK** .

**CHECK** : *Is there clogging of hoses or pipes in evaporative emission control system?*

**YES** : Repair or replace hoses or pipes.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




OBD (FB1)  
 P1442 <FLVL\_R2>  
 B2M1137

**CS: DTC P1442**  
**— FUEL LEVEL SENSOR CIRCUIT RANGE/**  
**PERFORMANCE PROBLEM 2 —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10CS1****CHECK DTC P0461, P0462 OR P0463 ON DISPLAY.****CHECK****: Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0461, P0462 or P0463?****YES****: Inspect DTC P0461, P0462 or P0463 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>****NOTE:****In this case, it is not necessary to inspect this trouble.****NO****: Replace fuel sending unit and fuel sub meter unit.**

OBD (FB1)

P1500 <FAN\_1>

OBD0527

**CT: DTC P1500**  
**— RADIATOR FAN RELAY 1 CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Radiator fan does not operate properly.
- Overheating

**WIRING DIAGRAM:**





B2M1289

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODE.

<Ref. to 2-7 [T3D0] and [T3E0].>

**10CT1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.
- 3) Turn ignition switch to ON.

- 4) Measure voltage between ECM and chassis ground.


**CHECK** : **Connector & terminal**  
**(B84) No. 74 (+) — Chassis ground:**  
**Does voltage change between 0 and 10**  
**volts?**

**NOTE:**

Radiator fan relay operation check can be executed using Subaru Select Monitor (Function mode: FD03). For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Repair poor contact in ECM connector.

**NO** : Go to step **10CT2**.


**10CT2 CHECK GROUND SHORT CIRCUIT IN RADIATOR FAN RELAY 1 CONTROL CIRCUIT.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal**  
**(B84) No. 74 — Chassis ground:**  
**Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in radiator fan relay 1 control circuit.

**NO** : Go to step **10CT3**.



**10CT3 CHECK POWER SUPPLY FOR RELAY.**

- 1) Disconnect connector (B52) from fuse and relay box (F/B).
- 2) Turn ignition switch to ON.
- 3) Measure voltage between fuse and relay box (F/B) connector and chassis ground.

**CHECK** : **Connector & terminal (B52) No. 4 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Go to step 10CT4.


**NO** : Repair open circuit in harness between ignition switch and fuse and relay box (F/B) connector.

**10CT4 CHECK VEHICLE MODEL.**

**CHECK** : **Is the vehicle equipped with A/C?**

**YES** : Go to step 10CT5.

**NO** : Go to step 10CT6.




**10CT5 CHECK POWER SUPPLY FOR MAIN FAN RELAY 1.**

- 1) Turn ignition switch to OFF.
- 2) Connect connector (B52) to fuse and relay box (F/B).
- 3) Remove main fan relay 1.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between main fan relay 1 connector and chassis ground.

**CHECK** : **Connector & terminal (F28) No. 1 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Go to step 10CT6.

**NO** : Repair open circuit in harness between fuse and relay box (F/B) and main fan relay 1 connector.


**10CT6****CHECK MAIN FAN RELAY 1, SUB FAN RELAY 1 AND MAIN FAN RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between main fan relay 1 terminals. (With A/C models only)

**CHECK** : **Terminal No. 1 — No. 3:**  
**Is the resistance between 87 and 107 Ω?**

**YES** : Go to next step 3).

**NO** : Replace main fan relay 1.




- 3) Remove sub fan relay 1. (With A/C models only)  
Remove main fan relay. (Without A/C models only)
- 4) Measure resistance between sub fan relay 1 or main fan relay terminals.

**CHECK** : **Terminal No. 1 — No. 3:**  
**Is the resistance between 83 and 117 Ω?**

**YES** : Go to step 10CT7.

**NO** : Replace sub fan relay 1.



**10CT7**

**CHECK OPEN CIRCUIT IN RADIATOR FAN RELAY 1 CONTROL CIRCUIT.**

- 1) Disconnect connector (F40) from fuse and relay box (F/B).
- 2) Measure resistance of harness between ECM and main fan relay 1 connector.

NOTE:

With A/C models only.

**CHECK** : **Connector & terminal (B84) No. 74 — (F28) No. 3: Is the resistance less than 1 Ω?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and main fan relay 1 connector
- Poor contact in coupling connector (F45)

**CHECK** : **Is there poor contact in ECM or main fan relay 1 connector?**

**YES** : Repair poor contact in ECM or main fan relay 1 connector.

**NO** : Go to next step 3).



3) Measure resistance of harness between ECM and sub fan relay 1 (with A/C models) or main fan relay (without A/C models) connector.

**CHECK** : **Connector & terminal (B84) No. 74 — (F40) No. 4:**  
**Is the resistance less than 1  $\Omega$ ?**

**YES** : Go to next **CHECK** .

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and sub fan relay 1 (with A/C models) or main fan relay (without A/C models) connector
- Poor contact in coupling connector (F45)
- Replace diode (A/C)

**CHECK** : **Is there poor contact in ECM or sub fan relay 1 (with A/C models) or main fan relay (without A/C models) connector?**

**YES** : Repair poor contact in ECM or sub fan relay 1 (with A/C models) or main fan relay (without A/C models) connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



OBD (FB1)

P1502 <FAN\_F>

OBD0538

**CU: DTC P1502**  
**— RADIATOR FAN FUNCTION PROBLEM —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Occurrence of noise
- Overheating

**WIRING DIAGRAM:**



B2M1290

**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.

<Ref. to 2-7 [T3D0] and [T3E0].>

**NOTE:**

If the vehicle, with the engine idling, is placed very close to a wall or another vehicle, preventing normal cooling function, the OBD system may detect malfunction.

<b>10CU1</b>	<b>CHECK ANY OTHER DTC (BESIDE DTC P1502) ON DISPLAY.</b>
--------------	---

**CHECK** : *Is there any other DTC on display?*

**YES** : Inspect the relevant DTC using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

**NO** : Check engine cooling system. <Ref. to 2-5 [K100].>

OBD (FB1)  
 P1507 <ISC\_SHI>  
 B2M1140

**CV: DTC P1507**  
**— IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.

**WIRING DIAGRAM:**



B2M1311

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10CV1</b>	<b>CHECK DTC P0505 ON DISPLAY.</b>
--------------	------------------------------------

**CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P0505?*

**YES** : Inspect DTC P0505 using "10. Diagnostics Chart with Trouble Code". <Ref. to 2-7 [T10A0].>

NOTE:

In this case, it is not necessary to inspect DTC P1507.

**NO** : Go to step **10CV2**.

<b>10CV2</b>	<b>CHECK AIR INTAKE SYSTEM.</b>
--------------	---------------------------------

1) Turn ignition switch to ON.

2) Start engine, and idle it.

**CHECK** : *Is there a fault in air intake system?*

NOTE:

Check the following items.

- Loose installation of intake manifold, idle air control solenoid valve and throttle body
- Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket
- Loose connections and cracks of idle air control solenoid valve by-pass hoses
- Disconnections of vacuum hoses

**YES** : Repair air suction and leaks.

**NO** : Replace idle air control solenoid valve.

OBD (FB1)  
 P1520 <FAN\_1HI>  
 B2M1141

**CW: DTC P1520**  
**— RADIATOR FAN RELAY 1 CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Radiator fan does not operate properly.
- Overheating

**WIRING DIAGRAM:**





B2M1289

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODE.

<Ref. to 2-7 [T3D0] and [T3E0].>

**10CW1 CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.
- 3) Turn ignition switch to ON.

- 4) Measure voltage between ECM and chassis ground.


**CHECK** : **Connector & terminal (B84) No. 74 (+) — Chassis ground: Does voltage change between 0 and 10 volts?**

**NOTE:**

Radiator fan relay operation check can be executed using Subaru Select Monitor (Function mode: FD03). For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**YES** : Go to step **10CW2**.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.

**10CW2 CHECK SHORT CIRCUIT IN RADIATOR FAN RELAY 1 CONTROL CIRCUIT.**

- 1) Turn ignition switch to OFF.
- 2) Remove main fan relay 1 and sub fan relay 1. (with A/C models)  
Remove main fan relay. (without A/C models)
- 3) Disconnect test mode connector.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 74 (+) — Chassis ground (-): Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in radiator fan relay 1 control circuit. After repair, replace ECM.

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.


**NO** : Replace ECM.

OBD (FB1)  
 P1540 <VSP\_S>  
 B2M1142


**CX: DTC P1540**  
**— VEHICLE SPEED SENSOR MALFUNCTION**  
**2 —**

**DTC DETECTING CONDITION:**  
 ● Immediately at fault recognition

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.  
 <Ref. to 2-7 [T3D0] and [T3E0].>


**10CX1****CHECK SPEEDOMETER OPERATION IN COMBINATION METER.****CHECK** : *Does speedometer operate normally?***YES** : Go to step **10CX2**.**NO** : Check speedometer and vehicle speed sensor <Ref. to 6-2 [K3A0].>.**10CX2****CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from TCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 83 (+) — Chassis ground (-): Is the voltage more than 2 V?****YES** : Repair harness and connector.**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and combination meter connector
- Poor contact in ECM connector
- Poor contact in combination meter connector
- Poor contact in coupling connector (B37)

**NO** : Go to step **10CX3**.**10CX3****CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 83 — Chassis ground: Is the resistance less than 10 Ω?****YES** : Repair ground short circuit in harness between ECM and combination meter connector.**NO** : Repair poor contact in ECM connector.



OBD	(FB1)
P1700	<ATTH>
OBD0501	

**CY: DTC P1700**  
**— THROTTLE POSITION SENSOR CIRCUIT**  
**MALFUNCTION FOR AUTOMATIC**  
**TRANSMISSION —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effected in "3" range; excessive shift shock; excessive tight corner "braking"

**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>

<b>10CY1</b>	<b>CHECK DTC P1700 ON DISPLAY.</b>
--------------	------------------------------------

- CHECK** : *Does the Subaru select monitor or OBD-II general scan tool indicate DTC P1700?*
- YES** : Check throttle position sensor circuit. <Ref. to 3-2 [T7K0].>
- NO** : It is not necessary to inspect DTC P1700.


OBD (FB1)  
 P1701 <ATCRS>  
 B2M0669

**CZ: DTC P1701**  
**— CRUISE CONTROL SET SIGNAL CIRCUIT**  
**MALFUNCTION FOR AUTOMATIC**  
**TRANSMISSION —**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**WIRING DIAGRAM:**



**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.

<Ref. to 2-7 [T3D0] and [T3E0].>




**10CZ1 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and CCM.
- 3) Measure resistance of harness between TCM and CCM connector.

**CHECK** : **Connector & terminal**  
(B56) No. 3 — (B94) No. 3:  
**Is the resistance less than 1 Ω?**

**YES** : Go to next step 4).

**NO** : Repair open circuit in harness between TCM and CCM connector.




4) Measure resistance of harness between TCM and chassis ground.

**CHECK** : **Connector & terminal**  
(B56) No. 3 — Chassis ground:  
**Is the resistance less than 10 Ω?**

**YES** : Repair short circuit in harness between TCM and CCM connector.

**NO** : Go to step **10CZ2**.



#### 10CZ2 CHECK INPUT SIGNAL FOR TCM.

- 1) Connect connector to TCM and CCM.
- 2) Lift-up the vehicle or set the vehicle on free rollers.

#### CAUTION:

**On AWD models, raise all wheels off ground.**

- 3) Start the engine.
- 4) Cruise control main switch to ON.
- 5) TCS OFF switch to ON. (with TCS models only)
- 6) Move selector lever to "D" and slowly increase vehicle speed to 50 km/h (31 MPH).
- 7) Cruise control set switch to ON.
- 8) Measure voltage between TCM and chassis ground.

**CHECK** : **Connector & terminal**  
(B56) No. 3 (+) — Chassis ground (-):  
**Is the resistance less than 1 V?**

**YES** : Go to next **CHECK** .

**NO** : Check cruise control set circuit. <Ref. to 6-2 [T7A0].>

**CHECK** : **Is there poor contact in TCM connector?**

**YES** : Repair poor contact in TCM connector.


**NO** : Replace TCM.

OBD (FB1)  
 P1702<ATDIAG\_LO>  
 B2M1143

**DA: DTC P1702**  
**— AUTOMATIC TRANSMISSION DIAGNOSIS**  
**INPUT SIGNAL CIRCUIT LOW INPUT —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**




B2M0614

**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

**10DA1 CHECK TRANSMISSION TYPE.**

- CHECK** : *Is transmission type AT?*
- YES** : Go to step 10DA2.
- NO** : Check AT/MT identification circuit. <Ref. to 2-7 [T10DD0].>

**10DA2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**


- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

- CHECK** : **Connector & terminal (B84) No. 80 (+) — Chassis ground (-): Is the voltage less than 1 V?**
- YES** : Go to step 10DA3.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**NOTE:**


In this case, repair the following:

- Poor contact in ECM connector
- Poor contact in TCM connector

**10DA3 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM and TCM.
- 3) Measure resistance of harness between ECM and chassis ground.

- CHECK** : **Connector & terminal (B84) No. 80 — Chassis ground: Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step 10DA4.



**10DA4 CHECK ECM.**

- 1) Connect connector to ECM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 80 (+) — Chassis ground (-): Is the voltage more than 5 V?**

**YES** : Replace TCM.


**NO** : Replace ECM.

OBD (FB1)  
 P1722<ATDIAG\_HI>  
 B2M1144

**DB: DTC P1722  
 — AUTOMATIC TRANSMISSION DIAGNOSIS  
 INPUT SIGNAL CIRCUIT HIGH INPUT —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**




**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>




**10DB1 CHECK TRANSMISSION TYPE.**

- CHECK** : *Is transmission type AT?*
- YES** : Go to step 10DB2.
- NO** : Check AT/MT identification circuit. <Ref. to 2-7 [T10DD0].>



**10DB2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**


- 1) Turn ignition switch to ON.
  - 2) Measure voltage between ECM and chassis ground.
- CHECK** : **Connector & terminal (B84) No. 80 (+) — Chassis ground (-): Is the voltage more than 10 V?**
  - YES** : Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM.
  - NO** : Go to step 10DB3.




**10DB3 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure voltage between ECM connector and chassis ground.

- CHECK** : **Connector & terminal (B84) No. 80 (+) — Chassis ground (-): Is the voltage more than 4 V?**
  - YES** : Go to step 10DB4.
  - NO** : Go to next **CHECK** .
- CHECK** : **Connector & terminal (B84) No. 80 (+) — Chassis ground (-): Is the voltage less than 1 V?**
  - YES** : Repair poor contact in ECM connector.
  - NO** : Go to next **CHECK** .





**CHECK** : **Connector & terminal (B84) No. 80 (+) — Chassis ground (-): Does the voltage change from 1 V to 4 V while monitoring the value with voltage meter?**

**YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**NOTE:**


In this case, repair the following:

- Poor contact in ECM connector
- Poor contact in TCM connector

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**10DB4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure voltage between TCM and chassis ground.

**CHECK** : **Connector & terminal (B55) No. 11 (+) — Chassis ground (-): Is the voltage more than 4 V?**

**YES** : Go to next **CHECK** .

**NO** : Repair open circuit in harness between ECM and TCM connector.

**CHECK** : **Is there poor contact in TCM connector?**

**YES** : Repair poor contact in TCM connector.


**NO** : Check TCM power supply line and grounding line.

OBD (FB1)  
 P1742 <ATDIAG\_2>  
 B2M1147

**DC: DTC P1742**  
**— AUTOMATIC TRANSMISSION DIAGNOSIS**  
**INPUT SIGNAL CIRCUIT MALFUNCTION —**

- DTC DETECTING CONDITION:**
- Two consecutive driving cycles with fault

**WIRING DIAGRAM:**



**CAUTION:**  
 After repair or replacement of faulty parts, conduct  
**CLEAR MEMORY** and **INSPECTION MODES**.  
 <Ref. to 2-7 [T3D0] and [T3E0].>

<b>10DC1</b>	<b>CHECK TRANSMISSION TYPE.</b>
--------------	---------------------------------

- CHECK** : *Is transmission type AT?*  
**YES** : Go to step **10DC2**.  
**NO** : Check AT/MT identification circuit. <Ref. to 2-7 [T10DD0].>

<b>10DC2</b>	<b>CHECK DRIVING CONDITION.</b>
--------------	---------------------------------


- 1) Start and warm-up the engine until the radiator fan makes one complete rotation.  
2) Drive the vehicle.  
**CHECK** : *Is AT shift control functioning properly?*  
**YES** : Go to step **10DC3**.  
**NO** : Replace TCM.

<b>10DC3</b>	<b>CHECK ACCESSORY.</b>
--------------	-------------------------

- CHECK** : *Are car phone and/or CB installed on vehicle?*  
**YES** : Repair grounding line of car phone or CB system.  
**NO** : Replace TCM.

**DD: — AT/MT IDENTIFICATION CIRCUIT  
MALFUNCTION [MT VEHICLES] —**

**WIRING DIAGRAM:**




B2M0617

**CAUTION:**

**After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.**

**<Ref. to 2-7 [T3D0] and [T3E0].>**



10DD1

### CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**CHECK** : **Connector & terminal (B84) No. 81 (+) — Chassis ground (-): Is the voltage more than 2 V?**

**YES** : Repair harness and connector.

#### NOTE:

In this case, repair the following:

- Open circuit in harness between ECM connector and engine grounding terminal
- Poor contact in engine grounding terminal
- Poor contact in coupling connector (B22)

**NO** : Go to next **CHECK** .

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

#### NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.