

## 10. Performance Test

### A: INSPECTION

#### 1. VEHICLE SET UP

In order to obtain meaningful test results, the vehicle must be set up to meet the following conditions:

- Vehicle in shade
- No wind
- All vehicle doors closed
- Front windows open
- Hood open
- Engine speed set at 1,500 rpm.
- A/C ON
- Temperature control switch — Maximum cold
- Air source — Recirculation
- Blower speed — 4th position (High)
- Operate A/C for 10 minutes (Minimum) before taking measurement.

#### 2. MEASUREMENTS

After 10 minutes (Minimum) of A/C operation and using accurate test equipment, take the following measurements (in order):

- 1) Evaporator intake air temperature at recirculation door.
- 2) Evaporator discharge air temperature at center grill.
- 3) Condenser (Ambient) intake air temperature measured 0.9 m (3 ft) in front and in line with the center of the condenser
- 4) Suction (Low) side pressure
- 5) Discharge (High) side pressure

#### NOTE:

If only one thermometer is available; 1) take the ambient measurement first; then 2) the intake air; and 3) discharge air temperature.

## 11. Compressor


### A: INSPECTION

#### 1. COMPRESSOR CLUTCH

#### NOTE:


Compressor clutch trouble is often caused by clutch slippage and noise. Check and take corrective measures, as required.

- 1) Remove duct (A).



B6M1186A

- 2) Remove belt cover.




B4M0090

- 3) Check that clearance between drive plate and pulley over the entire perimeter is within specifications.

#### Clearance:

**$0.45 \pm 0.15$  mm ( $0.0177 \pm 0.0059$  in)**



B4M0091

- 4) Check that voltage applied to magnetic coil is at least 10.5 volts.
- 5) When noise is noted, check that it originates in either compressor or pulley bearing.