


## 2. Parking Brake Lever

### A: REMOVAL

- 1) Set the wheel stoppers to tires.
- 2) Remove the console box.
- 3) Disconnect the parking brake switch connector.
- 4) Remove the parking cable adjusting nut (self-locking nut).
- 5) Remove the parking brake lever.



### B: INSTALLATION

- 1) Install in the reverse order of removal.

#### **Tightening torque:**

##### **Parking brake lever**

**18 N·m (1.8 kgf·m, 13.0 ft·lb)**

- 2) Install a new adjusting nut (self-locking nut).
- 3) Adjust the lever stroke. <Ref. to PB-4, ADJUSTMENT, Parking Brake Lever.>

### C: INSPECTION

- 1) Operate the parking brake lever 3 to 4 times and return the lever fully.
- 2) While pulling the parking brake lever upward, count the notches.

#### **Lever stroke:**

**5 to 6 notches when pulled with a force of 200 N (20.4 kgf, 45 lb)**

If it is not within the specified value, adjust the parking brake. <Ref. to PB-8, ADJUSTMENT, Parking Brake Assembly (Rear Disc Brake).>

### D: ADJUSTMENT

Adjust the parking lever stroke. <Ref. to PB-8, LEVER STROKE, ADJUSTMENT, Parking Brake Assembly (Rear Disc Brake).>