

### 6. “T-type” Tire

#### A: NOTE

“T-type” tire for temporary use is prepared as a spare tire.

#### CAUTION:

- Do not drive at a speed greater than 100 km/h (62 MPH).
- For the model with tire pressure monitoring system, the indicator light may blink when running with the “T-type” tire.

#### B: REPLACEMENT

Refer to “Steel Wheel” for installation procedure of “T-type” tire. <Ref. to WT-6, REMOVAL, Steel Wheel.>

#### CAUTION:

Replace with a conventional tire as soon as possible since the “T-type” tire is only for temporary use.

#### C: INSPECTION

- 1) Check the tire air pressure.

#### *Specifications:*

*420 kPa (4.2 kg/cm<sup>2</sup>, 60 psi)*

- 2) Take the stones, glass, nails, etc. out of the tread groove.
- 3) Check the tires for deformation, cracks, partial wear or wear.

#### CAUTION:

Replace the tire with a new one if defective.