

Tumble Generator Valve Position Sensor

FUEL INJECTION (FUEL SYSTEMS)

14. Tumble Generator Valve Position Sensor

A: SPECIFICATION

Do not remove the tumble generator valve position sensor from tumble generator valve assembly, since it cannot be adjusted during installation.

Refer to "Tumble Generator Valve Assembly" for removal and installation procedures. <Ref. to FU(H4DOTC)-30, REMOVAL, Tumble Generator Valve Assembly.> <Ref. to FU(H4DOTC)-30, INSTALLATION, Tumble Generator Valve Assembly.>