


30. Fuel Sub Level Sensor

A: REMOVAL


WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

- 1) Drain fuel. <Ref. to FU(H4DOTC)-44, DRAINING FUEL, PROCEDURE, Fuel.>
- 2) Remove the rear seat.
- 3) Remove the service hole cover.
 - (1) Remove the bolts (A).
 - (2) Push the grommet (B) down under the body and remove the service hole cover.




- 4) Disconnect the connector from fuel sub level sensor.



- 5) Disconnect the quick connector and then disconnect the fuel delivery hose, return hose and jet pump hose. <Ref. to FU(H4DOTC)-60, REMOVAL, Fuel Delivery, Return and Evaporation Lines.>

- 6) Remove the nuts and bolts which install the fuel sub level sensor on fuel tank.



- (A) Jet pump hose
- (B) Delivery hose
- (C) Return hose

- 7) Remove the fuel sub level sensor.

B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Use a new gasket.

- (1) Ensure the sealing portion is free from fuel or foreign particles before installation.
- (2) Tighten the nuts and bolts to specified torque in the order as shown in the figure.

Tightening torque:

4.4 N·m (0.45 kgf·m, 3.2 ft·lb)

