


## 6. Engine Oil Pressure


**Tightening torque:**  
**25 N·m (2.5 kgf-m, 18.1 ft-lb)**

### A: INSPECTION

- 1) Remove the collector cover.
- 2) Remove the oil pressure switch from engine cylinder block. <Ref. to LU(H4DOTC)-18, REMOVAL, Oil Pressure Switch.>
- 3) Connect the oil pressure gauge hose to cylinder block.
- 4) Connect the battery ground cable to battery.



- 5) Start the engine, and measure the oil pressure.



#### **Oil pressure (Standard):**

**At 800 rpm**

**98 kPa (1.0 kgf/cm<sup>2</sup>, 14 psi) or more**

**At 5,000 rpm**

**294 kPa (3.0 kgf/cm<sup>2</sup>, 43 psi) or more**

#### **CAUTION:**

- If the oil pressure is out of specification, check oil pump, oil filter and lubrication line. <Ref. to LU(H4DOTC)-21, INSPECTION, Engine Lubrication System Trouble in General.>
- If the oil pressure warning light is turned to ON and oil pressure is within specification, replace the oil pressure switch. <Ref. to LU(H4DOTC)-21, INSPECTION, Engine Lubrication System Trouble in General.>

#### **NOTE:**

The specified value is based on an engine oil temperature of 80°C (176°F).

- 6) After measuring the oil pressure, install the oil pressure switch. <Ref. to LU(H4DOTC)-18, INSTALLATION, Oil Pressure Switch.>