

Reservoir Tank

POWER ASSISTED SYSTEM (POWER STEERING)

8. Reservoir Tank


A: REMOVAL

- 1) Drain fluid from the reservoir tank.
- 2) Disconnect the hose from reservoir tank.

CAUTION:


To prevent foreign matter from entering the hose and pipe, cover the open ends of them with a clean cloth.

- H4 model



- (1) Reservoir tank
- (2) Suction hose
- (3) Return hose
- (4) Oil cooler
- (5) Oil cooler bracket

- H6 model



- (1) Reservoir tank
- (2) Suction hose
- (3) Return hose

- 3) Remove the reservoir tank from body.

B: INSTALLATION


- 1) Install the reservoir tank to body.

Tightening torque:

13 N·m (1.32 kgf·m, 9.6 ft·lb)


- 2) Connect the hose to reservoir tank.

- H4 model



- (1) Reservoir tank
- (2) Suction hose
- (3) Return hose
- (4) Oil cooler
- (5) Oil cooler bracket

- H6 model



- (1) Reservoir tank
- (2) Suction hose
- (3) Return hose

- 3) Feed the power steering fluid to specified level.
<Ref. to PS-52, Power Steering Fluid.>

C: INSPECTION

Check the reservoir tank for cracks, breakage and damage. If a failure is found, replace the reservoir tank.