


## 8. Rear Differential Front Member

### A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Lift-up the vehicle.
- 3) Support the rear differential using transmission jack, and then remove the rear differential front member.



(A) Rear differential front member


### B: INSTALLATION

Install the rear differential front member with a new self-locking nut.

#### *Tightening torque:*

**T1: 65 N·m (6.6 kgf-m, 48 ft-lb)**

**T2: 110 N·m (11.2 kgf-m, 81 ft-lb)**



### C: INSPECTION

- 1) Check the rear differential front member for damage, bend and corrosion.  
If damage, bend or corrosion is excessive, replace the rear differential front member.
- 2) Check the bushings of rear differential member for cracking, hardening and damage.  
If cracking, hardening or damage is excessive, replace rear differential front member.