

Rear Window Defogger System

GLASS/WINDOWS/MIRRORS

16.Rear Window Defogger System

A: WIRING DIAGRAM

<Ref. to WI-169, Rear Defogger System.>

B: INSPECTION

Symptom	Repair order
Rear window defogger does not operate.	(1) Fuse (M/B No. 10) (F/B No. 22) (2) Rear defogger relay (3) Defogger switch (4) Rear defogger condenser (5) Defogger wire (6) Wiring harness (7) Body integrated unit

NOTE:

Rear window defogger system can be customized on the Subaru Select Monitor.

System name	Initial setting	Customize setting
Rear window defogger timer	OFF after 15 min.	Repeat 15 min. operation and 2 min. stop.