

## 27. Immobilizer Control Unit

### **A: NOTE**

The control of immobilizer system is carried out in body integrated unit.

### **B: REMOVAL**

<Ref. to SL-53, REMOVAL, Body Integrated Unit.>

### **C: INSTALLATION**

Install in the reverse order of removal.