

# Wiper Deicer System

GLASS/WINDOWS/MIRRORS

## 21. Wiper Deicer System

### A: WIRING DIAGRAM

<Ref. to WI-159, Wiper Deicer System.>

### B: INSPECTION

Symptom	Repair order
Wiper deicer does not operate.	(1) Fuse (F/B No. 4, 9) (2) Wiper deicer relay (3) Wiper deicer switch (4) Wiring harness (5) Body integrated unit

Refer to “Rear Window Defogger” for inspection.

<Ref. to GW-33, INSPECTION, Rear Window Defogger.>

#### NOTE:

Wiper deicer system can be customized on the Subaru Select Monitor.

System name	Initial setting	Customize setting
Wiper deicer timer	OFF after 15 min.	Continuous operation*

\*: When one of following items is occurred, finish the continuous operation and goes to OFF after 15 min.

- Ambient temperature that is more than 5°C (41°F) continues for 10 sec.
- Malfunction occurs on ambient temperature sensor
- Vehicle speed that is below 15 km/h (9 MPH) continues 15 min.
- Malfunction occurs on CAN communication

### C: REPAIR

Refer to “Rear Window Defogger” for repair.

<Ref. to GW-34, REPAIR, Rear Window Defogger.>