

15.Oil Flow Control Solenoid Valve

A: REMOVAL

Oil flow control solenoid valve forms a unit with camshaft cap.

Refer to "Camshaft" for removal. <Ref. to ME(H4DOTC)-51, REMOVAL, Camshaft.>

B: INSTALLATION

Install in the reverse order of removal.