


Oil Pressure Switch

LUBRICATION


6. Oil Pressure Switch

A: REMOVAL

- 1) Remove the collector cover.
- 2) Remove the generator from bracket. <Ref. to SC(H4SO)-20, REMOVAL, Generator.>
- 3) Disconnect the terminal from oil pressure switch.



- 4) Remove the oil pressure switch.




B: INSTALLATION

- 1) Apply liquid gasket to the oil pressure switch threads.

Liquid gasket:


THREE BOND 1324 (Part No. 004403007) or equivalent




- 2) Install the oil pressure switch onto engine block.

Tightening torque:

25 N·m (2.5 kgf·m, 18.1 ft·lb)



- 3) Connect the terminal to oil pressure switch.



- 4) Install the generator to bracket. <Ref. to SC(H4SO)-20, INSTALLATION, Generator.>
- 5) Install the collector cover.

C: INSPECTION

Make sure oil does not leak or seep from where the oil pressure switch is installed.