

20. Key Lock Cylinders

A: REPLACEMENT

- 1) Raise the front door glass to the top position.
- 2) Remove the door trim. <Ref. to EI-48, REMOVAL, Door Trim.>
- 3) Remove the sealing cover.
- 4) Remove the rod clamp. Remove the bolt. Replace the key cylinder (1).

