

25. In-Vehicle Sensor (Auto A/C Model)

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the console side panel of driver's side.
<Ref. to EI-54, REMOVAL, Center Console.>
- 3) Disconnect the connector and aspirator hose, remove the pawl and remove the in-vehicle sensor from center console frame.

CAUTION:

Be careful not to damage the sensors and interior trims when removing.

B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

<Ref. to AC(diag)-33, IN-VEHICLE SENSOR, Diagnostic Procedure for Sensors.>