

Schedule

PERIODIC MAINTENANCE SERVICES

2. Schedule

A: MAINTENANCE SCHEDULE 1

1. U.S.

- Except U5 model

		MAINTENANCE INTERVAL																	Remarks
		[Number of months or km (miles), whichever occurs first]																	
		3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	
Months	4.8	12	24	36	48	60	72	81.4	96	108	120	132	144	156	168	180	192		
× 1,000 km	3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120		
× 1,000 miles																			
1	Engine oil	3.0 L	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
		2.5 L		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
2	Engine oil filter	3.0 L	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
		2.5 L		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
3	Spark plugs						R				R				R				
											R							R	
4	Drive belt(s)					I				I				I		R			
5	Camshaft Drive belt					I				I				I		R			
6	Fuel line					(I)				(I)				(I)			I		
7	Fuel filter					(R)				(R)				(R)			R		
8	Air cleaner element					R				R				R			R		
9	Cooling system					I				I				I			I		
10	Coolant					R				R				R			R		
11	Clutch system			I		I		I		I		I		I		I	I		
12	Transmission oil					I				I				I			I		
13	ATF					I				I				I			I		
14	Front & rear differential oil					I				I				I			I		
15	Brake line			I		I		I		I		I		I		I	I		
16	Brake fluid					R				R				R			R		
17	Disc brake pads & discs			I		I		I		I		I		I		I	I		
18	Parking brake			I		I		I		I		I		I		I	I		
19	Suspension			I		I		I		I		I		I		I	I		
20	Wheel bearing									(I)							(I)		
21	Axle boots & joints			I		I		I		I		I		I		I	I		
22	Tire rotation		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
23	Steering system (Power steering)			I		I		I		I		I		I		I	I		
24	Supplement restraint system	Inspect every 10 years																	
25	A/C filter	Replace every 12 months or 12,000 km (7,500 mile)																	

Symbols used:

R: Replace

I: Inspection

(R) or (I): Recommended service for safe vehicle operation.

Schedule

PERIODIC MAINTENANCE SERVICES

NOTE:

(1) This inspection is not required to maintain emission warranty eligibility and it dose not affect the manufacturer's obligations under EPA's in-use compliance program.

(2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.

(3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically rust, damaged or ATF leaked.

(4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less

(5) When the A/C filter is installed.

- U5 model

		MAINTENANCE INTERVAL												Remarks
		[Number of months or km (miles), whichever occurs first]												
		3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	Continue to next table	
	Months													
	× 1,000 km	4.8	12	24	36	48	60	72	81.4	96	108	120		
	× 1,000 miles	3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75		
1	Engine oil		R	R	R	R	R	R	R	R	R	R		
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R		
3	Spark plugs					R				R				
4	Drive belt(s)					I				I				
5	Camshaft Drive belt					I				I				
6	Fuel line					(I)				(I)				Note (1)
7	Fuel filter					(R)				(R)				Note (1)
8	Air cleaner element					R				R				Note (2)
9	Cooling system					I				I				
10	Coolant					R				R				
11	Clutch system			I		I		I		I		I		
12	Transmission oil					I				I				
13	ATF					I				I				Note (3)
14	Front & rear differential oil					I				I				
15	Brake line			I		I		I		I		I		
16	Brake fluid					R				R				
17	Disc brake pads & discs			I		I		I		I		I		
18	Parking brake			I		I		I		I		I		
19	Suspension			I		I		I		I		I		
20	Wheel bearing									(I)				
21	Axle boots & joints			I		I		I		I		I		
22	Tire rotation		I	I	I	I	I	I	I	I	I	I		Note (4)
23	Steering system (Power steering)			I		I		I		I		I		
24	Supplement restraint system	Inspect every 10 years												
25	A/C filter	Replace every 12 months or 12,000 km (7,500 mile)												Note (5)

Symbols used:

R: Replace

I: Inspection

(R) or (I): Recommended service for safe vehicle operation.

NOTE:

(1) This inspection is not required to maintain emission warranty eligibility and it dose not affect the manufacturer's obligations under EPA's in-use compliance program.

(2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.

(3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically rust, damaged or ATF leaked.

(4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less

(5) When the A/C filter is installed.

Schedule

PERIODIC MAINTENANCE SERVICES

		MAINTENANCE INTERVAL [Number of months or km (miles), whichever occurs first]											Remarks
	Months	Continue from previous table	82.5	90	97.5	105	112.5	120	127.5	135	142.5	150	
	× 1,000 km		132	144	156	168	180	192	204	216	228	240	
	× 1,000 miles		82.5	90	97.5	105	112.5	120	127.5	135	142.5	150	
1	Engine oil		R	R	R	R	R	R	R	R	R	R	
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	
3	Spark plugs			R				R				R	
4	Drive belt(s)			I		R				I			
5	Camshaft Drive belt			I		R				I			
6	Fuel line			(I)				I				(I)	Note (1)
7	Fuel filter			(R)				R				(R)	Note (1)
8	Air cleaner element			R				R				R	Note (2)
9	Cooling system			I				I				I	
10	Coolant			R				R				R	
11	Clutch system			I		I		I				I	
12	Transmission oil			I				I				I	
13	ATF			I				I				I	Note (3)
14	Front & rear differential oil			I				I				I	
15	Brake line			I		I		I		I		I	
16	Brake fluid			R				R				R	
17	Disc brake pads & discs			I		I		I		I		I	
18	Parking brake			I		I		I		I		I	
19	Suspension			I		I		I		I		I	
20	Wheel bearing							(I)				(I)	
21	Axle boots & joints			I		I		I		I		I	
22	Tire rotation		I	I	I	I	I	I	I	I	I	I	Note (4)
23	Steering system (Power steering)			I		I		I		I		I	
24	Supplement restraint system	Inspect every 10 years											
25	A/C filter	Replace every 12 months or 12,000 km (7,500 mile)											Note (5)

Symbols used:

R: Replace

I: Inspection

(R) or (I): Recommended service for safe vehicle operation.

NOTE:

(1) This inspection is not required to maintain emission warranty eligibility and it does not affect the manufacturer's obligations under EPA's in-use compliance program.

(2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.

(3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically rust, damaged or ATF leaked.

(4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less

(5) When the A/C filter is installed.

Schedule

PERIODIC MAINTENANCE SERVICES

2. CANADA

		MAINTENANCE INTERVAL																	Remarks
		[Number of months or km (miles), whichever occurs first]																	
Months		3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	
× 1,000 km		4.8	12	24	36	48	60	72	81.4	96	108	120	132	144	156	168	180	192	
× 1,000 miles		3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	
1	Engine oil	3.0 L	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
		2.5 L	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
2	Engine oil filter	3.0 L	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
		2.5 L	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
3	Spark plugs						R								R			R	
																			R
4	Drive belt(s)					I				I					I			R	
5	Camshaft Drive belt					I				I					I			R	
6	Fuel line					(I)				(I)					(I)			I	
7	Fuel filter					(R)				(R)					(R)			R	
8	Air cleaner element					R				R					R			R	
9	Cooling system					I				I					I			I	
10	Coolant					R				R					R			R	
11	Clutch system			I		I		I		I		I		I		I		I	
12	Transmission oil					I				I					I			I	
13	ATF					I				I					I			I	
14	Front & rear differential oil					I				I					I			I	
15	Brake line			I		I		I		I		I		I		I		I	
16	Brake fluid					R				R					R			R	
17	Disc brake pads & discs			I		I		I		I		I		I		I		I	
18	Parking brake			I		I		I		I		I		I		I		I	
19	Suspension			I		I		I		I		I		I		I		I	
20	Wheel bearing									(I)								(I)	
21	Axle boots & joints			I		I		I		I		I		I		I		I	
22	Tire rotation		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
23	Steering system (Power steering)			I		I		I		I		I		I		I		I	
24	Supplement restraint system	Inspect every 10 years																	
25	A/C filter	Replace every 12 months or 12,000 km (7,500 mile)																	

Symbols used:

R: Replace

I: Inspection

(R) or (I): Recommended service for safe vehicle operation.

NOTE:

(1) This inspection is not required to maintain emission warranty eligibility and it does not affect the manufacturer's obligations under EPA's in-use compliance program.

(2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.

(3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically rust, damaged or ATF leaked.

(4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less

(5) When the A/C filter is installed.

Schedule

PERIODIC MAINTENANCE SERVICES

B: MAINTENANCE SCHEDULE 2

Item	Every	Repeat short distance drive	Repeat rough/muddy road drive	Extremely cold weather area	Salt or other corrosive used or coastal area	High humidity or mountain area	Repeat towing trailer
Engine oil	3.75 months	R		R			R
	6,000 km						
	3,750 miles						
Engine oil filter	3.75 months	R		R			R
	6,000 km						
	3,750 miles						
Fuel filter	7.5 months				I		
	12,000 km						
	7,500 miles						
Fuel line	7.5 months				I		
	12,000 km						
	7,500 miles						
Transmission oil	15 months						R
	24,000 km						
	15,000 miles						
ATF	15 months						R
	24,000 km						
	15,000 miles						
Front & rear differential oil	15 months						R
	24,000 km						
	15,000 miles						
Brake line	7.5 months				I		
	12,000 km						
	7,500 miles						
Brake fluid	15 months					R	
	24,000 km						
	15,000 miles						
Disc brake pads & discs	7.5 months	I	I		I		I
	12,000 km						
	7,500 miles						
Parking brake	7.5 months				I		
	12,000 km						
	7,500 miles						
Suspension	7.5 months		I	I	I		
	12,000 km						
	7,500 miles						
Axle boots & joints	7.5 months	I	I		I		I
	12,000 km						
	7,500 miles						
Steering system (Power steering)	7.5 months		I	I	I		
	12,000 km						
	7,500 miles						