

## Fuel Sub Level Sensor

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

### 9. Fuel Sub Level Sensor

#### A: REMOVAL

For removal procedure, refer to “FU(H4DOTC)” section. <Ref. to FU(H4DOTC)-57, REMOVAL, Fuel Sub Level Sensor.>

#### B: INSTALLATION

For installation procedure, refer to “FU(H4DOTC)” section. <Ref. to FU(H4DOTC)-57, INSTALLATION, Fuel Sub Level Sensor.>