


## 4. Combination Meter

### A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Set the tilt steering at the lowest position.
- 3) Remove the instrument panel under cover and lower cover of driver's seat side. <Ref. to EI-56, REMOVAL, Instrument Panel Assembly.>
- 4) Remove the screws of combination meter (one for upper side, two for lower side) and pull tilting the meter toward you.



- 5) Disconnect the connector in the rear side of combination meter to remove meter.

#### CAUTION:

- Be careful not to damage the meter or instrument panel.
- Pay particular attention to avoid damaging the meter glass.

### B: INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

- Make sure the electrical connector is connected securely.
- Make sure that each meter operates normally.
- When the combination meter of model with immobilizer has been replaced, be sure to perform the registration procedure of immobilizer.

# Combination Meter


INSTRUMENTATION/DRIVER INFO

## C: DISASSEMBLY

### CAUTION:

- Use gloves to avoid damage and getting fingerprints on the glass surface and meter surfaces.
- Be careful not to apply excessive force to the trip knob.
- Be sure not to touch the meter indicator needle.

Remove the pawl (A), and then detach the meter glass assembly (B) and meter panel assembly (C) from meter case assembly (D).



## 1. BULB REPLACEMENT

LEDs are used for all of warning lights and indicator lights of combination meters, replace the meter case assembly if faulty.

## D: ASSEMBLY

Assemble in the reverse order of disassembly.