

Fuel Tank Sensor Control Valve

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

11. Fuel Tank Sensor Control Valve

A: REMOVAL

Fuel tank sensor control valve and fuel tank pressure sensor are integrated into one unit; therefore, the removal procedure is the same as that for fuel tank pressure sensor. <Ref. to EC(H4DOTC)-11, REMOVAL, Fuel Tank Pressure Sensor.>

B: INSTALLATION

Fuel tank sensor control valve and fuel tank pressure sensor are integrated into one unit; therefore, the installation procedure is the same as that for fuel tank pressure sensor. <Ref. to EC(H4DOTC)-11, INSTALLATION, Fuel Tank Pressure Sensor.>

C: INSPECTION

Make sure the hoses are not cracked or loose.