

General Description

INSTRUMENTATION/DRIVER INFO

1. General Description

A: SPECIFICATION

Combination meter	Speedometer	Stepping motor type	
	Tachometer		
	Water temperature gauge		
	Fuel gauge		
	Malfunction indicator light	LED	
	Oil pressure warning light		
	ABS warning light		
	Airbag warning light		
	Seat belt warning light		
	Door open warning light		
	Brake fluid and parking brake warning light		
	Low fuel warning light		
	Charge warning light		
	ATF temperature warning light		
	AWD warning light		
	Tire pressure warning light		
	Vehicle dynamics control (VDC) warning light		
	Vehicle dynamics control (VDC) indicator light		
	Turn signal indicator light		
	HI-beam indicator light		
	Security indicator light		
	Cruise indicator light		
	Cruise set indicator light		
	Front fog light indicator light		
	SPORT indicator light		
	AT select lever position indicator light		
	Light illumination indicator light		
	Meter illumination light		
	LCD back light		
	Odo/Trip indicator		LCD
	SPORT shift indicator		

B: CAUTION

- Be careful not to damage the meters and instrument panel.
- Be careful not to damage the meter glass.
- Make sure the electrical connector is connected securely.
- After installation, make sure that each meter operates normally.
- Use gloves to avoid damage and getting fingerprints on the glass surface and meter surfaces.
- Do not apply an excessive force on the printed circuit.
- Do not drop or otherwise apply impact.
- When the combination meter of model with immobilizer has been replaced, be sure to perform the registration procedure of immobilizer.

C: PREPARATION TOOL

1. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.