

# Clutch Fluid Air Bleeding

## CLUTCH SYSTEM


### 9. Clutch Fluid Air Bleeding

#### A: PROCEDURE

##### NOTE:

Bleed air from the oil line with help of a co-worker.

- 1) Remove the air intake chamber. <Ref. to IN(H4SO)-9, REMOVAL, Air Intake Chamber.>
- 2) Fit one end of a vinyl tube into the air bleeder of operating cylinder and put the other end into a brake fluid container.




- (A) Clutch hose
- (B) Air bleeder

- 3) Slowly depress the clutch pedal and keep it depressed. Then open the air bleeder to discharge air together with the fluid.

Release the air bleeder for 1 or 2 seconds. Next, with the bleeder closed, slowly release the clutch pedal.

##### CAUTION:

**When loosening bleeder screw, cover the bleeder with cloth to prevent brake fluid from being splashed over surrounding parts.**




- (A) Operating cylinder
- (B) Vinyl tube

- 4) Repeat the procedure 3), until there are no more air bubbles in the vinyl tube.
- 5) Tighten the air bleeder.

##### Tightening torque:

**T: 8 N·m (0.8 kgf·m, 5.8 ft·lb)**



- 6) After depressing the clutch pedal, make sure that there are no leaks evident in the entire clutch system.
- 7) After bleeding air from the clutch system, ensure that clutch operates properly.