

# Drive Pinion Shaft Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL


## 16. Drive Pinion Shaft Assembly

### A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-25, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the transfer case with extension case assembly. <Ref. to 5MT-37, REMOVAL, Transfer Case and Extension Case Assembly.>
- 3) Remove the transmission case. <Ref. to 5MT-49, REMOVAL, Transmission Case.>
- 4) Remove the drive pinion shaft assembly.

#### NOTE:


Use a hammer handle, etc. to remove if too tight.



- (A) Main shaft ASSY for single-range  
(B) Drive pinion shaft ASSY

### B: INSTALLATION

- 1) Remove the differential assembly.
- 2) Alignment marks/numbers on hypoid gear set: Use hypoid driven gear of its match number corresponding with upper one on the drive pinion (A). The figure (B) shows a number for shim adjustment. If no number is shown, the value is zero.




- (A) Match number  
(B) Number for shim adjustment

- 3) Place the drive pinion shaft assembly on the transmission main case RH without shim and tighten the bearing mounting bolts.
- 4) Inspection and adjustment of ST:

#### NOTE:

- Loosen the two bolts and adjust so that the scale indicates 0.5 correctly when the plate end and the scale end are on the same level.
- Tighten the two bolts.

ST 499917500 DRIVE PINION GAUGE ASSY




- (A) Plate  
(B) Scale

- 5) Position the ST by inserting the knock pin of ST into the knock hole in the transmission case.

ST 499917500 DRIVE PINION GAUGE ASSY

- 6) Slide the drive pinion gauge scale with finger tip and read the value at the point where it matches with the end face of drive pinion.

ST 499917500 DRIVE PINION GAUGE ASSY



- (A) Adjust clearance to zero without shim.

- 7) The thickness of shim shall be determined by adding the value indicated on drive pinion to the value indicated on the ST. (Add if the number on drive pinion is prefixed by +, and subtract if the number is prefixed by -.)

ST 499917500 DRIVE PINION GAUGE ASSY

- 8) Select one to three shims in the next table for the value determined as described above, and take the shim(s) which thickness is closest to the said value.

# Drive Pinion Shaft Assembly

## MANUAL TRANSMISSION AND DIFFERENTIAL

| Drive pinion shim |                   |
|-------------------|-------------------|
| Part Number       | Thickness mm (in) |
| 32295AA031        | 0.150 (0.0059)    |
| 32295AA041        | 0.175 (0.0069)    |
| 32295AA051        | 0.200 (0.0079)    |
| 32295AA061        | 0.225 (0.0089)    |
| 32295AA071        | 0.250 (0.0098)    |
| 32295AA081        | 0.275 (0.0108)    |
| 32295AA091        | 0.300 (0.0118)    |
| 32295AA101        | 0.500 (0.0197)    |

9) Install the differential assembly. <Ref. to 5MT-65, INSTALLATION, Front Differential Assembly.>

10) Set the transmission main shaft assembly for single-range and drive pinion assembly in position (So there is no clearance between these two when moved all the way to the front). Inspect the suitable 1st — 2nd, 3rd — 4th and 5th shifter fork so that the coupling sleeve and reverse driven gear are positioned in the center of their synchronizing mechanisms. <Ref. to 5MT-62, INSPECTION, Drive Pinion Shaft Assembly.>

11) Install the transmission case. <Ref. to 5MT-49, INSTALLATION, Transmission Case.>

12) Install the transfer case with extension case assembly. <Ref. to 5MT-37, INSTALLATION, Transfer Case and Extension Case Assembly.>

13) Install the manual transmission assembly to vehicle. <Ref. to 5MT-25, Manual Transmission Assembly.>

### C: DISASSEMBLY

#### NOTE:


Attach a cloth to the end of driven shaft (on the frictional side of thrust needle bearing) to prevent damage during disassembly or reassembly.

1) Unlock the caulking of lock nut. Remove the lock nut using ST1, ST2 and ST3.

ST1 899884100 HOLDER


ST2 498427100 STOPPER

ST3 899988608 SOCKET WRENCH (27)



2) Draw out the drive pinion from driven shaft.

Remove the differential bevel gear sleeve, adjusting washer No. 1, adjusting washer No. 2, thrust bearing, needle bearing and drive pinion collar.




- (A) Differential bevel gear sleeve
- (B) Washer No. 1 (25 × 37.5 × t)
- (C) Thrust bearing (25 × 37.5 × 3)
- (D) Washer No. 2 (25 × 37.5 × 4)
- (E) Needle bearing (25 × 30 × 20)
- (F) Drive pinion collar
- (G) Needle bearing (30 × 37 × 23)
- (H) Thrust bearing (33 × 50 × 3)

3) Remove the roller bearing and washer using ST and press.

#### NOTE:

Do not reuse the roller bearing.


ST 498077000 REMOVER



4) Unlock the caulking of lock nut. Remove the lock nut using ST1 and ST2.

ST1 499987300 SOCKET WRENCH (50)

ST2 899884100 HOLDER




5) Remove the 5th driven gear using ST.


# Drive Pinion Shaft Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL


ST 499857000 5TH DRIVEN GEAR REMO-  
VER



6) Remove the woodruff key.  
7) Remove the roller bearing and 3rd-4th driven gear using ST1 and ST2.  
ST1 499757002 INSTALLER  
ST2 899714110 REMOVER




8) Remove the key.  
9) Remove the 2nd driven gear, inner baulk ring, synchro cone and outer baulk ring.




- (A) 2nd driven gear
- (B) Inner baulk ring
- (C) Synchro cone
- (D) Outer baulk ring

10) Remove the 1st driven gear, 2nd gear bushing, gear and hub using ST1 and ST2. (Non-turbo model).



- (A) 1st driven gear
- (B) Inner baulk ring
- (C) Hub
- (D) 2nd gear bushing

11) Remove the 1st driven gear, inner baulk ring, synchro cone, outer baulk ring, 2nd gear bushing, gear and hub using ST1 and ST2. (Turbo model)



- (A) 1st driven gear
- (B) Inner baulk ring
- (C) Synchro cone
- (D) Outer baulk ring

## NOTE:


Replace the gear and hub if necessary. Do not disassemble because they must engage at a specified point. If they have to be disassembled, mark the engaging point on the spline beforehand.

ST1 499757002 INSTALLER

# Drive Pinion Shaft Assembly

## MANUAL TRANSMISSION AND DIFFERENTIAL

ST2 899714110 REMOVER




### D: ASSEMBLY

1) Install the sleeve and hub assembly by matching alignment marks.

#### NOTE:


Use the new gear and hub assembly, when replacing the gear or hub.



- (A) 1st gear side
- (B) 2nd gear side
- (C) Flush surface
- (D) Stepped surface


2) Install the washer to 1st driven gear.

3) Install the 1st driven gear, 1st baulk ring, gear and hub assembly onto driven shaft. (Non-turbo model).



- (A) 1st driven gear
- (B) 1st baulk ring
- (C) Gear and hub ASSY
- (D) 2nd gear bushing

4) Install the 1st driven gear, inner baulk ring, synchro cone, outer baulk ring, gear and hub assembly onto driven shaft. (Turbo model)



- (A) 1st driven gear
- (B) Inner baulk ring
- (C) Synchro cone
- (D) Outer baulk ring

#### NOTE:

- Take care to install the gear and hub assembly in proper direction.
- Align the baulk ring and gear and hub assembly with key groove.


5) Install the 2nd driven gear bushing onto driven shaft using ST1, ST2 and a press.

#### NOTE:

- Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).
- Attach a cloth to the end of driven shaft to prevent damage.
- When press-fitting, align the oil holes of shaft and bushing.

ST1 499277200 INSTALLER


ST2 499587000 INSTALLER



# Drive Pinion Shaft Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL

6) Install the 2nd driven gear, inner baulk ring, synchro cone and outer baulk ring, and insert onto driven shaft.




- (A) 2nd driven gear
- (B) Inner baulk ring
- (C) Synchro cone
- (D) Outer baulk ring

7) After installing the key on driven shaft, install the 3rd-4th driven gear using ST and press.

NOTE:

- Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).
- Align the groove in baulk ring with insert.

ST 499277200 INSTALLER




8) Install a set of roller bearings onto the driven shaft using ST and press.

NOTE:

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).

ST 499277200 INSTALLER




9) Position the woodruff key in groove on the rear of driven shaft. Install the 5th driven gear onto driven shaft using ST and press.

NOTE:

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).

ST 499277200 INSTALLER




10) Install the lock washer. Install the lock nut and tighten to the specified torque using ST.

ST 499987300 SOCKET WRENCH (50)


**Tightening torque:**

**260 N·m (26.5 kgf·m, 191.7 ft·lb)**



NOTE:

- Stake the caulking of lock nut at two points.
- Using a spring balancer, check that starting torque of roller bearing is 0.1 to 1.5 N (0.01 to 0.15 kgf, 0.02 to 0.33 lbf).




11) Install the roller bearing onto drive pinion.

# Drive Pinion Shaft Assembly

## MANUAL TRANSMISSION AND DIFFERENTIAL

**NOTE:**

When installing roller bearing, note its directions (front and rear) because the knock pin hole in outer race is offset.



- (A) Roller bearing
- (B) Knock pin hole


12) Install the washer using ST1, ST2 and a press.

**NOTE:**

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).


ST1 499277100 BUSHING 1-2 INSTALLER

ST2 499277200 INSTALLER



- (A) Washer


13) Install the thrust bearing and needle bearing. Install the driven shaft assembly.



14) Install the drive pinion collar, needle bearing, adjusting washer No. 2, thrust bearing, adjusting washer No. 1 and differential bevel gear sleeve in this order.

**NOTE:**

Be careful because the spacer must be installed in proper direction.



- (A) Driven shaft
- (B) Drive shaft
- (C) Drive pinion collar
- (D) Needle bearing (25 × 30 × 20)
- (E) Washer No. 2 (25 × 36 × 4)
- (F) Thrust bearing (25 × 37.5 × 3)
- (G) Washer No. 1 (25 × 36 × t)
- (H) Differential bevel gear sleeve

15) Adjust the thrust bearing preload. <Ref. to 5MT-63, THRUST BEARING PRELOAD, ADJUSTMENT, Drive Pinion Shaft Assembly.>

### E: INSPECTION

Disassembled parts should be washed with unleaded gasoline first and then inspected carefully.

1) Bearings


Replace the bearing in following cases:

- When the bearing balls, outer races and inner races are broken or rusty.
- When the bearing is worn.
- When the bearings fail to turn smoothly or emit noise in rotation after gear oil lubrication.
- The ball bearing on the rear side of the drive pinion shaft should be checked for smooth rotation before the drive pinion assembly is disassembled. In this case, because a preload is working on the

# Drive Pinion Shaft Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL


bearing, its rotation feels like it is slightly dragging unlike other bearings.



(A) Drive pinion shaft  
(B) Ball bearing


- When bearings have other defects:
- 2) Bushing (each gear)  
Replace the bushings in following cases:
    - When the sliding surface is damaged or abnormally worn.
    - When the inner wall is abnormally worn.
  - 3) Gears
    - Replace gears with new ones if their tooth surfaces are broken, damaged or excessively worn.
    - Correct or replace if the cone that contacts the baulk ring is rough or damaged.
    - Correct or replace if the inner surface or end face is damaged.
  - 4) Baulk ring  
Replace the ring in following cases:
    - When the inner surface and end face are damaged.
    - When the ring inner surface is abnormally or partially worn.
    - If the gap between the end faces of ring and the gear splined part is excessively small, check the clearance (A) while pressing the ring against the cone.

**Clearance (A):**  
**0.5 — 1.0 mm (0.020 — 0.040 in)**



- When the contact surface of synchronizer ring insert is scratched or abnormally worn.
- 5) Shifting insert key

Replace the insert key if deformed, excessively worn, or defective in any way.




(A) Insert key

- 6) Oil seal  
Replace the oil seal if the lip is deformed, hardened, worn or defective in any way.
- 7) O-ring  
Replace the O-ring if the sealing face is deformed, hardened, damaged, worn, or defective in any way.

## F: ADJUSTMENT

### 1. THRUST BEARING PRELOAD

- 1) Select a suitable adjusting washer No. 1 to adjust dimension (H) to zero through visual check. Position the washer (18.3 × 30 × 4) and lock washer (18 × 30 × 2) and install the lock nut (18 × 13.5).



- 2) Using the ST1, ST2 and ST3, tighten new lock nut to the specified torque.


|     |           |                    |
|-----|-----------|--------------------|
| ST1 | 899884100 | HOLDER             |
| ST2 | 498427100 | STOPPER            |
| ST3 | 899988608 | SOCKET WRENCH (27) |

# Drive Pinion Shaft Assembly

## MANUAL TRANSMISSION AND DIFFERENTIAL

### Tightening torque:

**120 N·m (12.2 kgf·m, 88.5 ft·lb)**




3) After removing the ST2, measure the starting torque using torque driver.

ST1 899884100 HOLDER


ST3 899988608 SOCKET WRENCH (27)

### Starting torque:

**0.3 — 0.8 N·m (0.03 — 0.08 kgf·m, 0.2 — 0.6 ft·lb)**




4) If the starting torque is not within the specified limit, select the adjusting washer No. 2 from following table, and recheck the starting torque.



(A) Adjusting washer No. 1

(B) Adjusting washer No. 2

5) When the specified starting cannot be obtained by the adjusting washer No. 2, select new adjusting washer No. 1 and recheck starting torque.



(A) Adjusting washer No. 1

(B) Adjusting washer No. 2

| Adjusting washer No. 1 |                   |
|------------------------|-------------------|
| Part Number            | Thickness mm (in) |
| 803025051              | 3.925 (0.1545)    |
| 803025052              | 3.950 (0.1555)    |
| 803025053              | 3.975 (0.1565)    |
| 803025054              | 4.000 (0.1575)    |
| 803025055              | 4.025 (0.1585)    |
| 803025056              | 4.050 (0.1594)    |
| 803025057              | 4.075 (0.1604)    |

| Starting torque | Dimension H | Washer No. 1        |
|-----------------|-------------|---------------------|
| Low             | Small       | Select thicker one. |
| High            | Large       | Select thinner one. |

6) Recheck that the starting torque is within specified range, then clinch the lock nut at four positions.

| Adjusting washer No. 2 |                   |
|------------------------|-------------------|
| Part Number            | Thickness mm (in) |
| 803025059              | 3.850 (0.1516)    |
| 803025054              | 4.000 (0.1575)    |
| 803025058              | 4.150 (0.1634)    |