

13. Steering Satellite Switch


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Set the tire to the straight-ahead position.
- 3) Remove the airbag module. <Ref. to AB-16, REMOVAL, Driver's Airbag Module.>

WARNING:

With the airbag module equipped, always refer to "Airbag System" when performing the airbag module repair service. <Ref. to AB-16, INSPECTION, Driver's Airbag Module.>

- 4) Remove the steering wheel. <Ref. to PS-14, REMOVAL, Steering Wheel.>
- 5) Remove the cover from steering wheel.
- 6) Remove each one of satellite switch mounting screw from the LH and RH side.




- 7) Remove the satellite switch.

B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION



	Step	Check	Yes	No
1	MUTE SWITCH CONTINUITY CHECK. 1) Press the mute switch. 2) Measure the resistance between satellite switch connector terminals. Terminals No. 1 — No. 2:	Is the resistance approx. 22 Ω ?	Go to step 2.	Replace the satellite switch.
2	VOLUME SWITCH CONTINUITY CHECK. 1) Press the volume switch. 2) Measure the resistance between satellite switch connector terminals. Terminals No. 1 — No. 2: Volume up No. 1 — No. 2: Volume down	Is the resistance approx. 90 Ω ? (Volume up) Is the resistance approx. 200 Ω ? (Volume down)	Go to step 3.	Replace the satellite switch.
3	MODE SWITCH CONTINUITY CHECK. 1) Press the mode switch. 2) Measure the resistance between satellite switch connector terminals. Terminals No. 1 — No. 2:	Is the resistance approx. 360 Ω ?	Go to step 4.	Replace the satellite switch.
4	SEEK SWITCH CONTINUITY CHECK. 1) Press the seek switch. 2) Measure the resistance between satellite switch connector terminals. Terminals No. 1 — No. 2: Seek up No. 1 — No. 2: Seek down	Is the resistance approx. 690 Ω ? (Seek up) Is the resistance approx. 1.5 k Ω ? (Seek down)	Go to step 5.	Replace the satellite switch.
5	CHECK SATELLITE SWITCH INSULATION. 1) Not to operate the satellite switch. 2) Measure the resistance between satellite switch connector terminals. Terminals No. 1 — No. 2:	Is the resistance approx. 4.7 k Ω ?	Satellite switch is normal.	Replace the satellite switch.