




8. General Diagnostics Chart A: VIBRATING PEDAL AND NOISE







B: EXCESSIVE STOPPING DISTANCE




C: IMPROPER PEDAL OPERATION



D: A.B.S. INOPERATIVE



E: FREQUENT A.B.S. OPERATION



BRAKES [ABS/TCS]

4-4b

	Page
T DIAGNOSTICS AIRBAG	2
1. Supplemental Restraint System "Airbag"	2
2. Pre-inspection	2
3. Electrical Components Location	4
4. Schematic	6
5. Control Module I/O Signal	7
6. Diagnostics Chart for On-board Diagnosis System.....	13
7. Diagnostics Chart for Warning Light Circuit Failure	18
8. Diagnostics Chart with Trouble Code	35
9. Select Monitor Function Mode	88
10. Diagnostics Chart with Select Monitor.....	96
11. General Diagnostics Table	130
12. Phenomena Peculiar to the System	131