


To wash the rear window when the rear wiper is not in use, turn the end of the wiper control lever clockwise to the "☐" position. The washer fluid sprays and the wiper operates until you release the lever.

Rear window defogger switch

CAUTION

Do not use sharp instruments or window cleaner containing abrasives to clean the inner surface of the rear window. They may damage the conductors printed on the window.

The rear window defogger operates only when the ignition switch is in the "ON" position.



To turn on the defogger, push the switch. To turn it off, push the switch again.

The indicator light located on the switch will come on when the rear window defogger is in operation.