

---

## Spark plugs

---

### ■ Replacing the spark plugs



#### **CAUTION**

- When disconnecting the spark plug cables, always grasp the spark plug cap, not the cables.
- Make sure the cables are replaced in the correct order.

Replace the spark plugs according to the maintenance schedule in the warranty and maintenance booklet.

### ■ Recommended spark plugs

---

2.2 Liter models

RC10YC4 (Champion)

[Alternate]

BKR6E-11 (NGK), K20PR-U11 (NIPPON DENSO)

2.5 Liter models

PFR5B-11 (NGK)

---

## Drive belts

---

### ■ Inspection

The alternator, power steering pump, and air conditioner compressor depend on drive belts. Satisfactory performance requires that belt tension be correct.