
■ **To disarm the system**


Unlock any door, rear gate or trunk lid with the key or turn the ignition switch to the "ACC" or "ON" position.

■ **How to turn the alarm off**

The alarm will stop only by unlocking a door, rear gate or trunk lid with the key. The alarm may not stop if the key is turned too quickly. In such a case, turn the key again more slowly. The alarm will not stop if the ignition switch is turned to "ACC" or "ON".

If the system does not operate as described above, have it checked by your SUBARU dealer.

Windows



Turn the handle to open or close the window.