
SERVICE PROCEDURE


10. Cowl Panel

A: REMOVAL AND INSTALLATION

- 1) Remove wiper arms.
- 2) Open front hood.
- 3) Remove cowl panel seal using a plier.



4) Lift cowl panel and detach it from clips attached to body panel.




5) Installation is in the reverse order of removal.

NOTE:

When installing cowl panel, first attach a middle clip to the cap attached to body panel. Then tap the cowl panel to attach it to other clips.

11. Molding and Retainer A: REMOVAL AND INSTALLATION

- 1) Remove weatherstrip.
- 2) Remove tapping screws.



3) Installation is in the reverse order of removal.

NOTE

Insert molding and retainer onto hook, then fasten with screws. Insert molding and retainer onto hook, then fasten with screws.

