


8. Front Hood Stay Installation

A: AT THE CHECK AND GENERAL MAINTENANCE



B: WHEN WIDER HOOD OPENING IS NECESSARY

Set stay into the hole of hood inner as shown in the figure below.

NOTE:

Before setting the hood in this position, remove the windshield washer hose attaching clip from the hood.

