

2. AT Shift Lock System A: WIRING DIAGRAM




B6M0466

B: BASIC DIAGNOSTICS CHART




2. AT Shift Lock System

C: DIAGNOSTICS PROCEDURE No. 1




D: DIAGNOSTICS PROCEDURE No. 2 (SHIFT LOCK DOES NOT RELEASE.)




2. AT Shift Lock System

E: DIAGNOSTICS PROCEDURE No. 3 (KEY INTERLOCK DOES NOT OPERATE.)



^{*:} When conducting operational checks of the key lock solenoid, do not apply 12 V to solenoid for more than one second, since this may break solenoid circuit.

F: DIAGNOSTICS PROCEDURE No. 4 (KEY INTERLOCK DOES NOT RELEASE.)



^{*:} When conducting operational checks of the key lock solenoid, do not apply 12 V to solenoid for more than one second, since this may break solenoid circuit.